

USER GUIDE AND WARRANTY INFORMATION



HEY THERE!

Thank you for purchasing the **JAM TRANCE MINI**. Check out the sections below for all the important information about your new Speaker.

WE'RE HERE TO HELP. CONTACT US!

You've got questions? We've got answers.

Contact a Customer Relations representative by phone or email to help answer any questions. Please be sure to have the model number of your product available. (Hint: It's HX-P460)

Register your Speaker! Information about where you bought it and how you're using it is like gold for the people who make these speakers.

US: www.jamaudio.com/customer-support/product-registration

CAN: www.Canada.jamaudio.com/customer-support-canada


USA
 ncservice@jamaudio.com
 cservice@jamaudio.com
 1.888.662.6644
 8:30am-7:00pm EST M-F

CANADA
 cservice@homedicsgroup.ca
 1.888.225.7378
 8:30am-5:00pm EST M-F


JUST CHARGE IT

Charging the speaker is so easy you've probably figured it out by now, but in case you've got two options, you can charge it using your computer or a wall outlet. The Jam Trance Mini needs about 3 hours for up to 5 hours of party time.

1. The cord that came with the speaker—the one with the USB on one end and the Micro USB on the other – will work with your computer.
2. IF you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store, or use any USB AC adaptor, including the one for your cell.




SHED SOME LIGHT



CONTROL YOUR DESTINY... OR AT LEAST YOUR SPEAKER

1. Power, press and hold for 3 seconds to power on. Let's you know *Bluetooth* is paired, & charging
2. Color selector button. Move through 7 different light programs
3. Program selector button. Move through 6 different light shows
4. Light intensity button. Control the brightness of your light show
5. Press < 0.5s Volume down. Press >3s Previous Track
6. Play/pause. Answer/hang up
7. Press <0.5 Volume up. Press >3s Next track
8. Power cord goes here
9. Here's where you hook it up old school



Switch to show ¼ angle with left side of unit to show aux-in port and charging port

BLUETOOTH® CONNECTION – IT'S A SET UP

Like any amazing couple, this one starts with a connection – one between your device and the speaker's *Bluetooth*. Here's how it works:

1. Make sure the smartphone, tablet or computer you're using with the Speaker has *Bluetooth*.
2. Turn on the Speaker and look for the little blinking light.
3. Do whatever your device your device needs to do on its end.
4. Look for Jam Trance Mini in your device's *Bluetooth* list or click YES.
5. Now hit PLAY on your Speaker and crank it up – or down if you're lame.

The device and *Bluetooth* will find each other every time just as long as the speaker is set to *Bluetooth* and your device's *Bluetooth* is, you know – on. If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company. Depending on your device you may be prompted to enter a pairing code. If prompted enter "0000" as the code. Press and hold PLAY/PAUSE for 3 seconds to activate pairing mode.




USER GUIDE AND WARRANTY INFORMATION

PUTTING ON A SHOW!


The Trance Mini comes with 6 distinctly different light programs that allow you to choose your light party.



All lights




Scaling lights



Scattered lights



Equalizer 1



Equalizer 2



All programs:
goes through all the light
programs.

LIGHT IT UP

Not only does the Trance Mini allow you to pick the light program you want to jam out to but you can also choose what color lights you want. The Trance Mini has 7 different light color programs to choose from:



BLUETOOTH® CONNECTION, CONTINUED

Note: If you turn on your Jam Trance Mini but haven't started the party yet, it will automatically power off after 2 minutes of unpaired inactivity.

Note: Once you've paired, if you pause the party for 15 minutes or more the Jam Trance Mini speaker will automatically shut off to preserve battery power.



HOOKING UP OLD SCHOOL AUDIO, JACK

1. Plug one end of the cord into the speaker and the other into the headphone jack on your device.
2. Turn on the speaker.
3. Hit PLAY on your device and crank it up-or down if you're lame.

You'll have to play and pause the music from your device, not your speaker. No problem. You're there anyway, right?

COMING CLEAN

A soft, dry towel is all you need to clean off your speaker. Using water, harsh cleaners, or anything else only starts messing with the mechanics inside. So, yeah, don't do it.

HELLO? SPEAKERPHONE? YES!

When friends call asking to join the party—and you know they will—answer the phone without disconnecting from your JAM Trance Mini. Yes, that's right. Your speaker is a speakerphone too. How amazing is that? Here's how it works:

1. Make sure your phone and Speaker are connected through *Bluetooth*.
2. Answering and ending a call works the same way: simply click the PLAY/PAUSE button on your Trance Mini
3. If you'd rather not talk, hold down the PLAY/PAUSE button on your Trance Mini for 3 seconds to ignore the call.

THE COOLEST PART: The Trance Mini knows when a call is coming in and pauses the music before ringing. When you hang up, the music starts where it left off—and so does the party. If it's you making the call, just start dialing from your phone, and the Trance Mini automatically does its hands-free thing. Isn't it refreshing to know your speaker totally gets you?

Situation	Short Press Play/Pause Button	Long Press Play/Pause Button
1 st Incoming call	Pick-Up call	Reject call
On call	End call	Move call from speaker to device
2 nd Incoming call	Call 1 on Hold, Pick-Up call 2	Reject call 2
Both calls Active	Hang up call 1, Switch to call 2	Switch between 1 st call and 2 nd call

THE VOICE FROM WITHIN

When your JAM Trance Mini isn't rocking out, it can tell you all sorts of things it's doing: when it's powering on, ready to pair, paired, maximum volume, charging, incoming call, call ended, call rejected, and powering off.

Just like the global gadget it is, your speaker toggles between several languages or no language at all. Your speaker can parlay with you in English, Spanish, French, or Portuguese. But, making the change between language and tone is as simple as poking a paperclip, safety pin, or the pin included into the small hole on the bottom. Click though until the speaker starts speaking your language.

1 YEAR LIMITED WARRANTY

For detailed Warranty Instructions and Information visit:
<http://www.jamaudio.com/customer-support/warranty-1yr>

To obtain warranty service on your Jam product, contact a Consumer Relations Representative by telephone or email for assistance (You can find their contact info on page 1).

Please make sure to have the model number of the product available.

STUFF THE GOVERNMENT MAKES US SAY

FCC Disclaimer:

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by HMDX could void the user's authority to operate this equipment.

ICD: RSS-GEN ISSUE 3 DECEMBER 2010

This device complies with Industry Canada License-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

STUFF OUR LAWYERS MAKE US SAY

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

- **WARNING:** Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to Smartphones, iPod/iPad/MP3 player or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

Attention California Residents:

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm.

A MESSAGE FROM THE ENVIRONMENT

WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local, state, province and country guidelines.

This product contains small parts that may present a choking hazard for young children.

CAUTION: All servicing of this product must be performed by authorized Jam Audio Service Personnel only.

