Manual

XY-8 Wireless Stereo Earbuds

Diagrammatic sketch

1. Magnetic contacts
2. Indicator
3. Touch area
4. Indicator
5. Type-C charging port
6. Sound outlet
7. Magnetic contacts

Specifications

- Product model:XY-8
- Bluetooth version:V5.0
- Product weight: 38g
- Earbud battery:30mAh
- Charging case battery:400mAh
- Input:5V
- Play time:3 hours
- Cahrging voltage:3.0V-4.2V
- Charging time:70 mins
- Speaker driver:32Ω
- Frequency response:20-20KHZ
- Distance:10M

Package List

- Earbuds (2PCS)
- Charging box
- USB cable
- Manual
- Gift box

How To Use

1.Power On

Automatic Power On For First Time User

Step 1: Open the lid of the charging case.

Step 2: Take the earbuds out of the charging case. Green led lights on left & right earbuds blink slowly. This means that both earbuds automaticlly have power on & paired to each other.

(Note: If red & green lights of earbuds blink alternately when take them out of the charging case, double click the right earbud until both sides earbuds slowly blink green light.)

Manual Power On When Earbuds Are Out From Charging Case

If the earbuds are not in the charging case, you can long press both earbuds individually for 5 seconds to power on.

2.Turn Off

Automaticlly Turn Off The Earbuds

Step 1 : After use, remove both left and right earbuds from your ear.

Step 2 : Put them back into the charging case to charge the earbuds.

Manually Turn Off The Earbuds

Step 1 : If both earbuds are on, long press either left or right earbuds for 5 seconds to manually power off.

Step 2 : Place them back into the charging case to charge the earbuds.

3.Connection Mode - Earbuds conntect with smart phone

Step 1 : Take the earbuds out of the charging case.

Step 2 : Make sure your smart phone' s bluetooth function is turned on.

Step 3 : find out earbuds device name"【XY8】" on your smart phone.

Step 4 : Click it to connect.

4.Normal Functions Operation

Incoming call / Reject Call:

·Touch the earbud once to answer/hang up the call.

·Long touch the earbud to reject the call.

Play/Pause

·When playing music, touch the earbud once to play or pause the music.

Volume +/-

·Touch the left earbud 3 times to increase the volume.

·Touch the right earbud 3 times to decrease the volume.

Previous/Next song

·Touch the left earbud twice to skip to previous song.

·Touch the right earbud twice to jump to next song.

Voice Assistant

·Long touch on either left or right earbud for 3 seconds to wake up Assistant.

Ear sensor

·Music start to play when put on the earbuds, the music will automaticlly stop when take off the earbuds from ears.

Indicator working status

working status	earbuds indicator status
power on	red & green lights flash alternately
standby	Lights off
charge	red led light
fully charge	Lights off
Paired successfully	Green light blinks slowly
Connect with cell phone	Lights off

Precautions for use

1、The earphones should be stored in a dry and ventilated environment, to avoid oil, water; moisture and dust affecting product performance.

2、Avoid using stimulus, organic solvents or items containing these ingredients to clean the earphones.

3、The use of earphones should be correctly as per the specification, pay attention to use the influence of environment on the earphones.

In order to ensure the smooth connection, it's recommended that the distance between the earphones and phones with in 10 meters.

4、If the earphones failed to connect or with poor connection, pls do not take apart the earphones or the accessories on your own.Otherwise, no warranty.

5、Regarding charging earphones. Pls use the standard usb cable or pointed charging cable from our company to charge the earphones.

6、In order to ensure normal use, please ensure sufficient power of the earphones.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.