



Mi Phone User Guide

Welcome

Mi phone is powerful smart phone brand presented by Xiaomi Inc.

Please visit www.mi.com to learn more features about Mi phone and purchase accessories.

To know more features about MIUI, please visit www.miui.com

This user guide may differ from actual phone due to software update. Please refer to your actual phone accordingly.

This revision is updated on 12th May, 2016

Table of Contents

Chapter 1: Overview	1
<hr/>	
Overview	1
Applications	3
Status Bar Icons	7
Chapter 2: Get Started	9
<hr/>	
Important Information	9
Battery and Charging	9
USB Connectivity	9
Headset Quick Guide	10
Chapter 3: Basic Function	11
<hr/>	
Applications	11
Gestures	11
Notification Panel	12
Text Input	12
Chapter 4: Introduction of Detailed Functions	14
<hr/>	
Phone	14
Take Photos and Videos	24
Entertainment	26
Browse the Web	29
Multi-Tasks	29
Add Widgets, Change the Wallpaper and Home Screen Thumbnail	29
Changing Themes	30
System Tools	31
Other Utilisations	32

Chapter 1: Overview

Overview

Thank you for choosing Mi Phone! This user guide will help you with Mi Phone basics and advance functions. For more information, please visit our official website: www.mi.com



*Picture shown above may differ from each model. Please refer to your actual phone accordingly.

Buttons

Names	Functions
Power Button	Long press this button to turn the device on or off.
Volume Buttons	Adjust the sound volume. Press this button when there is an incoming call to switch to silent mode.
Menu Button + Volume Down Button	Capture Screenshot.

Installing the SIM or USIM card

For phones with non-removable batteries:

1. Take the ejection pin out from print bundle ;
2. Insert the ejection pin into the hole on/beside the tray to loosen the tray and pull out the tray from the slot gently ;
3. Place the SIM or USIM card on the tray properly ;
4. Insert the tray back into the tray slot.

For phones with removable batteries:

1. Remove the back cover and the battery ;
2. Insert the SIM or USIM into the slot with metal contacts facing down ;
3. Insert the battery and close the back cover.

Applications



Phone

Making phone calls or searching contacts with T9 keyboard. You can also check your call logs.



Messaging

Messaging lets you exchange text messages with other SMS and MMS devices using your cellular connection.



Contacts

You can manage your contacts saved in SIM/UIM, external memory and Mi account.



Mail

Setup your mail account and access your mailbox with Mi phone. You will receive notification when new email received.



Music

Dirac HD sound brings a genuine improvement in audio performance, immersing your ears in a world of music.



Camera

Take photos and record videos using various modes and settings.



Gallery

The new Gallery with reorganized layout enables smooth browsing of images. Cloud albums will sync automatically, making it easy to create albums and manage photos.



Browser

It brings you a smooth browsing and reading experience, and additionally offers comprehensive security protection.



Themes

Personalise your MI Phone by choosing from hundreds of unique MI Themes. Choose your own style, change it to fit your moods simply and quickly with just a few screen taps.



File Explorer

File explorer lets you check storage usage and file browsing. You can also use WLAN to manage your phone storage remotely.



Security

The Security and Privacy functions allow you to set how you'd like to lock and unlock your phone. The MIUI supports application encryption. Using MIUI virus scan and block-list features could prevent your phone from virus attacks, spam calls and junk SMS.



Updater

Keep your updated to latest MIUI version.



Clock

Customize your alarm clock setting and tag each of the alarm.



Notes

You can take down notes and share via SMS, Bluetooth, mail and etc.



Radio

Radio supports auto scan and lets you listen to local FM radio stations.



Recorder

Recorder lets you use Mi Phone as a portable recording device.



Calendar

Check out all the dates and public holidays. Calendar also supports lunar calendar.



Compass

Find a direction, see your latitude and longitude, and level, or match a slope.



Downloads

Manage all your download contents.



Calculator

Calculator provides simple and complex calculation function.



Weather

Get the latest whether information online.



















Scanner








Portable QR code, bar code scanner.

** Application may different due to the region sold.*

Status Bar Icons

Notification bar will show below icons to indicate different status.

Status Bar Icons	Explanation
 Cell Signal	The more number of bars shown, the better cell signal reception your phone has.
 No Signal	Cannot connect to telco service provider. Only emergency numbers are available.
 Flight Mode	Airplane mode is on—you can't make phone calls, and other wireless functions may be disabled.
 Cellular Data Network Connected	Your Mi phone has been connected to cellular data network.
 4G Network	4G/ LTE network connected.
 HSPA+ Network	HSPA+ network connected.
 EDGE Network	EDGE network connected.
 GPRS Network	GPRS network connected.
 Wi-Fi Connection	Your phone has been connected to Wi-Fi nearby. The more number of bars shown, the better Wi-Fi signal reception your phone has.
 Silent Mode	Your phone has been set to silent mode.
 Vibration Mode	Your phone has been set to vibration mode.
 GPS Service	GPS and location service has been activated.
 Do Not Disturb Mode	An alarm is set
 Do Not Disturb Mode	“Do Not Disturb” is turned on.
 Bluetooth	Bluetooth function has been enabled.
 Bluetooth Connection	Bluetooth is on and paired with one or multiple devices.

Status Bar Icons	Explanation
 Network Tethering Mode	Network tethering mode is on and you can share your cellular data network with other devices.
 Earpiece	An earpiece has been plugged into your phone.
 Speakerphone Mode	Use the speakerphone to listen a phone call.
 OTG device connected	New device has been connected via OTG
 Data Synchronisation	Synchronising your data.
 Synchronisation Failure	Your phone cannot synchronise data for some reason.
 More Notifications	There are multiple notifications in your notification bar.

Chapter 2: Get Started

Important Information

To avoid injury, please read following critical information before using Mi phone.

- Please do not switch on your Mi phone in the place where wireless device is prohibited, for instance, plane, hospital and medical equipment with “No Mobile Phone” sign
- Please do not switch on your Mi phone where RF and cellular signal could possibly cause danger or interference, for instance, gas station, fuel, chemical solution and explosive article.
- Please use authentic Mi branded accessories and batteries. Do not use unauthorised accessories.
- Please keep your phone in dry condition
- Repair job should be operated by authorised professionals.
- For external plugged-in accessories, please read the user guide and handle with care.
- Xiaomi Communications Co., Ltd. and its affiliates (“Xiaomi”) will not be liable for any injuries, loss or damages due to unauthorised modifications or modes of operations of Xiaomi products.

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Caution

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

To prevent possible hearing damage,
do not listen at high volume levels for long periods.

Temperature: 0°C—40°C

Adapter shall be installed near the equipment and shall be easily accessible.

Battery and Charging

The battery icon in the upper-right corner shows the battery level or charging status. To display the percentage of battery charge remaining, go to Settings > Additional settings > Battery & performance > Battery indicator. When syncing or using Mi phone, it may take longer to charge the battery.

USB Connectivity

With the supplied USB cable, you can transfer data from other devices. You can choose the connection mode in the notification panel.

Headset Quick Guide

Pause / Play	Press the button in the middle of the remote control.
Next Song	Press the next button.
Previous Song	Press the previous button.
Answer calls	Press the middle button when someone dial in.
Finish calls	Press the middle button during a call.
Reject calls	Press and hold the middle button for 2 seconds.

** You can also customise the function of each button in the latest MIUI version.*

Chapter 3: Basic Function

Applications




- If you need to launch an APP, just tap the icon in the home screen.
- Return to home screen: Press the home button.
- Switch to other home screens: Swipe left/right on the screen, or tap the white dot.
- Switch to recent used APPs: Press the menu button.

Gestures

You can operate icon, button, menu, and input keypad via gesture function.

- Tapping: To open an APP, to select a menu item, to press an on-screen button, or to enter a character using the keypad on the screen, tap it with your finger.
- Tapping and holding: Tap and hold an item or screen or more than 2 seconds to access available options.
- Swiping: Swipe to the left or right on the Home screen or Apps screen to view other panels. Swipe upwards or downwards to scroll through a webpage or a list of items, such as contacts.
- Spreading and pinching: Spread two fingers apart on a webpage, map, or image to zoom in a part. Pinch to zoom out.
- Dragging: To move an item, tap and hold it and drag it to the target position.

- Double-tapping: Double-tap on a webpage or image to zoom in. Double-tap again to return.



Notification Panel

When there are icons shown in the notification bar, please drag down from the notification bar to open the notification panel and check the details of the information.

Text Input

Virtual keypad is available for text input purpose.

Below is an example showing how to use the input keypad. Detailed interface layout and operations depends on the keypad which you set by default.

Opening the keypad

1. Type the input field(such as typing a message) to open the keypad. There is cursor flashing in the input field.
2. Type the letter on the keypad.