

BLUETOOTH® HEADPHONE

USER MANUAL

*The picture is only provided for reference. Please refer to the actual unit!

GETTING STARTED

Please read this user 's manual carefully before using the product to make a correct use of all functions and know well about the system connection and usage.

Please keep this manual in a safe place for future reference.

INTRODUCTION


This Bluetooth® headphone will allow you to listen to your music wirelessly from your mobile phone, tablet or other Bluetooth® enabled device. It delivers powerful and clear sound. The built-in microphone will allow you to answer calls from mobile phone.

WARNING

Prolonged use of headphones at high volume may cause irreparable hearing loss. We strongly advise you to adjust your listening volume to a reasonable level. The higher the volume, the more you risk damaging your hearing quickly.

We also recommend you to use your headphones responsibly! It is dangerous or even illegal in some areas, to use headphones in situations that require your full attention, such as driving a car, motorcycle or bicycle, but also as a pedestrian when crossing the street, etc..

PRECAUTIONS



4. Places apt to fall

5. Never disassemble the combination audio; otherwise, it may invalidate the warranty.

PRODUCT OVERVIEW

Key description

1: Foldable and adjustable headband

- 2: Multi-function button (MFB) : Power on/power off/answer a call/end a call/reject a call/redial last number/pause/voice dial/play/switching between lines (three way calling)
- 3: “</V-” button: Short press for Previous Track; Long press to decrease Volume
- 4: “>/V+” button: Short press for Next track; Long press to increase Volume
- 5: LED indicator (see below for function details)
- 6: Built-in microphone
- 7: 3.5mm Aux-in jack
- 8: Micro USB Charging port

Fonction of LED indicator

A. When charging

RED LED is on when the battery is charging.

RED LED is off when battery charge is finished.

B. When using the headphone

RED and BLUE LED blink alternately when the headphone is in pairing mode.

BLUE LED blinks every 3 seconds when there is no phone conversation.

BLUE LED gradually turns on and off during phone conversation.

RED LED blinks with sound alert when the battery has low power.

CHARGING THE BATTERY

The headset comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB Cord to charge the headset. Please charge for 4 hours.

Connect the micro USB connector of the charging cable into the micro USB port on the side of the headphone. Connect the other end of the USB cable to your computer’s USB port or to an optional USB wall charger (not included)

The RED LED indicator light is illuminated.

The RED LED indicator light shuts off when the speaker is fully charged. (Approximately 4 hours).

OPERATION INSTRUCTIONS

SWITCHING ON/OFF

Switch ON : Press and hold the MFB for 2-3 seconds, until the LED flashes BLUE.

Switch OFF: Press and hold the MFB for 3-5 seconds , until the LED stops flashing.

PAIRING INSTRUCTIONS

You need to pair the headphone with your Bluetooth® enabled device (smartphone, tablet, mp3 player, computer, etc.) before enjoying the music wirelessly with the headphone.

Enter in pairing mode

Be sure that the headphone is in power off status first, press and hold the MFB for 3-5 seconds, until red and blue led blink alternately. Then release the MFB button, the unit is now in paring mode.

Pairing the headphone with Bluetooth® devices

Make the headphone enter into pairing mode (please refer to above section)

After searched, select ”OE-BTHS01” in the device list on the Bluetooth® device.

If a password is asked, enter the “0000” and press ”connect” (only some Bluetooth® devices will ask for a password)

When the connection is successful, beep sound will be heard and the BLUE LED will flash quickly for a few times while paired.

Please note pairing mode on the headphone will last for around 3 minutes. If no devices are paired within around 3 minutes the headphone will automatically return to standby mode. If pairing is unsuccessful, turn off the headphone first and then re-pair again following the above steps.

Re-connecting to Bluetooth® devices

Every time the headphone is switched on, it will connect to the nearest and the last connected device automatically .

When the headphone is in standby mode and doesn't connect to any device, short press the MFB button and it will connect to last connected device automatically.

LISTEN TO MUSIC

When the headphone is correctly paired with your Bluetooth® device, simply start to play music on your device and you can enjoy the sound wirelessly in your headphone.

Volume up in music mode: Long press on volume "+" key. You will hear a beep tone when the maximum volume level is reached.

Volume down in music mode: Long press on volume "-" key. You will hear a beep tone when the minimum volume level is reached.

Go to next song of your playlist: Short press on the Next « + » key.

Go to previous song of your playlist: Short press on the Prev « + » key.

Play/Pause music: Short press on the MFB to pause the music. Short press again to play again.

HANDS-FREE FUNCTION

You can answer calls from your mobile phone when the headphone is paired with your mobile phone. If you receive a call when listening to music, your music will pause automatically and you will hear your telephone ring tone in the headphone.

Answer a call: Short press the multifunction button.

Reject a call : Press and hold the MFB button for 2 seconds until an indication tone is heard.

End a call: Short press the multifunction button.

Volume up in conversation mode: Long press on volume "+" key. when the volume has reached the maximum level, you will hear an indication tone.

Volume down in conversation mode: Long press on volume "-" key, when the volume has reached the minimum level, you will hear an indication tone.

Voice Dial : when connected to a device in standby mode, press and hold the MFB button for 2 seconds and release when your hear the indication tone.

Redial the last number : when connected to a device in standby mode, short press the MFB button twice.

Three-way Calling

New incoming call during phone conversation : to put the call on hold and answer the new incoming call, press and hold the MFB button to switch between the phone calls.

New incoming call during phone conversation : to end the current call and answer the new incoming call, short press the MFB button once.

AUX FUNCTION

You can use the 3.5mm cable included in the kit to play music once your Bluetooth is turned off or once the battery of the device is out of power. Connect one end of the 3.5 mm aux cable into the Aux jack of the headset. The other end of the cable connects to the 3.5 mm jack of your mobile phone / computer / audio devices.

(Note: Bluetooth mode should be turned off while using the AUX feature. Don't connect Bluetooth between your headset and your mobile phone when Aux is being used.)

MOBILE DEVICES SUPPORTED

In theory, it can support all equipments with Bluetooth®-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP). In order for Bluetooth® devices to communicate with one another properly, they must utilize the same Bluetooth® profile. To determine the profiles supported by your device, please refer to the device's user guide. Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth®-enabled devices, and/or the functionality of such features may be limited in certain devices.

GUIDANCE ON SIMPLE TROUBLESHOOTING

Bluetooth® pair and connection fail

Other cell phone or equipment has been connected before connection, and has not left yet and Bluetooth® cannot be switched off. When connection feature is employed again, the Bluetooth® unit will automatically search for this Bluetooth® equipment for connection. First turn off the Bluetooth® feature of Bluetooth® equipment and the next Bluetooth equipment can search, pair and connect normally.

The indicator lamp does not turn on and the Bluetooth® unit is not available

Bluetooth® unit has not operated for a long time, and may come into dormant state, then press the MFB on the unit for a longer time to re-use it.

Low Bluetooth® volume

Check the volume level of your Bluetooth® device when playing the music and increase the volume if needed.

Short Bluetooth® connection distance

There is a barrier between the cell phone and Bluetooth® headphone, please clear it away.

Bluetooth® may be normally connected and played, but sometimes, there is interrupted

1. There is a barrier between device phone and Bluetooth® headphone, please clear it away.
2. The distance between the Bluetooth® unit and connected device is too far away, out of normal connection range. Please put them nearer.

SPECIFICATIONS

Bluetooth® specifications: 3.0+EDR

Working distance: up to 10 meters in open space

Supporting Profiles: HSP/HFP/A2DP and AVRCP Profiles

Built-in microphone for answering calls from mobile

Aux in port for cable connection of audio device

Built-in rechargeable lithium battery - Charging time 3 to 4 hours*

Up to 6 hours playing and 8 hours talk time*

* Battery life & charging time may vary, based on usage & types of devices used

Power: Micro USB cable

Unit size: 175 x 172 x 52 mm - Unit weight: 130 gr.

Box content : Bluetooth[®] Headphone – Micro USB cable – Aux In cable – User manual

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.