BLUETOOTH WIRELESS EARBUD



INSTRUCTION MANUAL

Getting Started

- Remove the product from the box.
- Remove any packaging from the product.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list.

Package Contents

- Bluetooth Earbud
- USB Charging Cable
- Instruction Manual

Safety Instructions

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids. Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not use the unit with wet hands.

Do not put objects into any of the openings.

Keep the unit free from dust, lint etc.

Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children.

This product is not a toy.

Do not use the headset at excessive volume levels, as damage to hearing may occur.

Description of Parts:



| 1 | MF (Multi-Function) / Phone button | |
|---|------------------------------------|--|
| 2 | Built-In Microphone | |

| 3 | LED Light Indicator | |
|---|---------------------|--|
| 4 | Speaker | |
| 5 | Charging Port | |

INSTRUCTIONS FOR USE

Charging Instructions

The Bluetooth Earbud comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB cable for charging.

Connect the USB cable to a computer USB port and the other end plug to the charging port of the device. The red LED illuminates while the device is charging. It takes about 1.5 hours for the unit to fully charge. When the battery is fully charged, the LED will turn to blue.

Turning on/off the Bluetooth Earbuds

Press and hold the MF button for 4-6 seconds to turn ON or OFF the device.

Pairing the device with Bluetooth devices (phone or tablet that support call-answering)

- Ensure the Bluetooth Earbud is turned off, then press and hold the MF button for 4-6 seconds until the LED flashes red and blue.
- Place the Bluetooth Earbud and Bluetooth device (phone or tablet that support call answering) no further than 3 feet apart from each other;
- Activate the Bluetooth function on your mobile device. Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your mobile device, select the "BTH-530" from the list of available Bluetooth devices.
- If required, enter the password '0000' to confirm & finalize pairing.
- Once paired successfully, the LED will turn off, and a voice 'Connected' may be heard.
- You can now start to use the earbud.

Making a call with the Bluetooth Earbud in Bluetooth mode Basic operation

| Function | Operation | Button |
|----------------------|-----------------------|--|
| Answer incoming | Incoming Call | Short press the Phone button to answer an |
| call | | incoming call. |
| Reject Incoming Call | Incoming Call | Long press the Phone button for 2-3 seconds |
| End call | Incoming Call | After your phone conversation, short press |
| | | the Phone button |
| Redial last number | Standby mode and | Short press the Phone button twice |
| | connected to a device | |

Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the

Bluetooth Earbud to stream music wirelessly. Once it is paired, play music from your device.

| Function | Operation | Button |
|----------|---------------|--|
| Pause | Playing music | Short press the MF button will pause the music |
| Play | Pausing | Short press the MF button will resume the music |

Note: Other functions including volume increase/decrease, next/previous track, you may need to control through your source device.

Specifications

| Operating distance | 33 Feet |
|------------------------|-------------------------|
| Working time | Music: up to 1.5 hours |
| | Talk: up to 2.5 hours |
| | Standby: about 20 hours |
| Charging input voltage | DC 5V |
| Charging time | About 1.5 hours |
| Built-In Battery | 35mAh |
| Size | 1.06 x 0.71 x 0.59 inch |
| Weight | 0.2 Oz |

(Note: Battery life & charging time may vary based on usage & types of devices used.)

FCC Instructions

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

| Note: modifications to this product will void the user's authority to operate this equipment. | | | |
|---|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |