

# 100x140mm

## SYLVANIA

### Bluetooth Mini LED Speaker

MODEL NO.: BTS-S02  
INSTRUCTION MANUAL



\* The picture is only provided for reference. Please refer to the actual unit!  
SYLVANIA is a registered trademark of OSRAM Sylvania Inc, used under license.

#### Instructions for use

Please read all instructions carefully

#### Getting started

Remove the unit from the box  
Remove any packaging from the product.  
Place the packaging inside the box and store for safekeeping

#### In the box

Bluetooth neon light up speaker  
Micro USB charging cable  
3.5mm Aux cable  
Instruction Manual


#### Features

- streams music wirelessly
- Bluetooth wireless connection functionality
- translucent body changes colors
- Built-in rechargeable battery
- Microphone echo effect and volume adjustment
- Support TF card playback
- built-in FM radio & Aux jack

#### Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This product is not a toy.
- Do not use abrasive cleaning solvents to clean.
- To minimize the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity.
- Do not operate around water (e.g. bathroom, swimming pool ect.)
- Do not expose to excessive heat such as sunshine, fire ect.
- Never immerse the unit in water or any other liquid for cleaning purposes.

#### Product Diagram



1	Aux jack	Aux-in jack-plays music through auxiliary connection
2	Power on /off switch	Turn on /off the speaker
3	USB flash drive Slot	Plays music from USB flash drive (not included)
4	DC charging port	DC charging port-to charge the speaker
5	Led light indicator	Indicates the recharging status
6	▶▶	Short press the button will skip to the next track or next FM radio station. Hold press the button will increase volume level.
7	LED button	Short press each time for changing 3 different lighting patterns and off within playing operation.
8	M/M/	MODE-long press for changing mode of operation (Bluetooth/AUX/TF/AUX) or short for searching FM station, short press will pause or restart the music. call answer/reject call /call end /redial button at Bluetooth phone conversation.
9	◀◀	Short press the button will return to the previous track or previous FM radio station. Hold press the button will decrease volume level.
10	Micro SD (TF) card slot	Play music from micro SD (TF) Card (not included)

#### INSTRUCTION FOR USE

##### Charging the speaker

This unit has a built in rechargeable battery.  
Before using it for the first time we recommend you use the USB cable to charge the battery fully.  
Connect the USB cable to the micro USB port or USB wall charger (Not included), ANDA connect other side to the USB charging slot of the speaker. The red battery charging LED indicator illuminates while the speaker is being charged. When the battery is fully charged, the red LED indicator will be OFF.

##### Pairing your device with Bluetooth speaker

Pairing the Portable Karaoke Player with Bluetooth devices (phone or music device)  
Slide the power ON/OFF switch to ON position.  
You would hear the indication tone and see led light bright, the speaker is now in pairing mode.  
Place the speaker and Bluetooth device (phone or music device) so that they are no further than 30 feet apart.  
Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.  
Once you have activated Bluetooth on your device, select the pairing name " BTS-S02 " from the list of available Bluetooth devices.  
If required, enter the password "0000" to confirm to pairing.  
Once paired successfully, you will hear a Ding Dong tone indicating pairing successful.  
You can now start to use the speaker.

Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

The speaker will attempt to automatically connect to the last device it was paired with when Bluetooth mode turn on. If you want to pair it with a new device, please turn OFF your last Bluetooth device (phone or music device) then use your new device to search and select the pairing name.  
Once the speaker is paired with your device the music will transmit directly to the speaker. Please refer to your device's user manual for further information.

#### Function Summary

##### Listening to Music

Once the speakers are paired with your device you can stream music wirelessly through the portable speaker.  
Select the track you wish to listen to and it will be streamed to your Bluetooth speaker, and you can use your device to control the Volume and skip tracks.

##### Talking using the Bluetooth speaker

Please ensure that your cell phone is paired with the Bluetooth speaker to use the below functions.

function	operation	button
Answer incoming call	Incoming call	Press the phone button once to answer an incoming call
Reject call	Incoming call	Long press the phone button 2-3 seconds.
End call	Incoming call	After your phone conversation, short press the phone button
Volume increase	During a call	Long press on the next track button will increase the volume.
Volume decrease	During a call	Long press on the previous track button will decrease the volume.
Redial last number	Standby mode and connected to a device	Short press the phone button twice.

##### Using the FM radio

Turn on the unit, and hold the Mode switch button to select the FM radio mode.

- 1) A short press on the Play/Pause button, FM radio will automatic searching and can automatically save;
- 2) A short press on the next track & previous track button to select the desired radio station,
- 3) Hold on the next track & previous track button to change volume;

##### TF card playback

After the speaker is turned On, then speaker search Bluetooth device, insert the TF card to the card slot will start to play the music, and the Bluetooth mode will be disconnect.

##### U disk play music

After the speaker is turned On, then speaker will be search Bluetooth device, insert the U disk to the USB port will start to play the music, and the Bluetooth mode will be disconnect.

##### Using AUX-in

After the speaker is turned On, connect one end of the 3.5mm AUX cable (included) into AUX in jack, the other end of the Cable to connect MP3 / Smartphone /phone to play music

#### Please Note

- Not all mobile phones support all the functions listed above. Please refer to your cell phone's user's manual for further information.
- Certain functions and indication tones may vary depending on your mobile phone.

#### Cleaning & Maintenance

Turn OFF the speaker if it is left unattended and before cleaning.  
NEVER immerse the speaker into water and please use a dry cloth for cleaning.

#### Storage

Turn OFF the power when you not in use, clean and store safely.

#### Do's and Don'ts

Read the following recommendations before using the speaker. Following these you will be able to enjoy the product for many years.

- Don't use abrasive cleaning solvents to clean the speaker.
- Do not expose the speaker to extremely high or low temperature as this will shorten the life of electronic devices, distort certain plastic parts.
- Don't dispose of the speaker in a fire as it will result in an explosion.
- Don't expose the speaker to contact with sharp objects as this will cause scratches and damage.
- Don't attempt to disassemble the speaker as it may get damaged if you are not professional.
- Do not expose the speaker to heat or fire. Avoid storage in direct sunlight.
- Do not subject the speaker to mechanical shock.
- Do not add any fluids or solids to your speaker.
- Do not use the speaker if it has been damaged in any way.

#### Specifications

Bluetooth specification	Bluetooth V3.0
Operating distance	10 meters (max.)
Speaker power	1 x 3W
Built-in battery	3.7V / 300mAh
Charging time	About 3 hours
Working time	About 1.5 hours

Note: Battery life & charging time may vary based on usage & types of devices used.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.