



Description of Parts:



Item	Function	Operation
1	LED charge indicator	Red light stays on during charging, and turns off when speaker is fully charged.
2	PREV / Volume decrease (-)	Short press will skip backward to the previous track, and long press will decrease the volume.
3	LED Lantern button	To adjust white LED light brightness, or change different color light mode.
4	▶ / phone button	Play / pause button - Short press will pause or restart the music. Phone button - Answer / reject / end call / redial last number. For Hands-Free Conversation
5	Power button	To turn ON/OFF the speaker.

6	Volume increase (+) / NEXT	Short press will skip forward to the next track, and long press will increase the volume level.
7	Bluetooth / Aux-in mode LED indicator	Bluetooth mode - Blue LED indicator blinks. Aux-in mode - Blue LED indicator will flash.
8	DC Charging Port	DC Charging Port – To charge the speaker
9	USB Charging Port	Use this USB Charging Port to charge your smart phones and other mobile devices
10	TF Card Slot	Play music from TF card
11	Aux-in jack	To play music through auxiliary cable.
12	Built-In Mic	For Hands-Free Conversation
13	Rubber Cover	To protect water ingress when not in use

(Note: Some of the above functions can be used in Bluetooth mode only.)

INSTRUCTIONS FOR USE

Charging the speaker

For best results, fully charge the speaker before its first use.

1. Connect the USB charging cord (included) to the DC 5V charging port of the speaker and insert the other end into a port on your computer or similar power source.
2. Red LED glows indicating that the battery is being charged. Once it is fully charged, the Red LED will turn off. It will take around 2-3 hours to fully charge the battery.

Turn On/Off the Speaker with LED Lantern

Press and hold the "Power" button for 1-2 seconds until you hear the indication tone. Blue LED indicator light will blink, your speaker is now ON and is entering "pairing" mode.

Press and hold the "Power" button for 1-2 seconds to turn off the speaker.

Turn the speaker to Bluetooth pairing mode -

1. Press and hold the "Power" button for 1-2 seconds until you hear the indication tone.
2. Blue LED indicator light will blink, your speaker is now ON and is entering "pairing" mode.

(Note: Speaker automatically pairs with the previously paired devices)

Function	Operation	Button
Increase / Decrease Volume	Playing music	Long press + to increase the volume or long press - to decrease the volume
Pause	Playing music	Press ► once to pause the music
Play	Pause	Press ► once resume the music
Skip Forward / Skip Backward	Playing music	Short press + to skip forward the track. Short press - to skip backward the track.

(Note: An indication tone will alert you when the volume is adjusted to the maximum level.)

Stream music from TF card –

- Turn ON the device.
- Insert the TF Card with songs into the TF Card Slot of the speaker.
- Speaker would automatically start playing songs from the TF Card
- To Skip Track Forward – Short press the + button.
- To Skip Track Backwards – Short press the - button.
- To Pause the Track – Short press the ►|| button.
- To Play the Track – Short press the ►|| button.
- Long press + to increase the volume or - to decrease the volume.

(Note: When you insert TF Card with songs into the TF Card Slot of the speaker, the Bluetooth of the speaker will Turn Off, automatically.)

Play music using “Aux-In” Jack

1. Turn ON the device.
2. Insert the 3.5 mm Aux in cable (included) in the Aux-in jack of the speaker. And, the other end of the cable, to the audio device (such as computer / tablet etc.).
3. The Blue LED indicator light will flash.
4. Select your favorite song at the source device.

(Note: When you insert 3.5 mm Aux in cable into the Aux-in jack of the speaker, the Bluetooth or stream music from TF card of the speaker will Turn Off, automatically. Functions except Volume Increase or Volume Decrease can be only controlled through source devices, while playing music in Auxiliary mode. An indication tone will alert you when the volume is adjusted to the maximum level.)

White LED light Mode (LEDs are not replaceable)

1. Turn ON the device.
2. Short press the LED Lantern button to turn on the White LED light mode.
3. This mode has 3 levels of brightness (low, medium, high), short press the LED Lantern button each time to change the brightness.

Color Changing LED light Mode (LEDs are not replaceable)

1. Turn ON the device.
2. Long press to turn ON the color changing LED lantern mode with Red light first, and then short press each time to switch to different light modes. The light modes include: Red -> Blue -> Green -> Purple -> Cyan -> Alternative -> Dynamic.
3. While it is on any color light mode, long press to change to white LED light model.

Recharging External Devices (through this speaker)

Turn ON the device. Use the USB Charging port of the speaker to charge your external devices like smart phones etc. Using this saves you from having an extra charger to keep your devices powered.

Do's and Don'ts

Do not play music at excessive levels. Damage to hearing and/or equipment may result.
Do not use outdoors in excessive rain or extreme weather conditions.

Specification

Bluetooth version	: 2.1+EDR
Speaker power	: 5 Watts
Unit Size	: 9.4 cm x 9.4 cm 19.3 cm
Unit Weight	: 510 gram
Run time (Music)	: Up to 1.5 hours
Run time (LED lantern)	: 7 to 8 hours
Charge Voltage	: DC5V (USB)
Bluetooth Range	: 10 meter
Built-In Rechargeable Battery:	3.7V / 1200mAh
USB Charging Port	: 5V / 500mA (Max) Output

(Note: Battery life & charging time may vary based on individual handling & other environmental conditions)

Getting Started

- Remove the device from the box.
- Remove any packaging from the product.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Bluetooth Speaker with Color Changing LED Lantern
- USB rechargeable cable
- 3.5mm Auxiliary cable
- Instruction Manual

Key Features

- Bluetooth Lantern Speaker
- With colour changing LED light
- Connects to any Bluetooth enabled device
- Stream music wirelessly from your iPhone, iPad and other Android/Windows devices
- Connects via Bluetooth to most smartphones, tablets, computers and other Bluetooth enabled devices
- Built-in Color Changing LED Lantern
- Silicone carrying handle
- Built-in MIC for Hands-Free Bluetooth calls
- Power bank function
- Aux & charging cables included

SAFETY INSTRUCTIONS

- Read all instructions before using this product
- Do not leave this product unattended while connected to the power supply.
- Do not immerse in water or any other liquids.
- Keep the unit away from heat sources, direct sunlight, humidity, dust and any prolonged contact with water or liquids.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Do not
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This appliance is not a toy.
- Do not use the handset at excessive levels as damage to hearing may occur.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat, such as sunshine, fire etc.
- If the unit has not been used for a long period, make sure you charge the unit fully before you start using it again

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.