

User Guide



EHBTF101A7



Table of contents

The introduction of Intel PPC (Tablet PC)	3
The function table of the Intel PPC (Tablet PC).....	4
The setting of Intel PPC (Tablet PC).....	4
Power on and start.....	5
Basic knowledge.....	5
Touch, keyboard and the mouse.....	5
Start screen.....	5
Turn to Start screen	5
Open the applications	6
The touch operation list	6
Super button.....	7
The familiar screen.....	8
New functions of part Windows 8.1.....	8
Lock screen mode and login.....	9
The introduction	9
Network connections	9
Setting the E-mails.....	10
Contacts: add contact	10
The knowledge about Intel PPC.....	10
Power status: boot, shutdown, standby and restart.....	10
Charge	11
The touch screen.....	11
The screen keyboard.....	11
Physical keyboard.....	11
Close the keyboard.....	12
Touch pad	12
Sound functions.....	12
Open apps.....	12
Find and open the application	12

Switching between the opened applications.....	12
Use the application at the same time (side by side).....	13
Close the application.....	14
Application command.....	14
Application Settings and help	14
The setting up of the applications	14
Your account	14
Access to applications.....	14
Delete the applications.....	14
Re-install the application.....	15
The setup program from the INTERNET, CD or network	15
Personalized Settings, Intel PPC.....	15
Add an account.....	15
Personalized Settings "start" screen.....	15
Connection device.....	16
Connect USB mouse, printers and other accessories	16
Use the mouse.....	16
Add Bluetooth device.....	16
Add, delete, and manage devices and printers.....	16
Connect to TV, monitor or projection.....	17
Network.....	17
Connection to wireless network.....	17
Disconnect the wireless network connection.....	17
Built-in applications.....	17
Camera.....	17
Music.....	18
Photo.....	18
Video.....	18
Other information you should understand.....	18
How to restore, recover or reset the Intel PPC.....	18
The production specifications.....	19

The introduction of Intel PPC (Tablet PC)

Intel PPC is the one which can really replace a portable computer. You can connect all kinds of accessories, printers, and network as usual. Run the touch application and your favorite Windows 8 program, and it is as security and easier to be managed as PC.



The function table of the Intel PPC

The touch screen	10.1 inch IPS monitor, aspect ratio is 16:9, and the resolution ratio is 1280 x800 pixels, which is very suitable to browse a network, watch high hd movies, and use Office applications. You can use your finger on the screen, zoom and move the Item.
CPU& RAM	Intel PPC: Intel®Z3735F,G,LPDDR3
Two cameras and a microphone	Two cameras and a microphone allows you to easily use Intel PPC recording video and make a phone call Cameras can record the video of 720p hd video recording, and the aspect ratio is 16:9 (wide screen).
Stereo speakers and earphone jack	Two stereo speakers and a headphone jack for audio output and microphone input, and you can attend the online meeting and listening to music.
Memory	Select 16, 32, 64 GB of internal flash memory.
Port	Full size USB 2.0 port connects USB accessories, such as mouse, printer, or Ethernet adapter, etc. MicroSD card reader will use MicroSD card reader as additional storage or for transmission gears. Mini HDMI can to the HDTV, display quit projector to share the content (video card sold separately) by Intel PPC connect. When the battery charging port is low in power, please connect with power adapter.
Software	Intel PPC comes with a lot of built-in applications ----in your "start" screen, you can see the magnet of the application. You can install more applications from Windows applications store.
WiFi & Bluetooth	Intel PPC supports standard wi-fi protocol (802.11b/g/n) and Bluetooth 4.0 ®. This means that you can connect a wireless network, and use Bluetooth devices (for example, keyboard, mouse, printer, and earphones).
Sensor	Intel PPC has two sensors (ambient light sensor, dynamic sensing), you can use them to complete the outstanding functions.

Setting the Intel PPC

Before we start, make sure that the wireless network is available and you have a network password (if the protected network).

Power on and start

1. Plug the Intel PPC in the keyboard socket.
2. Plug the power cable to the wall socket or the patch panel
3. Connect the power connector to the charging interface of Intel PPC.
4. Press and release the power button (upright side).The Intel PPC will be enabled to start and set.

Basic knowledge

You need to know the following information related with the Intel PCC

Touch, keyboard and the mouse

Using Intel PPC, you can easily switch between touching, keyboard and mouse.

Touch: like intelligent mobile phone, you can use your fingers to perform the touch screen operation. Such as: drag the finger on the screen to scroll.

Keyboard: connecting auxiliary keyboard or use full size USB or Bluetooth keyboard.

Mouse: use the matching keyboard touchpad or connect with the USB or Bluetooth mouse.

The Start screen


[Start] is like the Intel PPC heart, and you can open the application here to see your best friend's new information.

Turn to the Start screen

[Start] is like the Intel PPC heart, and you can open the application here to see your best friend's new information, and visit your favorite website.

"Start" screen interface indicates the relative information, such as new email and new date on the calendar.

Turn to the Start screen:

Touch: Touch or press the  part below the touch screen, or slightly touch and move from the right edge of the screen to the left, then click "start".

Keyboard: push the  Windows instructions key on the keyboard.

Mouse: click the "start" button  on the left corner of the screen









Open the applications



Touch or mouse: click or click once the application magnet on the "start" screen.

Keyboard: turn to "start" screen and type the application name (such as Word or SkyDrive).

Slightly touch and move upward from the middle of the "start" screen to check all applications.

Touch operation list

Hands movements	Operation method	Functions
Switching applications 	Slide from left edge on the plane to the right	You can switch between open applications. You can continue to slide, and switch one application every time.
Slide from the edge 	Slide from the edge to the inner part.	Right edge: open the super button Left edge: Indication the opened applications. Upper or lower: Indicating the command or close the application
Application options 	Slide from the lower edge of the screen toward upper edge or from the upper edge of the screen toward lower edge	According to the application options
Click 	Click once on a certain pattern.	Open, select, or start the item of your clicked. It is similar to press the left key of mouse.
Click and hold 	With your finger pushing down for around one second.	To indicate the operation that relates to the option that you hold (similar to press the left key of mouse.).
Shrink or stretch 	With two or more fingers touching the screen or one item, and then move your fingers inward (shrinkage) or outward (dragging).	Zoom, map or image website.
Rotating 	Put two or more fingers on an item, and then turn your hand.	Rotate the items which can be rotating
Slightly sliding to scroll 	Drag the finger on the screen.	Scroll the contents of the screen (similar to use the mouse scroll).

		
<p>Slightly sliding to select</p> 	<p>Opposite to the screen scroll direction, moving rapidly, and slightly slide an item.(For example, if the screen scroll to the left or right, then touch the item slightly upwards or downwards)</p>	<p>Select a project, such as the magnet application or photos. Usually the applications command will be displayed.</p>











Super button

No matter which position of the equipment you are in, you can complete one of the most common operations, such as search and sharing, print, and change the Settings by the Super button. You can open Super button through the following ways:

Touch: Slightly slide from the right edge of the screen to the right, and then click the super button you need.

The mouse: Move the mouse pointer to the right upper corner or the right lower corner, then move the pointer upwards or downwards, and then press super button.

The following operation can be done by the Super button

<p>Search</p> 	<p>No matter which position in the equipment, super button ( +S) can complete most common operations, such as searching, sharing, printing, and change the Settings. You can open through the following ways:</p>
<p>Share</p> 	<p>In the application, you can use the "share" ( +H) to share files, pictures, or web page.</p>
<p>Start</p> 	<p>Use the "start" button () that can turn to the "start" screen. Or if you have been in the "start" on the screen, the application allows you to enter the last use.</p>
<p>Equipment</p> 	<p>Using the "equipment" ( +K) can play, projection and print to the device.</p>
<p>Setting:</p> 	<p>Use the "Settings" ( +I) can change Intel tablet Settings, or if you are in the application, you can enter the application Settings.</p>

The familiar desktop

After introduce all the new content, here are you familiar with the content.

Windows Desktop (including taskbar, folders and icons) remain, including new taskbar and simplify document management.


To go to the desktop, perform the following actions:

Touch: click on the "start" screen "desktop" (this is a magnet).

Mouse: click the "start" button  to screen the bottom left corner.

Keyboard: press Windows instructions  +D.

Desktop is you run the Office desktop applications, such as using the console or document the location of the resource manager.

If you want to open a console and other Settings: right-click on the screen the bottom left of the "start" button .

Part of new contents about Windows 8.1

Task or items	Operation method of Windows 8.1
Search	The search is the new searching method.
The Start Menu	In Windows 8.1, The "start" screen replaces the "start" menu screen. From "start" screen, you can start any applications or programs. To access the items on the previous "start" button, please click the start button on the left lower corner of the "start" button.
Shutdown or restart	Open the "Settings" super button, click "power", and then select the "shutdown" or "restart".
Console (change Settings)	"Console" is still available, but many Settings are in the PC Settings.
Printing	There is no change to print form the desktop. If you want to print from Windows application store, open equipment, and then select to print.
Close the application	There is no change to close the application from the desktop. If you want to close the application from Windows application store, drag the application out of the screen bottom.
Check all the applications and program	If you want to check all the applications, slide from the middle of the start screen upwards.
The installing of the application and program	Windows 8 with brand new app store called Windows app store.
Change the date and time	Open the setting, click "change the PC Setting> Time and Language."

Lock screen and login

Microsoft account, lock screen interface and "Start" screen and other personal settings can follow you to the other devices. Your favorite websites, browser history, and a fixed website also can follow your moves.

If you do not use Intel PPC for a few minutes, the screen is closed and locked. After locking the screen, press any key (or press and release the power button), then slide upward on the touch screen. Then type the password and log in the account.

Now we come to set up your e-mail and other accounts.

Getting Started

Now that you understand the basic knowledge, we will connect the networking and add accounts.

Connect Network

Network connection methods as following:

1. Open the "Settings" super button (slide from the right edge of the screen to the left and click "Settings").
2. Click the wireless network icon.
3. Click the network with which you want to connect, and then click "Connect."



Set up email

Now we start to set up your e-mail. You can add Outlook.com, Gmail, AOL, Yahoo! and Exchange e-mail account to the "Mail" application.

Note that the "Mail" application does not support the use of POP (Post Office Protocol) account.

Follow the below operations to add an e-mail account:

1. Click "Mail" on the "Start" screen.
2. Open the "Settings", and then click "Account"> "Add Account."
3. Select the type of account you want to add, and then follow the onscreen instructions.

Contacts: Add a contact

"Contacts" application is your general address book. You can check all the contacts in the address book; understand the updating of your best friends. You can also synchronize your concern social network contacts, for example, Facebook, LinkedIn and Twitter. Directly send mails, make phone calls or release information to contact others from the "contacts" application.

The following method is to add account contact:



1. Click on the "contact" on the "start" screen.
2. Open the "Settings", click the "account" > "add account".
3. Select the account type you want to add, and then follow the screen instructions.

Introduction of the Intel tablets

Now that you have added the account, we will have a further introduction.

Power supply: Boot, shutdown, standby and restart

The following is an overview of Intel PPC power status:

Status	Operation method
Boot/wake	Press and release the power button. If there is no response, Intel PPC may need to charge. Connect the power adapter, and then press the power button again.
Shutdown (turned off)	Open the "Settings", click the "power"  > "Shutdown". Intel PPC: you can also hold down the power button for 2 seconds, and then slide gently down on the screen.
Sleep	Close the keyboard, press and release the power button, or don't use the Intel PPC for a few minutes.
Restart	Open the "Settings" super button, click the "power"  > "restart".

Charging


Intel PPC has the built-in lithium battery, and allows you to carry with it. Battery life varies, depending on your Intel tablet usage and the power supply current plan. Insert the power cord to a power outlet or patch panel. Then the power connector is connected to the charging interface. Intel PPC light is on when power supply is connected.

Touch screen

Multi-touch screen with a 16:9 aspect ratio, which is very suitable for watching high-definition video and application of multitasking operating together. Like using an intelligent mobile phone, you can interact with the PPC by touching the screen.


The screen keyboard


Intel PPC calculator has a screen touch keyboard to be displayed only when it is needed.


1. Click the screen to input the position of the text, then the screen keyboard will be displayed.
2. If on the desktop, click the desktop keyboard icon  in your task tray (bottom right) to open the screen keyboard.

If you want to manually open the screen keyboard (type the content location without a click), please do the following:

Open the "Settings" super button, click the "keyboard" > "touch keyboard and the handwriting panel".

If you want to close the screen keyboard on Intel PPC, do the following: click the area where the text cannot be input or click the keyboard button ,

then close the keyboard button. .



A physical keyboard

The keyboard can be inserted to the Intel PPC by a rotation shaft.

Put the two closing, and insert the PPC into the keyboard rotation shaft; after the connection, the keyboard stay in original position, move the press button on the left Side of the axis to the right, and the PPC can be easily separated from the keyboard by pulling.

Close the keyboard

When you close the keyboard, the screen will close, and the Intel PPC will also enter the sleep state.

Touch pad

Keyboard includes a touchpad similar to the mouse. Same as a portable computer, you can move the pointer on the screen by dragging your fingers on the touch pad. If want to click, then click on touch pad (mouse the left key click) once.

The sound function

Intel PPC calculator has two stereo speakers and the earphone jack, which can be used to listen to music or watch movies. When you make a phone call or video recording, you can easily use the built-in microphone.

Using the application

Find and open the application

You can start the application on the "start" screen, just like using the Windows "start" button.

Intel tablet can run two applications:

Windows app store for example music, email, and weather.

Desktop applications for example note pad and office applications.

If you're looking for Intel tablet application or program, please operate as the following:

Application view: gently slide upward from the middle of the "start" screen (or click the "start" on the lower left corner of the screen). Application list will be displayed. Type the name or scroll to see all applications.


Use the search: open the "search" super button, and then type the application name, such as "email".

If you did not find the application or program you need, you should search within the Windows application store.

You can also start the desktop application from the desktop. You can create a shortcut for a desktop application, or the fix the common applications in the taskbar on desktop.

Switching between the opened applications

If you want the application to be displayed in full screen, you can quickly switch between the opened applications. Operation method is as follows:




Switch to previous application

Touch: slightly slide from the left edge of the screen to the right light.

Mouse: move the mouse pointer to the left upper corner of the screen, and then click.

Keyboard: Press Alt + Tab



Switch to a specific application

Touch: Slightly slide from left edge of the screen to the right, and the finger stays on the screen at the same time, and then back to the left edge. Click the required application.

Mouse: moves the mouse pointer to the upper left corner, then move down vertically. You will see the most recently used applications. Click the required application.

Keyboard: press the Alt key. And repeat press the Tab key to switch applications. When you go to the required application, and then let it go.

Using the application at the same time (side by side)

You can use two applications side by side. So you can see two applications on the screen at once (such as email and calendar application).

Using two applications together and the method is as follows

1. Open each application that you want to use.
2. Open the list of recently used applications (from the left edge of the screen to the right light, keep your finger stays on the screen at the same time, then move backward to the left edge.)
3. Don't stop dragging an application from the application list, until the dimension of the current application changed, and then loosen the application.
4. If you want to adjust the size of the application, please drag the vertical bar between applications.

If you want to change one of the applications, then go to "start" or "application" view, and then click an application.

It will display over the first two applications. Click the right side of the left edge of the screen.

Close the application

You don't need to close the application of the Windows application store. When you switch to other applications, Windows will run in the background to keep the original application, and finally to shut it down when you aren't using.

You can also close the application of Windows app store through the following way:

Touch: slightly slide from the upper edge to the lower edge on the screen, and drag the application down outside of the screen.

Mouse: move the pointer to the top of the application, when the pointer becomes a hand shape, click and drag the application down outside of the screen.

The application command

If you want to find out how to operate the application, you can open the application command. The following is the operation method:

1. Open an application, and then any performs the following operations:
Touch: slightly slide from the lower edge of the screen up or down from the screen edge.
Mouse or touch pad: click the right key. You can also click twice in the touchpad at any position.
Keyboard: Press the + Z.
2. One option on the command line.

Application Settings and help

In the application Settings: open the "Settings" super button from the application. For example,

Open the "mail" application, then open the "Settings" super button-- you will see the "mail" application Settings.

Application help: open the "Settings" from the application super button, and find the "instructions".

Install the application

You can explore various powerful application and games in Windows application store. You can browse the application by grouping or by category, such as "recommended" and "hot". If you already know the one you want to find, you can use the "search".

Your account

Before installing the application from the Windows app store, you need to use Microsoft account to log in.

Access to the application

When you want to install more applications or games, just turn to Windows app store.
Note: you need to connect to the Internet and use Microsoft account to log in, and then you can install the application.

Delete the application

If you do not use an application, it can be removed. The following is operation method:

1. Go to "start" screen, and then lightly slide upward from the middle of the screen.
2. Press down the application you are trying to remove for a few seconds.
3. Click "remove". If the application is a desktop application, please select the application from the list, and then click "discharge"

Reinstall the application

You can reinstall your purchased application or game, do not need to pay again (as long as the Windows app store provides.)

Application update

Publishers sometimes will update its application to add new functions and repair some problems. Windows app store can automatically install the updating the application during the updating.

The installation program from the Internet, CD or network

You can also install the application or program from the CD/DVD, website or network.

Personalized Settings of the Intel PPC

Add the account

If you haven't added E-mail or social networking account, please refer to the introductory section of this guide.

Personalized Settings of the "start" screen

You can change the color of the "start" screen and background. Operation method is as follows:

On the "start" screen, open the "Settings" super button, and then click the "personalized Settings".

Change the lock screen interface

The lock screen interface can include pictures, slides and application notice, such as your next calendar date. The following is the method to change the lock screen interface Settings: Open the "Settings" super button, click the "change computer Settings" > "computer and equipment" > "lock screen interface.

Notice

You can know whether there is a new email, news, calendar events, status updates and tweets through a variety of ways. The top right corner and the lock screen interface will display a notice

Add language

By adding a language, you can change on Windows, application and Web the language used for speaking, reading and writing.

The desktop background, color and sound

If you want to change the desktop background, color and sound, please do the following:

Open the setting Super button from the desktop, and then click or click the "personalized Settings". Choose a topic or change the desktop background, color and sound one by one.

Choose the screen after login

By default, login to the Intel PPC will see after the "start" screen. However you can also enter the desktop or the application view.

Connecting devices

Connecting with USB mouse, printers and other accessories

Intel PPC has a full size USB 3.0 port, which can be used to connect the matching devices such as a printer, camera, music player, phone, a mouse, or even external hard drives.

Using the mouse

You can use the touch pad on the keyboard cover, or add a USB or Bluetooth mouse.

USB, please insert the mouse into Intel PPC USB port

Add Bluetooth devices

You can use the following methods to add Bluetooth devices on the Surface PPC (also known as matching):

1. Enable the Bluetooth device, then the set it as the detected
2. Open the "Settings" super button, click "change computer Settings" > "computer and equipment" > "Bluetooth".
3. Ensure that Bluetooth is enabled, and then wait for Windows to search the Bluetooth devices.
4. Follow the screen instructions to complete the equipment matching.

Add, delete, and manage devices and printers

If you want to delete and diagnosis the abnormal operation of equipment, please refer to Windows.com to add, delete and management devices and printers.


Connect to TV, monitor or projector

You can watch the movies on a big screen by connecting the Intel PPC to the TV set, or connecting to a projector up to share the Powerpoint, or connect to another monitor to show the running multiple applications..


Network

Intel PPC with built-in wi-fi can be used to connect to the Internet. After networking, you can browse the Internet, get the application, send E-mails, and visit other computers and other equipment in the computers network.

Connecting to the wireless network

1. Open the "Settings" super button, and then click or click the wireless network icon  .
2. Click or click a wireless network which can be connected.
3. Click or click "connect". Input your network security keys (network password) after you see the cue note, then click or click "next".
4. Choose whether you want to connect to other computers and other equipment within the network. If you are in public places (such as a coffee shop), and you want to connect to the Internet, please select "no".

Disconnect the wireless network connection.

1. Open the "Settings" super button, and then click the wireless network icon  .
2. Click or click on the "connected" state of the network, then choose "disconnect"

Built-in application


Intel PPC has many built-in applications

Camera

Intel PPC has two cameras: you can use the front-facing camera for Skype, use the rear camera to record the meetings and activities. When Intel PPC is placed on the table by using the first kind of one-piece support position, the front-facing camera should point to the right forward.

Music

You can use "music" application to play the collected music

1. On the "start" screen, click or click the "music". After see the cue note, log in by using Microsoft account.
2. Click on the left side, or click the "collection".
3. Check your collections according to "album", "artist" or "song". Or use the "search"  to find what you want to play.
4. Select a song or album, and then click, or click the play button

Photo

You can use the "photos" application to view the photos on the Intel PPC and on the SkyDrive

If you want to see your photos, please go to "start" screen, and then open the "photos" application.

The pictures in the photos folder will be displayed in the photos "applications. If you want to view the " slide show "and" selection "command, please slightly slide down from the upper edge of the screen.

Video

You can use the "video" application to watch the video on the Intel PPC.

1. On the "start" screen, click the "video"
2. Scroll to the left to view video.
3. Click the video to play the video.

Here more information that you should know.

How to restore, recover, reset the Intel PPC.

If there are problems on your Intel PPC, you can try to restore or reset the Intel PPC

By restoring, you can annul the recently changed system.

By restoring, you can reinstall Windows and keep your files, Settings, and application

Through the resetting, you can reinstall Windows, but your files, Settings, and application (Intel tablets with the application of the exception) will be deleted.

Product Specifications

The operating system	Windows 8.1 Bing
The processor	Intel Bay Trail-T Z3735F
Memory	2GB DDR3
The storage space	64GB Flash memory
Display screen	10.1" 1280*800
Touch screen	10 touch screen
WIFI	802.11 b/g/n
Camera	Front 200W, rear500W
Orientation sensing	3 D Orientation sensing

The above specifications are for reference only, and see the real product for detailed information

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.