

SW501

Smart Watch Quick User Guide




€2200

The device contains tiny parts and is not suitable for children under 3 years old. Please keep it out of children's reach.


Button Description



Package Contents



Watch



Charge Cable



Watchband

Other accessories: Quick User Guide


How to Use

1. Power On/Off

To power on, press and hold the **Power** button for about 2 second until you feel a bit vibration.



To power off, press and hold the **Power** button for about 2 seconds, and then tap “OK” to confirm.




2. Basic Operations

- Home Screen



- **Turn over page**


Slide your finger on the screen to turn over the page.



- **Applications**


- A. Nextone Pedometer**

Count your walk steps and calories that your body consumed each day to monitor your daily exercise.




- B. Weather**

Real-time weather forecast.




C. Notifications

Notifications of incoming calls, messages or SNS.




D. Find the phone

To find your phone by making your phone ring or vibrate.



E. Camera

Remotely control your phone's camera to make a self-timer.



- **Go Back**

Press the **Home** button.



3. Pairing with Smart Phone

- (1) Slide rightwards to display menu and select "Settings".




(3) Turn on the Bluetooth, and select the Smart phone from device list.



(4) Start pairing.



(5) Tap “OK” after pairing.



Indroid Sync Mobile

Information in your smart phone such as contact list, message, etc can be synchronized with your Smart Watch by the application **Indroid Sync Mobile**. Before synchronization, firstly you need to install the application **Indroid Sync Mobile** in your Smart Phone.

The **Indroid Sync Mobile** apk is available at

<http://dl.yifangdigital.com/file3/yfly/sync.apk>

Please kindly note that the application Indroid Sync Mobile can only be used in Android Phones. The version for iPhone will be available later.


1. Install Indroid Sync Mobile APK in your Android Smart Phone.



- Pairing Smart Watch with Smart Phone by Bluetooth. Choose Settings both in Smart Watch and Smart Phone to open Bluetooth and then choose Scan to search and pair.




3. After pairing Smart Watch and Smart Phones, you will be reminded to confirm with passkey and then click OK both in Smart Watch and Smart Phones.




4. Run the application Indroid Sync Mobile in your Smart Phone, and then click the lower-left button in the Phone and choose Setting to set detailed sync information.



5. Click Sync Settings under the Setting and then choose items from the list to be synchronized with your Smart Watch. During the sync process, please make sure Bluetooth in your Smart Phone and Smart Watch are paired.




6. Quick SMS is used to set quick response to message.




7. Cancel Bonded is used to disconnect Bluetooth between the Phone and Smart Watch. Do not cancel the bond

during the synchronization. If you want to use another Smart Watch or another Phone, you can cancel the bond firstly.



8. System Update shows the current application version.



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.