


ZAGG®

Quick Start



charisma wireless

Female-Inspired Wireless Earbuds

charisma wireless instructions

- 1 Introduction**

Designed by women, for women, the Charisma Wireless earbuds give you stylish sound that stands out. Here's how to get the most out of them. To download a complete manual, visit www.zagg.to/manuals.
- 2 Wireless Hub**

Your Charisma Wireless earbuds feature a wireless hub that houses all the music and call controls for easy access. When you're not using your earbuds, the magnetic Storage Clip™ makes cable management easy; simply wrap the earbud cables around the wireless hub and secure in place with the Storage Clip. Whether they're in your ears or in your pocket, the Charisma Wireless earbuds were made to move. Below is a quick reference for how to use the wireless hub:

Button Functions:

Raised bump button (Up button)


- Quick press - Volume up
- Long press - Track next song

Middle button (Center button)

- Quick press - Play/Pause/Answer call/End call
- Medium press - Voice control
- Long press - Power on/Power off/Deny call

Recessed groove button (Down button)

- Quick press - Volume down
- Long press - Track previous song



- 3 Power and Pair**
 1. Press and hold the Power button until the LED flashes red and blue.
 2. Ensure your device's Bluetooth® connection is on and select "IFROGG Charisma". Complete any additional pairing steps based on your device. The LED will flash blue every five seconds while your earbuds are on and paired.
 3. To turn your earbuds off, press and hold the Power button for three seconds. The LED will flash red until they are powered off.
 4. The next time you turn on the earbuds they will automatically connect to your device.

- 4 Charge**

To charge your earbuds, connect the micro USB end of the included charging cable to the port at the end of the wireless hub and the USB end to your preferred USB outlet. The LED will light red while they are charging and will turn off when they are fully charged.

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

1 Introduction

Conçu par des femmes, pour les femmes, les écouteurs de Charisma Wireless vous donner un son avec style qui se démarque. Voici comment profiter au maximum parti d'eux. Pour télécharger un manuel complet, visitez www.zagg.to/manuals.

2 Centre sans fils

Vos écouteurs de Charisma Wireless disposent d'un centre sans fils qui abrite tous les contrôles de musique et d'appel pour un accès facile. Lorsque vous ne l'utilisez pas vos écouteurs, le champ magnétique de Storage Clip™ rend la gestion des câbles facile; tout simplement envelopper les câbles des écouteurs autour du centre sans fils et sécurisé en place avec le Storage Clip. Lorsque qu'ils soient dans vos oreilles ou dans votre poche, les écouteurs de Charisma Wireless ont été faits pour se déplacer. Voici une référence rapide pour savoir comment utiliser le centre sans fils :

Fonctions des boutons :

Bouton bosse (bouton en haut)


- Presse rapide - Volume augmente
- Appui long - Chanson suivante

Bouton au milieu (bouton central)

- Presse rapide - Lecture/Pause/Répondre à un appel/Terminer appel
- Presse moyenne - Contrôle vocal
- Appui long - Alimenter/Éteindre/Refuser appel

Bouton rainure en retrait (bouton en bas)

- Presse rapide - Volume diminue
- Appui long - Chanson précédente



3 Alimenter et jumeler

1. Appuyez et maintenez le bouton d'alimentation jusqu'à ce que la LED clignote rouge et bleu.
2. Assurez-vous que la connexion de Bluetooth® de votre appareil est alimentée et sélectionnez "FROGZ Charisma". Remplissez tous les étapes de jumelage supplémentaires en fonction de votre appareil. La LED clignote en bleu toutes les cinq secondes pendant que vos écouteurs sont allumés et appariés.
3. Pour éteindre vos écouteurs, appuyez et maintenez le bouton d'alimentation pendant trois secondes. La LED clignote en rouge jusqu'à ce qu'ils soient éteints.
4. La prochaine fois que vous allumerez les écouteurs, il se connectera automatiquement à votre appareil.

4 Charger

Pour charger vos écouteurs, connectez l'extrémité de micro USB du câble de charge fourni au port à la fin du centre sans fils et l'extrémité d'USB à votre prise USB préféré. La LED va être rouge pendant qu'ils sont en charge et éteindre quand ils sont complètement chargés.

1 Introducción

Diseñados por mujeres y para mujeres, los auriculares Charisma Wireless te proporcionan un sonido refinado que destaca. A continuación te mostramos cómo sacarles el máximo partido. Para descargarte un manual completo, visita www.zagg.to/manuals.

2 Hub inalámbrico

Los auriculares Charisma Wireless cuentan con un hub que almacena toda la música y los controles de llamada para acceder a ellos fácilmente. Cuando no usas los auriculares, el Storage Clip™ magnético hace que gestionar el cable sea muy sencillo, simplemente enrolla los cables alrededor del hub inalámbrico y sujétalos con el Storage Clip. Tanto si los llevas puestos como si están guardados en tu bolsillo, los auriculares Charisma Wireless están hechos para moverse. A continuación mostramos una guía rápida de referencia de cómo usar el hub inalámbrico:

Funciones de los botones:

Botón elevado (Botón superior)


- Pulsación rápida - Subir volumen
- Pulsación larga - Pasar a la siguiente canción

Botón intermedio (Botón central)

- Pulsación rápida - Reproducción/Pausa/Responder llamada/Finalizar llamada
- Pulsación media - Control de voz
- Pulsación larga - Encendido/Apagado/Rechazar llamada

Botón ahuecado (Botón inferior)

- Pulsación rápida - Bajar volumen
- Pulsación larga - Pasar a la canción anterior



3 Encendido y conexión

1. Mantén pulsado el botón de Encendido hasta que el LED parpadee en color rojo y azul.
2. Asegúrate de que la conexión Bluetooth® del dispositivo está activada y selecciona "iFROGZ Charisma". Completa cualquier otro paso adicional de conexión dependiendo del dispositivo que tengas. El LED parpadeará en color azul cada cinco segundos mientras los auriculares están encendidos y conectados.
3. Para apagar los auriculares, mantén pulsado el botón de Encendido durante tres segundos. El LED parpadeará en color rojo hasta que se apaguen.
4. La próxima vez que enciendas los auriculares se conectarán automáticamente a tu dispositivo.

4 Carga

Para cargar los auriculares, conecta el extremo micro USB del cable de carga al puerto del extremo del hub inalámbrico y el extremo USB a la toma USB que prefieras. El LED se iluminará en color rojo mientras se cargan y se apagará cuando estén cargados completamente.

the 1990s, the number of publications on the topic has increased steadily (see Figure 1).

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.

There are a number of reasons for the increase in research on the topic. First, the number of people who are affected by the disease has increased. Second, the disease has become a major public health problem in many countries. Third, the disease has become a major cause of death and disability in many countries.