ZTE BLADE A110 Quick Start Guide

LEGAL INFORMATION

Copyright © 2016 ZTE CORPORATION.

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

Trademarks

ZTE and the ZTE logos are trademarks of ZTE Corporation.

Google and Android are trademarks of Google, Inc.

The *Bluetooth*[®] trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license.



microSDHC Logo is a trademark of SD-3C, LLC.

Other trademarks and trade names are the property of their respective owners.

We offer self-service for our smart terminal device users. Please visit the ZTE official website (at www.ztedevice.com) for more information on self-service and supported product models. Information on the website takes precedence.

Visit http://www.ztedevice.com to download the user manual. Just click **Service Support>user's manual** from the home page and then select your location, product type, and name to search for related support information.


Disclaimer


ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software.

Version No.: R1.0

Edition Time: 2016.1

Getting to Know Your Phone





Power Key

- Press and hold to power on, select phone modes, turn on/off airplane mode, restart, or power off.
- Press to wake up your phone.

Home Key

- Touch to return to the Home Screen from any application or screen.
- · Hold to see Google search.

Menu Key

Touch and hold to see recently used applications.

Back Key

Touch to go to the previous screen.

Volume Key

Press or hold to turn the volume up or down.


Starting Up

Switch off your phone before installing or replacing the battery or the SIM card. The microSDHC $^{\text{TM}}$ card is optional and can be installed and removed while the phone is turned on. Unmount the microSDHC card before removing it.


1. Place your finger in the slot at the bottom of the back cover to lift and remove the cover.



2. Hold the SIM card with its cut corner oriented as shown and slip it into the card holder.



3. Hold your microSDHC card with the metal contacts facing down and slide it into the microSDHC card slot.



4. Align the connectors on the phone and the battery and slide the battery into the compartment. Then gently press the battery down until it is secured.



5. Align the back cover with the back of the phone and press the cover back into place. Make sure all the tabs are secure and there are no gaps around the cover.

Charging the Battery

 Connect the adapter to the charging jack. Ensure that the adapter is inserted with the correct orientation. Do not force the connector into the charging jack.



- 2. Connect the charger to a standard AC power outlet.
- 3. Disconnect the charger when the battery is fully charged.

Powering On/Off Your Phone

Make sure the battery is charged before powering on.

• Press and hold the **Power Key** to turn on your phone.

 To turn it off, press and hold the Power Key to open the options menu. Touch Power off.

Product Safety Information

	Do not use hand-held while driving	A	Do not use while re-fuelling
	For body-worn operation maintain a separation of 10 mm		This device may produce a bright or flashing light
	Small parts may cause a choking hazard	*	Do not dispose of it in a fire
	This device may produce a loud sound	P	To prevent possible hearing damage, do not listen at high volume levels for long periods.
Ė	Avoid contact with magnetic media		Avoid Extreme Temperatures

A	Keep away from pacemakers and other personal medical devices		Avoid any contact with liquid, keep it dry
4	Switch off when instructed in hospitals and medical facilities		Do not attempt to disassemble
4	Switch off when instructed in aircrafts and airports	⊕ ×	Only use approved accessories
*	Switch off in explosive environments		Do not rely on this device for emergency communications

§ 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

Body Operation

This device was tested for typical body support operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the device, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body accessories that do not meet these

requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.