

**ZTE CORPO**

ZTE A37

GSM Dual-ba

User Manual

Copyright © 2006 by ZTE

All rights reserved.

No part of this publication  
any form or by any means,  
microfilm, without the prior writ

ZTE operates a policy of  
the technical specifications in t

Edition: 1<sup>st</sup> edition, May., 2006

SW Edition: P103B2SWDV1.0.

## **1 GENERAL INFO**

- 1.1 WELCOME .....
- 1.2 SECURITY .....
- 1.3 SAFETY PRECA

## **2 GETTING START**

- 2.1 KEY DEFINITIO
- 2.2 DISPLAY SYME
- 2.3 TECHNICAL PA
- 2.4 BATTERY .....

*2.4.1 Removing*

*2.4.2 Charging*

2.5

2.5.1 *SIM Card.*

2.5.2 *Inserting &*

2.5.3 *Power on/o*

2.5.4 *Unlocking*

2.5.5 *Connecting*

### **3 BASIC OPERATIO**

3.1 MAKING A CALL

3.2 ANSWERING A C

3.3 CALL MENU .....

### **4 FUNCTION MENU**

4.1 USAGE AND STR

4.2 PHONE MENUS.

4.2.1 *Call Histor*

4.2.2 *Call Di*

4.2.3	<i>Call Fire</i>
4.2.4	<i>Call Setti</i>
4.3	PROFILES .....
4.4	MY FAVORITES
4.5	SETTINGS .....
4.5.1	<i>Phone Se</i>
4.5.2	<i>Clock Set</i>
4.5.3	<i>Display S</i>
4.5.4	<i>Security S</i>
4.5.5	<i>Fact. Sett</i>
4.6	MESSAGES .....
4.6.1	<i>Messages</i>
4.6.2	<i>MMS.....</i>
4.7	CAMERA .....
4.8	TOOLKIT .....

4.8.2	<i>Full-screen</i>
4.8.3	<i>Calculator</i>
4.8.4	<i>Stopwatch</i>
4.8.5	<i>World Clock</i>
4.8.6	<i>Games.....</i>
4.9	WAP .....
4.10	STK (SIM TOOL)
4.11	NAMES.....
4.11.1	<i>Adding Ne</i>
4.11.2	<i>Searching.</i>
4.11.3	<i>Editing.....</i>
4.11.4	<i>Deleting...</i>
4.11.5	<i>Making an</i>
4.11.6	<i>Detail.....</i>
4.11.7	<i>Add New N</i>

4.11.9 *Settings...*

4.11.10 *Batch Op*

4.11.11 *Adding to*

## **5 TEXT INPUT .....**

5.1 OVERVIEW .....

5.2 ABC AND ABC

5.3 123 MODE .....

5.4 PREDICTIVE TE

5.5 CHARACTER C

## **6 TROUBLESHOO**





## 1.1 Welcome

Thank you for using ZTE A37

To guarantee the mobile phone  
carefully and keep it for further

The pictures, symbols and color  
not be completely identical with

## 1.2 Security

- If your mobile phone is lost or stolen, please contact the relevant agencies to ban the use of the phone. Any financial losses resulted from unauthorized use of the phone will not be covered by the manufacturer.
- To protect your mobile phone, please do not use the phone in the following situations:

- Set PIN code of the SIM card
- Set handset lock code
- Take it with you as you travel

### **1.3 Safety Precautions**

This section includes some important information that you should read this information before using the phone.

#### **Operational Precautions**

- Please use your phone properly. Do not use the phone as holding a wireless device (within 20 centimeters) from your body.
- Do not touch the antenna. This may affect call quality and may require a restart of the phone if needed.
- Keep the phone out of the reach of children. Do not use as a toy.

### **Precautions While Driving**

- Please pay attention to the location of your phone in the area of the driver's seat.
- Pull off the road and park before using your phone.

### **Precautions for Medical Devices**

- When using your phone, keep it at least 8 inches (20 centimeters) away from your body. Do not carry the phone in your pocket or purse to minimize the potential for interference, if necessary. If you are using a mobile phone, it is necessary to use speakerphone or a headset when driving, if necessary.
- Some phones may interfere with medical devices. If you experience interference, you may want to use alternative methods of communication.
- If you use any other personal electronic device, consult your device to determine if it may interfere with your medical device.

please pay attention to the  
phone if required.

### **Mobile phone**

- Please use original accessories from the manufacturer. Using any other accessories may affect the performance, hurt your hearing, and may not meet related national regulations.
- Turn off your phone before charging. Do not use a charger with a chemical or abrasive cleaning agent.
- As your mobile phone contains a battery, it should be kept away from magnetic items such as credit cards.
- Using the phone near a television or personal computer can cause interference.
- Do not expose your mobile phone to

- Prevent liquid from leaking into the phone.
- Do not drop, knock or hit the phone or its internal circuit boards.
- Do not connect the phone to a power source.
- Do not attempt to disassemble the phone.
- Do not store the phone in a hot or cold environment.
- Do not charge the mobile phone while it is in use.

#### **Precautions for Potentially Explosive Environments**

- Switch off your phone in potentially explosive atmospheres, such as fuel stations, gas stations, and around flammable liquids.
- Do not remove, install, or use the phone in a potentially explosive atmosphere. Failure to do so could result in injury or even death.
- To avoid possible interference with other electronic equipment, you are near electrical equipment, or you are in a potentially explosive atmosphere, do not use the phone.

### **Precautions for Electronic Devices**

- Some electronic devices, such as mobile phone, may be affected by wireless transmission if inadequate precautions are taken. Please consult the manual for details.

### **Safety and General Use in Vehicles**

- Safety airbag, brake, speed sensor, etc. may be affected by wireless transmission. Please refer to your automobile provider's manual for details. The airbag deployment and the airbag deployment are not guaranteed with great force and cause injury.
- Please turn off your mobile phone when driving in areas where the use of 2-way mobile phones is prohibited.

### **Aircraft Safety**

- Please turn off your mobile phone when on an aircraft.

mobile phone when it is in use. You should get aircrew's permission before using a mobile phone when it is in use.

- If the mobile phone has a low battery, set your alarm setting to ensure you are alerted during flight.

### **Battery use**

- Do not short-circuit the battery.
- Do not store battery in a fireproof container or explosion.
- Do not disassemble or damage the battery, or cause overheating, explosion or fire.
- Please store the battery in a fireproof container.
- The battery can be recharged. When the operating time is short, it is time to replace the battery.

evidence of aging.

- Return the wear-out bat  
environment regulations.

### Exposure to radio frequency

#### Radio wave exposure and Spe

- The handset is designed  
waves. This requirement  
margins designed to ass
- The radio wave exposure  
Specific Absorption Ra  
standardized method with  
in all used frequency ban
- While there may be diff  
models, they are all desi  
waves.
- The SAR limit recommen
- The highest SAR value fo  
is 1.492 W/kg(1g)
- The highest SAR value fo



- [SAR compliance for battery](#)  
[similar accessories that](#)  
[provide at least 1.5 cm](#)  
[the users body](#)

**Warning:** If the battery is damaged, do not touch it. If it comes into contact with the eyes or skin, wash immediately with water and seek medical attention from a doctor.

## 2.1 Key Definition



**Left Soft key**

Execute functions of the in



**Right Soft key**

Execute functions of the in



**Dial key**

Make and answer calls. Br



**End key**

Finish or refuse a call. Pow



### Up/Down/ Left/Right key

**Up/Down key:** Roll the page up/down when editing. They can be used as direction keys in games.


**Left/Right key:** Roll the page left/right. They can be used as shortcut keys in standby mode.

**OK key:** The middle key. Used for selection operation.



### 0~9 Number key

Enter numbers and characters. They could be set as direction keys in standby mode.




### \* key and # key

**Note:** In this manual **press** means you press a key once and **holding a key** means you hold down a key for a few seconds.


## 2.2 Display Symbols

  Signal strength

  New message; No


  Bar all calls

  Bar black list

  Only friends' call

  Indicate battery level


  Activate call diversion

  Enable mute mode

  Keypad is locked

  Indicates the phone is in airplane mode

  GPRS online

  Roaming

## 2.3 Technical Parameters

### Handset

Type

Dimensions  W×L×H

Weight

### Battery

Continuous standby time

Continuous talk time

For other parameters about

## 2.4 Battery

unpacking. A new battery pack should be inserted and recharged three times.

#### **2.4.1 Removing & Installing the Battery Pack**

- Remove: Push down the battery release button on the bottom of the battery pack and then lift the battery pack out of the device.
- Install: Place the bottom of the battery pack into the battery compartment of the device until it clicks into place.










## 2.4.2 Charging the Battery

- Connect the handset and the charger (with arrow.) Then plug the charger into the power outlet.
- A charge indicator icon  on the battery is charged in the animation.
- When the battery level indicator shows 100%, it means charge has been completed. At the stop of charge animation, the whole charge process needs to be repeated for the first three times. After that, the charger may become hot.
- Please disconnect the charger when the battery is fully charged.



**Warning:**

- Please put the phone  
40□. Please use cha

- Please charge the battery fully before use. When the battery is low, the phone displays a warning “Low Battery”.
- The phone’s talking time is limited by the signal strength of the network in the environments. In practice, the talking time is shorter in weak signal environments, work environments, and indoor environments.

## **2.5 Connecting to the Network**

### **2.5.1 SIM Card**

Please insert a valid SIM card into the phone. The SIM card is used by any GSM mobile phone. Don’t touch the metal surface of the SIM card. The SIM card can be lost or destroyed. Keep it safe.

**Warning:** Please power off the phone before removing the SIM card. Removing the SIM card while the phone is powered on may damage the SIM card.

### **2.5.2 Inserting & Removing the SIM Card**

battery.

- Pull the SIM card cover out of the battery compartment.
- Put SIM card into the cover.
- Insert the SIM card cover into the battery compartment.





### 2.5.3 Power on/off Your Phone

Hold **End key** to power on/off the phone.

The mobile phone will automatically power on.

If the PIN code is not valid after power on, then the phone will display the following screen:

**Enter PIN Code** ——if SIM card is not locked.

**Enter lock Code**——if handset is locked.

**Searching** ——search for network.

### 2.5.4 Unlocking the SIM Card

By setting PIN (personal identification number) or PIN2 (personal identification code), you can protect your SIM card.

By default, the SIM card is locked with PIN1.

- Method to unlock the SIM card:  
Press **End key** to power on the phone, then press **Soft key** [OK].

If you enter an incorrect PIN1, the phone will display the following screen:

The phone will be disconnected from the network and the phone will display the following screen:

Method to unlock the SIM card:



SIM card; please change

- Method to unlock the  
or Left soft key [OK].

**Note:** If you forget your h  
authorized local custome

### **2.5.5 Connecting to t**

After the SIM card and the  
search for the network.

After a few seconds, the han  
standby mode. Besides rec

- Press Right Soft key
- Press Left Soft key o

**Note:** If “Insert SIM card  
calls.

### **3.1 Making a Call**

You can make or answer calls. The call control icons in the top right corner of the screen show the status of the phone.

- Making DDD: Enter telephone number, then press the **Make** key to make a long distance call. Press the **End** key to end the call.
- Dialing extension number: Press the **Ext** key to dial an extension number.

Method 1: Dial the telephone number, then press the **Ext** key.

Method 2: Enter the telephone number, then press the **Ext** key, then enter the extension number, and press the **Ext** key. The extension number is dialed automatically after the telephone number.

**Area code**    **Exchange**

- Making IDD: Hold \* key, then dial the preset symbol of an international phone number and then dial the phone number and then dial the phone number.
- Dialing the number in the phonebook: Press the Phonebook icon, then press the number saved in a list of the phonebook. Press the Phonebook icon, then press the Calls and Missed Calls icon, then press the number view all the call logs. When you press the number, you can view all the call logs. You can check the list by pressing the number.
  - View **All calls** by pressing the number.
  - View full screen **Call** by pressing the number.
  - View **Names** by pressing the number.
  - All the numbers in the phonebook.

**Note:** Up/Down/Left/Right

**Settings-Fastkey Settings.**

## 3.2 Answering a Call

If **Anykey Answer** is active, you can press any key (any key) to answer a call in call waiting mode.

## 3.3 Call Menu

When in in-call mode, you can use the following methods to manage the call. The methods are the same as those in the process of communication. Multiparty need network to support. Contact your network service provider.

If you couldn't answer the call, you can do the following operations:

- Hold/ Retrieve: Keep the call on hold and retrieve it later.
- Names: Display information about the caller.
- Earpiece Volume: Adjust the volume of the earpiece.

- DTMF On/Off  Enable

- **Multiparty**

- **Answer:** Hang on the line.

- **Join All Calls:** Add all calls to the current call.

- **Hold All Calls:** Hang up all other calls.

- **Private:** Converse with one party while others are on hold.

- **Exclude:** Keep one party on hold while others are on hold.

- **Busy:** Send busy tone to all other parties.

- **End All Calls:** End all calls.

**Note:** Some menu items may not be available.

**Swap** will appear only when two parties are on the same time.

## **4.1 Usage and Structure**

- Scrolling search function  
key in standby
- In function menu, you can  
Right Soft key according

## **4.2 Phone Menus**

In standby mode, press  
access the PhoneMenus interface

#### 4.2.1 Call History

- View calls list

Select **All Calls** to view a

Select **Missed Calls** to v

Select **Received Calls** to

Select **Dialled Calls** to v

In the calls list interface,

to delete all call records

detailed submenus:

- Send Message: Send messages to a contact as creating messages.
- IP Dial: Dial an IP call. An IP address number has been set before.
- Detail: View the detail of a contact.
- Save Number: Save the contact's number.
- Add to Blacklist: Add the contact to the blacklist.
- Call Duration: You can view the approximate total duration of all calls. You can clear all call duration records.
- All Calls Info: View all call information.
- Cost Setting: In the menu, you can set the **Cost** to read or set the limit.

**Note:** This function needs



SIM card, all numbers in

#### **4.2.2 Call Diverting**

This service enables yo

Please contact your serv

##### ■ Set Diverts: Set diverts

➤ All Calls: Divert all c

➤ When Busy: Divert c

➤ No Answer: Divert c

➤ Unreachable: Divert

network.

When you have set com

chosen:

➤ On: Only registered

➤ Off: Delete the diver

➤ Status Check: Que

After choosing one of the a  
the following options, you

- All Services:
- Voice Calls: C
- Data: Only di
- Fax: Only div
- Messages: O
- All Except Ms

➤ Cancel All

Enter the divert interface,  
services.

### **4.2.3 Call Firewall**

#### **4.2.3.1 Incoming Calls**

- Current Settings: Press S

- Black List: Press **Select**
  - If you have not added any contacts to the Black List, press **Option-Add** to add the contacts.
  - If you have added some contacts to the Black List, press **Option-Add** to select such options: **Black List**.
- Friend List: Press **Select**
  - If you have not added any contacts to the Friend List, press **Option-Add** to add the contacts.
  - If you have added some contacts to the Friend List, press **Option-Add** to select such options: **Friend List**.

#### 4.2.3.2 Outgoing Calls

Before entering the function, the phone password is 1234.

- Current Settings:

- Bar All: Bar all outgoing calls
- Bar in List: Bar all numbers in the barred list, or any number in the barred list
- Cancel All: Cancel the call
- Barred List: Directly enter the number to be barred. Press **All**. If you have not added any numbers to the barred list, press **All** to select **Add**, and then press the number to be barred.

#### 4.2.4 Call Settings

- Anykey Answer: If **On**, the phone will answer any key except End key, and Right key.
- Minute Minder: Choose the number of minutes to ring before the phone answers a call. The phone will ring for the number of minutes when answering the call.
- Connected Minder: Select the number of minutes to ring before the phone answers a call. The phone will ring for the number of minutes when answering the call.
- DTMF Tones: Select **On** to enable DTMF tones.
- Call Waiting: Select **On** to enable call waiting.

the current status of this  
call if a third person o  
provider for detailed us

- IP Settings: You can se  
the Names or the calls  
the phone number that

### **4.3 Profiles**

In standby mode, press F  
profiles interface.

- Select Profile: You can select different profiles. The options are: Normal, Meeting, etc. You should select a profile before leaving factory. You can select a profile from the list.
- Edit Profile: Change the profile settings.
  - Alert Type: Select the alert type.
  - Ringing Tone: Many pre-defined tones are available.
  - Ringing Volume: Adjust the ringing volume.
  - Speaker Volume: Adjust the speaker volume.
  - Key Tone: Select to turn on/off the key tone.
  - Warn Tone: Select to turn on/off the warn tone.
  - Missed Alert: Select to turn on/off the missed alert call.
  - Message Alert: Select to turn on/off the message alert. You can select to turn off the alert.
  - Power on/off Ring: Select to turn on/off the power on/off ring.

## 4.4 My Favorites

In standby mode, press **Menu**

My Favorites interface.

- **Photos:** Press left soft camera.
- **Pictures:** Press left soft from a browser or from
- **Ringtones:** press left

Press Up/Down key to select  
the following submenu:

- Play: Play the selected message
- Set ringtone: Set the selected message as ringtone
- Information: View the attributes of the selected message
- Delete: Delete the selected message
- Delete All: Delete the all messages
- **Others:** press left soft key to view the messages sent or received from attachments
- **Space Usage:** check the space usage

## 4.5 Settings



setting interface.

#### **4.5.1 Phone Settings**

Select and enter the **Phone**

- Language: Select the language.
- Own Number: Edit/view own number.
- Fastkey Settings: Set the fastkey.  
key.
- Auto Lock Keypad  Switch keypad lock on/off automatically. If you select this option, the keypad will lock automatically when the screen is switched to standby. A keypad lock prompt on the interface will appear.

#### **4.5.2 Clock Settings**

You can set date and time.

Use Scroll key to switch

correctly inputting the date

### **4.5.3 Display Settings**

- Wallpaper: Select your favorite wallpaper.
- Contrast: Adjust the screen contrast.
- Brightness: Adjust the screen brightness.

### **4.5.4 Security Settings**

Security features protect your data.

**Note:** You need to input a handset lock code as soon as possible.

- PIN code: SIM password. Select **On/Off** to enable or disable. You can also set a new PIN code.

**Note:** Three consecutive failed attempts will lock the handset.

code may be provided to  
your network service pro  
soon as possible.

- Handset Lock: Handset L  
Select **On/Off** to enable  
to set a new handset loc

**Note:** The default hands

- Network Call Bar: You ca  
to improve security lev  
detailed use. The netwo  
enable your call restricti

- International Call: Ba
- All Except Home: Ba
- Incoming Calls: Bar
- Incoming if Abroad:

After choosing one of the a  
services:

- All Services: Restr
- Voice Calls: Only
- Data: Only restric
- Fax: Only restrict
- Messages: Only n
- All Except Msgs: n

When you have set types

- On: The restriction
- Off: Delete the res
- Status: Query if th

➤ **Cancel All:** Select Ca

**Note:** You need to input  
Three consecutive times

#### **4.5.5 Fact. Settings**

In this menu, you can s  
settings.

### **4.6 Messages**

If the network supports  
receive text short messa  
receive voicemail. Pleas  
In standby mode, press  
the message menu inter

---

#### **4.6.1 Messages**

- **New message**

Please confirm message  
messages.

- In message interface  
message input interface  
Input".)

- When you finish enter

select **Send to One, Send**

- Select **Save** to save the destination number according to the select number in the list of the opposite party's number and select number. Select **Save** numbers from the Name list prompt information on the screen.

**Note:** The SMS centers can support more than 70 Chinese characters.

■ **Inbox/Outbox**

- Select **Inbox** to check the messages saved in SIM card.
- In the message list, select the message to do the following operations:

- Forward: Transfer
- Voice Call: Call the

messages in the Inbox.)

- Send (The menu
- Extract Number.:

the screen. If you select or  
editing or dialing.

➤ Delete All: Delete all t

#### ■ Message Settings

You must set up necess

Access **Msg Settings** sub

➤ **Msg Centre:** Input th  
this number from your se

➤ Msg Validity: In the pe  
message till it is received



- Templates: When editing a message, press **Option-A** key. In this menu, you can edit the message template.
- Status Report: If the message is not delivered, it will inform you after the service is restored. This option needs the network to send the status report.
- Save Edit: Select when you want to save the edited message.
- Msg Firewall:
  - Current Settings: Select when you want to block all short messages, send messages from unknown numbers in the message, or block all incoming messages.
  - Msg Black List: Select when you want to add an empty number to the black list. Press **Option-A** to add an empty number. Press **Option-A** to delete a number. Press **OK** to save. If you want to access and then select a number, press **Option-A**.

Select and Access **Voice Mail**

➤ Select **Get Voice Mail** message.

➤ **Voice Mail Num.:** Set

■ Cell Information

➤ You can view

➤ Select **Setting**

#### 4.6.2 MMS

If your SIM card supports

■ New Message

Press **MMS-New Message**

following submenu:

➤ **Edit Text:** Select to e

Press left soft key [OK] to

enter the following subme

◆ **Done:** Press done to

- **Send later:** Save

next time you send the message

- **Subject:** Write a

- **To:** One or more

send the message

- **CC:** Phone number

copy of the message

Press **More** to check

- **BCC:** phone number

carbon copy of the message

other addresses)

- **Priority:** Set the

- **Lifetime:** Select

server while trying to de

- ◆ **Edit Text:** Go back to
- ◆ **Add Picture:** Select t
- ◆ **Add Sound:** Add a m
- ◆ **Delete Object:** Delete
- ◆ **Preview:** Select to pre

Press **More** to check the f

- ◆ **Add Page** □ Add a new
- ◆ **Object Properties:** D
- ◆ **Page Properties:**

- **Inbox**
- **Sent**
- **Outbox**
- **Drafts**
- **Templates**
- **Settings**

➤ **Read Reports:**

- **Send Report:** S
- **Request Report**

message.

➤ **Deliver Receipts**

- **Send Receipt:** S
- **Request Receipt**

MMS.

➤ **Lifetime:** Set the ma

➤ **Advanced:**

- **Message Cente**
- **WAP Profile:** S
- **MMS Download**

or download MMS after

- **Span Filter:** Set

## 4.7 Camera

The phone has a built-in camera.

In standby mode, press **Menu** to access the camera interface.

The following icons appear on



Brightness



Zoom



Frame

key to adjust its parameter

- Frame: Press Left/Right key to adjust its parameter. Press Up/Down key to adjust its parameter.
- Face: Press Left/Right key to adjust its parameter. Press Up/Down key to adjust its parameter.
- Large: Press Up/Down key to adjust its parameter.
- Multiply Normal/Multiply Large: Press Up/Down key to select its parameter.
- Press OK key to catch the parameter. Press Left soft key [back] or press Right soft key [back]

## 4.8 Toolkit

In standby mode, press **Menu** key to enter the Toolkit interface.

#### 4.8.1 Alarm Clock

Your phone can set up to

- Set Alarm: Select **Set Al**  
to instructions: alarm typ  
ring tone.

The alarm clock is valid only wh  
will powered on automatically

automatically if you select "no



- List Alarms: Select **List** in the alarm clocks settings. Press **C** to view the alarm clock settings. Press **C** to enable/disable it.
- Define Rest Day: Select **Rest Day**. Workday alarm will not ring on the Rest Day. Then press **Select/Cancel**.
- Clear All: Select **Clear All**.

#### **4.8.2 Full-screen Calendar**

Use **Scroll** key to select the date from January 1, 1901 to December 31, 2050.

#### **4.8.3 Calculator**

- Press 0~9 Number key.
- Press Up/Down/Left/Right key.

calculator. Press Left soft

**Note:** This calculator has 1  
in long division.

#### **4.8.4 Stopwatch**

You can measure time and take

- Press **OK key** to start time
- Press **OK key** to stop the
- Press **Left soft key** or **O**

#### **4.8.5 World Clock**

The world Clock function provid

- You can view the time of  
navigation screen of Wor
- Press **Left soft key [Sav**
- Press **End key** to quit.

#### **4.8.6 Games**

- Tetris: The options are
  - New Game: Start a new game
  - Set Lines: Select the number of lines to clear
  - Help: Check the rules
- Push Box: The options are
  - New Game: Start a new game
  - Load Game: Read the saved game
  - Help: Check the rules

#### **4.9 WAP**

- **Home:** Press to go into the home screen
- **Resume:** Press to enter the resume screen

up/down key to choose the  
address and delete.

- **Empty Temp.:** Delete the
- **Enter address:** Input the  
page.
- **Settings:**

- **Connection Settings**

edit, change name or delete

Press edit to enter the

- **Homepage:** Edit
- **Image Settings:**
- **Connection Type**
- **Connection Opti**
- **Gateway Setting**
- **Bearer:** Set Data

- **Security Cert.:** Press
- **Push Security:** Sel
- **Push Messages:** Ente  
the information, load th
- **GPRS Info:** Press to ch
- **Fastkey operation:** in  
And then press **OK key**
- **Stop:** Stop web brow
- **Go back:** Move to th
- **Bookmarks:** Press
- **Add bookmark:** Ad
- **Enter address:** Ent
- **Home:** Move to the
- **Top:** Move to the top
- **Refresh:** Refresh th

page. Select to enter the image  
it.

#### **4.10 STK (SIM Tool)**

In standby mode, press **Me**  
interface.

This service needs the ne  
the network service provid  
For more information, plea

#### **4.11 Names**

In standby mode, access t  
It shows **List empty** when  
pressing Left Soft key. Sav  
the first character of the n

- In the names list interface, the following options are available:  
options are as follows:

- Search
- Edit
- Delete
- IP Dial
- Detail
- Add New Name
- Settings
- Batch Operation

- In the names list interface, the following options are available:  
soft key [**Option**] to access:

- Send Message
- Edit
- Delete

- Add to Speed
- Copy to MS
- Move to MS
- Add to Blacklist
- Add to Friendlist

■ Press Left/Right key to switch

be seen. Press End key to

Whether saved in SIM card

number. Number types co

Office, Fax or Pager.

Records saved in the SIM

doesn't appoint the record

Besides, there are six gro

Society and VIP.



#### 4.11.1 Adding New Name

In the names list interface  
to save new number into

If **SIM Card** is selected

- Enter the name of the number.
- Enter the phone number.

If **Phone Memory** is selected

- Press OK key, enter the name.
- Select the group.
- Enter the phone number.
- Select Caller Icon.

If the name is saved into the list,  
at least the name and phone number  
chosen, the default is memory.  
group is the current group.

#### **4.11.2 Searching**

- In the names list interface, you can search for a name that you want to search.
- Quick-search: In the Name record interface, you can search for a record of the name with a search term.
- Sort principle: Sort by ASCII.
- Match principle: If match, then show.

#### **4.11.3 Editing**

In the names list interface, you can edit a name record.

#### **4.11.4 Deleting**

In the names list interface, you can delete a name record. The information of the current name record is shown in the interface.

#### **4.11.5 Making an IP Call**

In the names list interface, press the **Call** button to the current chosen number.

#### **4.11.6 Detail**

In the names list interface, press the **Detail** button in the interface. You can press

#### **4.11.7 Add New Name**

Add a new record.

#### **4.11.8 Sending Messages**

In the names list interface, press the **Message** button in the interface of editing number to create or editing number to creating messages.

#### **4.11.9 Settings**

- Ringing Tone: You can se
- Save Nos. to: You can se
- Used Space: You can vie  
records in SIM card and
- Copy/Move to MEM/SIM  
or SIM card. When copy  
destination space is full.
- Speed Dial List: List the s

#### **4.11.10 Batch Operation**

This function provides you to ba  
card or phone memory. Note:

Please be careful to use this fu

#### **4.11.11 Adding to Speed**

Dial List. You can set at  
standby mode, if you ho  
automatically. Press **Del**

## 5.1 Overview

Your mobile phone provides the numeric input and predictive text input. When you are in a field that allows numeric input, a numeric mode indicator in the upper right corner of the field indicates different input modes.

## 5.2 ABC and abc modes

- Use the number key from the numeric keypad to enter a digit.
- Press the key labeled with the letters you want to enter.
  - Once for the first letter

- And so on

- To insert a space, press the space key on the display.
- Press \* key to open a list of words, and press Ok key to select a word.

### **5.3 123 mode**

- The 123 mode enables you to enter numbers with a few key strokes.
- Press the keys corresponding to the numbers you want to enter.

### **5.4 Predictive text**

You can enter any letter with a few key strokes using the predictive text dictionary.

- To write the desired word, press the key corresponding to the first letter for one letter. For example, to write the word "K", press the key corresponding to the letter "K".

word is not correct, press  
found.

## 5.5 Character Cha

Refer to the table below for mo

key	
1	1
2	Al
3	D
4	G
5	Jk
6	M
7	P
8	TU
9	W



* key	
# key	
Up/Down key	
Left/Right key	
End key	

## 6

Check the following references for more information. Contact your distributor if you cannot find the information.

1. “Enter PIN code” is shown on the screen.  
Input the PIN or input the default PIN.  
Set “off” if you do not want to use a PIN.
2. “Insert SIM” is shown on the screen.  
Turn off your phone and insert the SIM card.
3. “Unlock” is shown on the screen.  
Press Unlock and then enter the PIN.
4. No key tone volume.  
Check the keypad setting in the Settings app.
5. No incoming ring tone.  
Check the ringing tone and volume in the Settings app.

6. No alarm tone wh

Check the profile setting

7. A phone number

Check whether call restri

8. A phone call canr

Check whether call restri

9. Short message c

Check the Msg centre se

10. Some menus rela

Check the profile settings