

105(H) x 297(W) mm



ORIGIN

WIRELESS STEREO EARBUDS
WITH MICROPHONE AND VOLUME CONTROL

USER MANUAL

Thank you for purchasing the Origin Wireless stereo Earbuds with microphone and volume control. This manual provides more information about the wireless earbuds, please read the instructions before using.

Earbuds Overview



Power On/Off

- ◆ **Power on**
Press and hold down the On/Off Button for 3 seconds and the blue LED will turn on.
- ◆ **Power off**
Press and hold down the On/Off Button for 4 seconds and the blue LED will turn off.

Pair Origin Wireless Stereo Earbuds with your mobile device

1. Keep the distance between your wireless earbuds and mobile phone (or other devices) within 3.28 Feet.
2. Power on the Origin Wireless Stereo Earbuds
3. Activate the Bluetooth function on your phone within range and select "EP-0349-Origin earbuds" from the list shown.
4. The LED blinks in blue when paired successfully.

- ◆ Attention: If the pairing is not successful within 2 minutes, the earbuds will power off, please repeat the pairing procedures to try again.

Reconnect Origin Wireless Stereo Earbuds to your mobile device

- ◆ When powered on, the earbuds will automatically connect with the last successfully paired device.

Disconnect the earbuds from your mobile device

- ◆ Power off the earbuds; or
- ◆ Switch off the Bluetooth on your mobile phone; or
- ◆ Leave the earbuds 60ft away from your mobile phone or further.

Answer a call

- ◆ When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone.

End a call

- ◆ Press the On/Off Button once to end the call or hang up your mobile phone.

Technical specification

Bluetooth version: - - - - - 3.0
 Supported profiles: - - - - - A2DP, AVRCP, HSP, HFP
 Transmission frequency range: - - - - - 2.4GHz-2.48GHz
 Bluetooth operating range: - - - - - 3.28 Feet
 Frequency response: - - - - - 20Hz-20KHz
 Bluetooth talk time: - - - - - 1.5-2hrs
 Bluetooth music time: - - - - - 2-2.5hrs
 Standby time: - - - - - 60hrs
 Fully charged time: - - - - - 1.5hrs

FAQ

- ◆ **If the Origin Wireless Stereo Earbuds cannot be paired with your device, please try the following:**
Ensure that your earbuds are in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated.
- ◆ **If the Origin Wireless Stereo Earbuds will not turn on:**
Make sure the earbuds are fully charged.
- ◆ **Can I change the battery for the earbuds?**
Origin Wireless Stereo Earbuds use a built-in non-detachable battery which cannot be removed.
- ◆ **If the Origin Wireless Stereo Earbud cannot be recharged:**
If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference.
 (2) This device must accept any interference received, including interference that may cause undesired operation.
 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ADM5-EP0349EP0350

Distributed By: Five Below Merchandising, Inc.
 1818 Market Street, Suite 2000
 Philadelphia, PA 19103
Keep All Relevant information for Future Reference