













ET-0740 Gudetama Remote Control Egg Vehicle Instruction Manual
 Size : 420 x 110 mm

03 MAY 2023

<p>8+ ages</p> <p>gudetama™ the lazy egg remote control egg vehicle</p> <p>Instruction Manual</p> <p>Thank you for purchasing the Remote Control Egg Vehicle. This manual provides more information about this Remote Control Egg Vehicle, please read the instructions before using.</p> 	<p>Product Overview</p>  <p>Remote Controller Egg Vehicle</p>  <p>Remote Controller</p>  <p>Instruction Manual</p>	<p>Package Contents</p> <p>Includes: 1(One) x Remote Control Egg Vehicle 6.6in. x 6.1in. x 6.1in. (16.7cm x 15.5cm x 15.5cm), 1(One) x Remote Control 8.27in. x 2.2in. x 1.3in. (21cm x 5.6cm x 3.4cm), 1(One) x Instruction Manual</p> <p>Specifications</p> <p>Remote Control Egg Vehicle Requires: 3(Three) X AA 1.5V Alkaline Batteries (Not Included)</p> <p>Remote Control Requires: 2(Two) X AAA 1.5V Alkaline Batteries (Not Included)</p> <p>Remote Controller</p>  <p>Forward Button Backward-Right Button</p>	<p>Standard Control</p> <p>Note: To avoid losing control, always pay attention when controlling the Remote Control Egg Vehicle.</p>  <p>Forward Button Control Remote Control Egg Vehicle to move forward</p>  <p>Backward-Right Button Control Remote Control Egg Vehicle to move backward-right</p>	<p>Power On/Off</p>  <p>Power On / Off</p> <p>Power On/Off Slide the ON/OFF Switch to ON to turn on the Remote Control Egg Vehicle. Slide the ON/OFF Switch to OFF to turn off the Remote Control Egg Vehicle.</p>	<p>Batteries Installation For Remote Control Egg Vehicle</p>  <p>To install batteries into the Remote Control Egg Vehicle, unclose the cover on the battery box cover to open the cover. Insert 3(AA) Alkaline Batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the screw.</p> <p>Notice: When inserting the batteries, you must insert according to the correct polarity. The Remote Control Egg Vehicle won't function if batteries are inserted.</p>
<p>Batteries Installation For Remote Controller</p>  <p>To install batteries into the Remote Controller, unclose the cover on the battery box cover to open the cover. Insert 2(AAA) Alkaline Batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the screw.</p> <p>Notice: When inserting the batteries, you must insert according to the correct polarity. The Remote Controller won't function if batteries are inserted.</p>	<p>Performance Tips</p> <ol style="list-style-type: none"> Do not drive the Remote Control Egg Vehicle on grass, sand or go through water. Do not drive the Remote Control Egg Vehicle in windy or rainy weather. Do not drive the Remote Control Egg Vehicle into any sharp object. Keep fingers, hair and loose clothing away from Remote Control Egg Vehicle. <p>Care and Maintenance</p> <p>Always use dry and soft cloth to clean this product. Avoid this product from being exposed to sunlight or heat. Avoid reinserting these toys in water; otherwise, the electrical parts may be damaged. Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired in good working condition.</p>	<p>IMPORTANT: BATTERY INFORMATION</p> <p>For AA Batteries</p> <p>WARNING TO AVOID BATTERY LEAKAGE 1) Do not use or insert the batteries until they are dry. 2) Follow the hygiene and safety manufacturer's instructions. 3) Do not mix old and new batteries or alkaline, standard (carbon zinc) or rechargeable (nickel cadmium) batteries. 4) Always remove leaks or dead batteries from the product. 5) Remove the battery if the product is left unused for a long period of time.</p> <p>For AAA Batteries</p> <p>WARNING TO AVOID BATTERY LEAKAGE 1) The batteries used with this product are small parts and should be kept away from small children who will put things in their mouths. If they are swallowed, promptly see a doctor and inform the doctor phone number/number of Poison Control Center (1-800-222-1222). 2) Always purchase the correct size and grade of battery must suitable for intended use. 3) Do not mix old and new batteries, alkaline, standard (carbon zinc) or rechargeable (nickel cadmium) batteries. 4) Clean the battery contacts and those of the device prior to battery installation. 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -). 6) Always remove batteries from source if product is to be left unused for a long time.</p>	<p>Warning</p> <p>This product is suitable to be used by people who has operating experience in remote toy or aged no less than 8 years old. Please do not put the product in your mouth to prevent choking hazard of small parts. Please do not put the finger into available intercompartments. Please do not use the product in a single way such as throwing, crushing or hitting it. Please store the unactivated product accessories in places that are out of reach of children in order to avoid the occurrence of accidents. Avoid placing the batteries in places in high temperature and avoid exposure to heat. When young children are operating the product, it shall be ensured that adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that makes the control of the toy more convenient. When the product is not in use, please switch off the power supplies of the toy and remove the batteries from the product. Please note that we won't take any responsibility for any wrong operation as this may result in severe injury or loss of property, and we cannot control the operating process during the time when the user assembles or uses the product. Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this product.</p>	<p>FCC Statement</p> <p>This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation. Certain changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or experienced radio/TV technician for help.</p> <p>FCC Warning statement The device has been designed to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>Remel ET-0740 FCC ID: 2ACZMS-ET-0740-07</p> <p>Keep All Relevant Information for Future Reference</p>	 <p>gudetama™ by Sawmio™</p> <p>© 2023 SANRIO CO., LTD. TM and ® denote U.S. Trademarks Used Under License. www.sanrio.com</p>  <p>SIL-35018 Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 2000 Philadelphia, PA 19106 MADE IN SHANTOU, CHINA</p> <p>Follow @gudetama on social media and @gudetamaweets on Twitter</p> 