


Size: 420 x 110 mm









Remote Control T-Rex Battery Charging Battery Installation For Remote Control T-Rex IMPORTANT: BATTERY INFORMATION

Make sure switch off the Remote Control Inflatable T-rex before charging.

Connect the Rechargeable Li-ion Battery to the charging cable and plug on a USB

The LED indicator on the charging cable will turn red while charging and will turn of

You must select a qualified charger from a regular manufacturer

Unscrew the screw on the battery box cover to open the cover.


Unplug and take out the rechargeable li-ion battery.



To install battery into the Remote Control Inflatable T-rex, unscrew the screw or the battery box cover to open the cover. Connect the rechargeable li-ion battery to the Remote Control Inflatable T-rex

Replace the battery box cover and tighten the screw.

Batteries Installation For Remote Control



To install batteries into the Remote Control, unscrew the screw on the battery box cover to open the cover.

Insert 3 x "AA" 1.5V batteries (Not Included) into the battery box.

Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the screw.

When inserting the batteries, you must insert according to the correct polarity. the Remote Control won't function if batteries are reversed

▲WARNING: DROWNING HAZARD This is not a life-saving Device. Do not use in water.

Li-ion battery charging warning statement

he input to the product is 5V 2A.
order to charge the product in safe manner and reliable conditions, olease only adopt certified appropriate charger/ adapter for charging the produ Only charge the product at ambient temperatures between 10 °C/ 50 °F and 40 °C/104 °F. Do not heat above 70 °C/158 °F, eg. Do not pose to sunlight or throw into fire. Please note that we won't take an expose to sullinglin to inflow lind line. Trease their lind we wint take any result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.

For AA Batteries

△ WARNING: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions.
- 2) Do not mix old and new batteries or alkaline, standard
- (carbon-zinc) or rechargeable (nickel-cadmium) batteries. 3) Always remove weak or dead batteries from the product.
- 4) Remove the battery if the product is left unused for a long period of time.

Charging Cable Rating 5V/2A Max.

▲ CAUTION: The charging cable included with this item is intended for use with this product. Only use the included charging cable to charge this product.

Performance Tips

 Do not drive the Remote Control Inflatable T-rex on grass, sand or go through water. 2. Do not drive the Remote Control Inflatable T-rex in windy or rainy weather.

3. Do not drive the Remote Control Inflatable T-rex into any sharp object. 4. Keep fingers, hair and loose clothing away from Remote Control Inflatable T-rex.

Care and Maintenance

Always use dry and soft cloth to clean this product.

Avoid this product from being exposed to sunlight or heat.

Avoid immersing these toys in water, otherwise, the electronic parts may be Check the product regularly. If any damages are discovered, please stop using

immediately, until it is completely repaired in good working condition.

Warning

This product is suitable to be used by people who has operating experience in remote toy or aged no less than 8 years old

Please do not put the product in your mouth to prevent choking hazard of small parts Please do not put the finger into available interspaces

Please do not play the product in a brutal way such as throwing, crashing or twisting it. Please store the smaller-sized product accessories in places that are out of reach of children, in order to avoid the occurrence of accidents.

Avoid placing the batteries in places in high temperatures and avoid exposure to hea When young children are operating the product, it shall be ensured that the adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that it makes the control of the toy more convenient. When the product is not in use, please switch off the power supplies of the toy, and remove the batteries from the product.

Please note that we won't take any responsibility for any wrong operation as this may result in severe injury or loss of property, and we cannot control the operating process during the time when the user assembles or uses this product.

Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The

- Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver

. Consult the dealer or experienced radio/ TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2ADM5-ET-0876



Distributed by 1616 Holdings Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106

Made In Shantou, China

Keep All Relevant Information for Future Reference

Item# ET-0876