Product: HP-0911 IM R2

SKU:

SIZE: 250mm x 172mm



BASS JAXX

# INSTRUCTION MANUAL



#### 1. Introduction **Table of Contents**

5 Product Specification · · · · 6

6 FAQ------ 6 7 FCC Statement ····· 7

Battery Statement ..... 8

1 Introduction       1         2 Packaging Contents       2         3 Connection Diagram       2         4 How To Use       3         4.1 General Function       3         4.2 Pairing To Mobile Phone       4	Congratulations, and thank you for choosing the Arena Wireless Headphones.  This manual will help you operate the Arena Wireless Headphones, but firstly you should familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using
4.3 Charging Your Headphones ···· 5	the Arena Wireless Headphones.

#### Safety Rules


- Please follow the rules depicted in this manual closely to ensure your safety.
  Before using this Bluetooth headphones. we would strongly encourage you to read through this user manual.
- 2 Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- 3 Do not modify, repair or dismantle this Bluetooth headphones. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth headphones, etc. All are not covered under warranty.
- Do not use an diluent or volatile liquid to clean the Bluetooth headphones.
- 5 Do not use the Bluetooth headphones in a

# 2. Packaging Contents



INCLUDES: 1(One) Pair of Wireless Headphones 6.7 in. x 6.9 in. x 3.4 in. (17 cm x 17.6 cm x 8.6 cm) 1(One) USB Type-C Charging Cable 10 in. (25 cm)

#### 3. Connection Diagram



1. On / Off Button 2. Volume Up / Next Sono

3. Volume Down / Previous Song Button 4. Play / Pause Button

# 4. How to use

#### 4.1.General Functions Required Action Desired Result

	! · · · · · · · · · · · · · · · · · · ·
Turn on & Enter the pairing mode	Press and hold the On / Off Button for 2 seconds. After turning on, the LED indicator flashes red/blue.
Pairing	Use a mobile phone with Bluetooth function or other Bluetooth devices to perform necessary pairing action. After pairing, the LED indicator slowly blinks with blue.
Turn off	Press and hold the On / Off Button for 3 seconds.
Charging	Plug the USB Type-C to the USB Type-C port. When charging, the LED indicator turns red. After full charging, the LED indicator turns off.
Answering a Call	Press Play / Pause button to answer phone call, press again to end call. Press and hold 2 seconds to reject call. Double click to redial last call.
Play / Pause Music	Press Play / Pause button to play music and press it again to pause music.
Previous / Next Song	Shot press Previous / Next Song button.
Volume Up /	Prace and hold Volume Lln / Down hutton

# 4.2. Pairing to Mobile phone or other device

To use your Bluetooth headphones, you must first pair your headphones with a mobile phone or other Bluetooth device. Once your Bluetooth headphones is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

# Pairing to a phone and Entertainment:

- Turn on your phone and ensure the Bluetooth function is activated.
- Turn on the headphones, enter the pairing mode.
- · Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information
- After a few seconds the phone will list the "BT ARENA HP" as a discover device. Select it and follow your phone's instructions to select this pairing.
- Your phone will confirm the pairing, and then press Yes/OK

# 4.3. Charging your headphones

⚠ For your safety, please always use an appropriate 5V input charger/Adapter to charge the product. DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product.

Use the USB Type-C charging cable accessory provided with this headphones. Connect the USB Type-C plug to the USB Type-C charging port on the headphones positioned in headphones diagram on page 2. Connect the USB plug to a USB port on a computer or wall adapter to activate

\*\*Make sure to keep the headphones charging for a minimum of 2 hours before initial use.



#### Warning:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth headphones if it has not been used for more than 6 months.

▲ CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

# 5. Product Specification

Driver Diameter: 40 mm Impedance: 32 Ohms Frequency Response: 20 Hz - 20 kHz Sensitivity: 100 dB +/- 3 dB

Power Supply: Li-ion Battery 3.7V 180 mAh Plaving Time: 3 - 4 Hours Charging Time: 2 Hours

Bluetooth Range: 32.8 Feet Bluetooth Version: 5.3

USB Type-C Charging Cable Included

#### 6. FAQ

- 1. Why is there no power even when the headphones is turned on ?
- Ans: Ensure the battery has been charged up to 2 hour for initial use
- 2. There is no sound when playback Ans: Check the connection between headphones with phone or computer, if the connection is not established, please connect again. Make sure the headphones is

paired and connected with your target phone or other

# 7. FCC Statement FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:

- Regrient or relocate the receiving antenna
- Increase the separation between the equipment and receiver - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

# RF warning statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

#### A Safety instructions for the lithium battery and charging the product

Press and hold Volume Up / Down button

ress the On / Off button once.

- -The input voltage to the product is 5V 1A
- -In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. -Only charge the product at ambient temperatures between 10 °C/50 °F
- Do not heat above 70 °C/158 °F,. Do not expose to sunlight or throw into fire. -Switch off the product after use
- -Please note that we won't take any responsibility for any wrong operation (e.g. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- -In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC ID: 2ADM5-HP-0911

ITEM# HP-0911

Down

LED On/Off

Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106

Made in China

Keep all relevant information for future reference

Approval: Date: