

# WOODEN WIRELESS SPEAKER

## Instruction Manual



SP-0272

FCC ID:2ADM5-SP0272

### Table of contents

1 Introduction	1
2 Packaging Contents	2
3 Connection Diagram	2
4 How to use	3
4.1 General function	3
4.2 Pairing to mobile phone	4
4.3 Charging your speaker	5
5 Product Specification	6
6 FAQ	7

### 1.Introduction


Congratulations, and thank you for choosing the Wooden Wireless Speaker. This manual will help you operate the Wooden Wireless Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Wooden Wireless Speaker.

#### Safety Rules


- 1 Please follow the rules depicted in this manual closely to ensure your safety. Before using this wireless speaker, we would strongly encourage you to read through this user manual.
- 2 Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- 3 Do not modify, repair or dismantle this wireless speaker. Doing so may result in fires, electric shocks, complete breakdown of this wireless speaker, etc. All of which, are not covered under warranty.
- 4 Do not use any diluents or volatile liquid to clean the wireless speaker.
- 5 Do not use the wireless speaker in a hazardous location.

1

### 2.Packaging Contents



### 3.Connection Diagram



2

### 4.How to use

#### 4.1.General Functions

Desired Result	Required Action
Turn on & Enter the pairing mode	Slide the  button to the right.
Pairing	You must use a Bluetooth function mobile phone or other Bluetooth devices to perform necessary pairing action.
Turn off	Slide the  button to the left.
Charging	Plug the Mini USB to the  port.

3

**4.2.Pairing to Mobile phone or other device**  
To use your wireless speaker, you must first pair your speaker with a phone or a computer. Once your wireless speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

#### Pairing to a phone and Entertainment:

- Turn on your phone and ensure its Bluetooth function is activated.
- Turn on the speaker go to the pairing mode.
- Search your Bluetooth device on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few second the phone will list the "MERCURY SPB97" as a discovered device. Select it and follow your phone instruction to select this pairing.
- Your phone will confirm the pairing, and then press Yes/OK.
- Finally, select to connect with wireless speaker from your phone.

4

**4.3.Charging your speaker**  
Use the Mini USB cable accessory provided with this speaker. Connect the Mini USB plug to the Mini USB charging port on the speaker positioned at in speaker diagram on page 2. Connect the USB plug to a USB port on a computer or wall adapter to activate charging.

**\*\*Make sure to keep the speaker charging for a minimum of 6 hours before initial use.**



**Warning:**

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth speaker if it has been not used for more than 12 months.

5

### 5. Product Specification

Parameter	Value
Driver Diameter	72mm*2
Impedance	4 Ohms
Bluetooth Version	4.1
Battery Capacity	Li-ion battery 1200 mAh
Battery Working Hours	3-4 Hours
Bluetooth Range	32.8 Feet



Rechargeable Li-ion Battery

6

### 6.FAQ

1. Why is there no power even when the Speaker is turned on?  
**Ans:** Ensure the battery has been charged up to 6 hours for initial use.
2. There is no sound when playback.  
**Ans:** Check the connection between speaker with phone or computer, if the connection is not established, please reconnect again. Make sure the speaker is paired and connected with your target phone or other master device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

8