VIVITAR

WIRELESS EARBUDS Instruction Manual





ITEM #: VZ40019BT

Introduction

Thank you for purchasing your Vivitar WL Earbuds with microphone and volume control VZ40019BT. You can use your earbuds with iPads, iPhones, iPods and many other types of smartphones and Bluetooth devices to stream music and enjoy hands-free calling. In order to get the best results when using this device, please read this manual first before using

Package Contents






VZ40019BT Bluetooth

Specifications

Bluetooth Version: 4.2 Supported Profiles: A2DP, AVRCP, HSP, HFP Transmission Frequency Range: 2.4GHz-2.48Ghz Bluetooth Range: Up to 32.8 feet (10 meters) Frequency Response: 20Hz-20KHz Bluetooth Talk Time: 1.5-2 Hours Bluetooth Music Time: 2-2.5 Hours Standby Time: 1.5 Hours Charge Time: Approximately 1.5 Hours Battery Type: 60 mAh, 3.7V Lithium-Ion Battery Driver Diameter: 10mm

A Quick Look at Your Device



LED indicator

Charging

Microphone

after a few charging-discharging cycles. Charge the battery fully before first use. To do so, follow the steps below: 1. Connect one end of the included Micro USB charging cable to the Micro USB charging port on your earbuds. Then plug the other end of the Micro USB charging cable

Your earbuds have a built-in, rechargeable lithium-ion

battery. To avoid damage, do not attempt to remove the

Charging Your Earbuds

NOTE: The internal battery of your earbuds takes approximately 1.5 hours to charge when completely drained. To maximize performance, it is recommended to charge the battery for six hours before initial use.

2. When the battery is charging, the LED indicator light will turn red. The LED indicator light will turn blue when the battery is fully charged. Unplug when charging is complete

NOTE: Overcharging could reduce the life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

To avoid a complete discharge of the battery, charge your earbuds at least once every six months

Pairing Your Earbuds

Your earbuds can be paired with most Bluetooth devices including iPads, iPhones, iPod Touch, and most smartphones, laptops and tablets. In order to pair your earbuds with a phone, follow the steps below:

- 1. Power on the Vivitar WL Earbuds, press and hold multi-function button for 3 seconds, the LED indicator light on your earbuds will flash blue to turn on pairing mode. When the light flashes red and blue, this indicates that your earbuds are successfully in pairing mode and bluetooth devices can now be searched
- 2. Go to the Bluetooth Manager of your Bluetooth device.
- 3. Search Bluetooth devices and select "VIVITAR WL FARBUDS" to start connecting
- Enter "0000" if your device asks for the PIN code.
- 5. Once paired, the mobile device will indicate if pairing has

Note: If the earbuds do not automatically enter into Bluetooth mode, press the multi-function button to initiate pairing

Attention: If the pairing is not successful within 3 minutes. the earbuds will power off, please repeat the pairing procedures to try again

Using Your Earbuds

- Listening to Music Play/Pause Button: Press to play or pause a track.
- · Quickly tap the "+" button to increase the volume.
- · Quickly tap the "-" button to decrease the volume. · Press and hold the "+" button to advance to the next song in a playlist.
- Press and hold the "-" button to go back to the previous song in a playlist.

Note: You can also adjust volume and playback settings on your phone or connected audio device.

Using the Phone Function

- Answering a Call: Quickly press the MULTI FUNCTION button to answer an incoming call.
- Reject an Incoming Call: Press and hold the MULTI FUNCTION button to reject an incoming call.
- Ending a Call: Quickly press the MULTI FUNCTION button to end a call.

Note: The phone function can only be used when there is a Bluetooth connection between your earbuds and phone.

Maintenance and Care

-Before using your earbuds, inspect the ports and jacks to make sure that they are clear of dust and debris

-Use a soft cloth to clean your earbuds. Never use any harsh chemicals or detergents. Make sure your earbuds are dry before using.

-When your earbuds are not in use, it should be stored in a

-Never tug or yank on the USB cable while they are connected to your earbuds. Connect and disconnect these cables as carefully as possible

-Never expose your earbuds to high temperatures, extreme cold, high humidity or excessive moisture or

-Please recycle or dispose of your earbuds properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earbuds for further information.



Important Safety Precautions

When using your Vivitar Wireless Earbuds basic safety precautions should always be followed, including the following:

- 1. READ ALL INSTRUCTIONS BEFORE USING YOUR FARRLIDS
- 2. Do not use your earbuds near water. Clean using a soft cloth or paper towel
- 3. Do not place your earbuds on any wet surfaces.
- 4. Do not allow children or the infirm to play with your earbuds without adult supervision
- 5. Do not expose your earbuds to excessive heat, flames or 6. Always press all buttons carefully. Do not manhandle your
- earbuds 7. Do not use in extremely dry environments, as this can lead
- to static discharge during usage 8. Do not expose your earbuds to temperatures above 40°C. Keep out of direct sunlight
- 9. Do not attempt to repair this product yourself. Contact a
- qualified service center if your earbuds is in need of service. 10. Do not drop, puncture or expose your earbuds to excessive trauma
- 11. Your earbuds are not intended for commercial use 12. Do not place near objects that generate a strong magnetic
- 13. Use only the supplied chargers and cables. Unplug this device when not in use for long periods of time or during lightning storms.

FCC Statement

Vol+/Next Track

Multi-Function

Vol-/Previous

Button

Track

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to
- Consult the dealer or experienced radio/ TV technician for help.

which the receiver is connected FCC ID: 2ADM5-VZ40019BT

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting

Call 1-800-592-9541 in the U.S. or 0-800-917-4831 in the UK or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem. and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (cont.)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT SPECIAL PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE

This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored endorsed or approved this product



