

BTE018
Bluetooth mono headset
User's manual

■ Brief introduction	1
1. Bluetooth wireless communication technology.....	1
2. About BTE018.....	1
■ Before use	1
1. Overview.....	1
2. Charging the headset.....	2
■ Getting started	2
1. Power on/off.....	2
2. Pairing with a Bluetooth mobile phone.....	3
3. Replacing ear cap.....	3
4. Making a call with the headset.....	4
5. Re-connecting with a Bluetooth device.....	5
6. LED indicator.....	5
7. Indication tone.....	6
■ Care and maintenance	6
■ FAQs	7
■ Specifications	8

Welcome to use this Bluetooth mono headset, BTE018. Please read this user's manual carefully before use.

■ Brief introduction

1. Bluetooth wireless communication technology

Bluetooth is a standard of close range radio-communication technology that was drawn up by Ericsson, IBM, Intel, Nokia and Toshiba. With Bluetooth technology, we can achieve the highest transmission rate among mobile phones, computers, printers, PDAs and other devices. The max transmission range of class II is 10 meters while the max transmission range of class I can reach up to 100 meters.


2. About BTE018

BTE018 is a Bluetooth mono headset. It has the following features:

- ◆ Answer a call, end a call and reject a call
- ◆ Redial last number
- ◆ Voice dial (This function needs to be supported by your mobile phone)
- ◆ Call transfer between BTE018 and your mobile phone
- ◆ Microphone mute

■ Before use

1. Overview



1	Multi-function button (MFB): Power on/power off/answer a call/end a call/reject a call/cancel calling/microphone mute/call transfer/redial last number/voice dial
2	Built-in microphone
3	Ear cap
4	Loudspeaker
5	Charging jack
6	LED indicator

2. Charging the headset

The headset comes with a built-in rechargeable battery, prior to using it, it is recommended to charge the battery fully for the first time.

Connect the charger to a computer USB port or a standard power outlet and the charger plug to the charging jack of the headset. The red LED is on while charging. It takes about 1.5 hours to charge the battery fully. When charging is completed, the red LED is off.

When the headset is on and the battery becomes low, the LED flashes red and the headset emits a string of indication tones every 15 seconds. Please recharge the battery fully as described above.



Warning:

- 1) The battery is recycled.
- 2) Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

■ Getting started

1. Power on/off

Function	Operation	LED indicator
Power on	Press and hold MFB button for 3~5 seconds	Blue LED is on for 1 second
Power off	Press and hold MFB button for 3~5 seconds	Red LED is on for 1 second
Entering pairing mode	Make sure BTE018 is off, then press and hold MFB button for 6~7 seconds	LED flashes red and blue alternately

Remark: In order to save power, the headset will turn off automatically if no devices can be connected after 10 minutes.

2. Pairing with a Bluetooth mobile phone

Prior to using the headset for the first time, you have to pair it with a Bluetooth-enabled mobile phone. The pairing procedures are subject to different models of mobile phones. Please refer to your mobile phone's user's manual for further information. The general pairing procedures are as follows:

- 1) Place the headset and Bluetooth mobile phone where they are easily viewable by no more than 1 meter apart;
 - 2) Enter BTE018's pairing mode (please refer to "Power on/off");
 - 3) Activate your mobile phone's Bluetooth function and set your mobile phone to search for Bluetooth devices within range, and select "BTE018" from the list of devices shown;
 - 4) According to the indication, enter password or PIN No: "0000"
 - 5) If prompted by your mobile phone to connect, select "Yes" (this will vary among mobile phone models);
 - 6) Go back to your mobile phone's main menu. For certain mobile phone models, a headset icon will be shown on the screen.
- You should now be able to make and receive a call using the headset.

Remarks:


- ◆ Pairing mode will last 2 minutes. The headset will switch to standby mode automatically if no devices can be connected after 2 minutes. If you want to continue pairing the headset with a Bluetooth device, please turn off the headset first and then try re-pairing according to steps 1~6 mentioned above.
- ◆ After successful pairing, the headset and your mobile phone will remember each other, it will no need to repair next time. The headset can remember 8 paired devices. When the number of devices exceeds 8, the first one will be replaced.

3. Replacing ear cap

Four different sizes of ear caps are included. You can replace the ear cap according to ear size and personal preferences.

Herein take replacing large ear cap for example, what you need to do are:

- 1) Remove the large ear cap from the loudspeaker;
- 2) Put the small ear cap onto the loudspeaker.



4. Making a call with the headset

Function	Status of BTE018	Operation
Cancel calling	Calling	Short press MFB button once
Answer a call	Incoming ring	Short press MFB button once
Reject a call	Incoming ring	Press and hold MFB button for about 2 seconds
End a call	During a call	Short press MFB button once
Call transfer (headset to mobile phone)	During a call	Press and hold MFB button for about 3 seconds
Call transfer (mobile phone to headset)	During a call	Press and hold MFB button for about 3 seconds
Microphone mute	During a call	Short press MFB button twice
Cancel mute	During a call (Microphone mute)	Short press MFB button twice
Voice dial	Standby mode and connected to a device	Press and hold MFB button for about 2 seconds
Redial last number	Standby mode and connected to a device	Short press MFB button twice
Clear pairing list	Charging in progress	Press and hold MFB button for about 1 second and then blue LED is on for 1 second

Remarks:

- ◆ Not all mobile phones support all functions listed above. Please refer to your mobile phone's user's manual for further information.
- ◆ When pressing the answer button on some mobile phones, the call will be transferred to the mobile phone. You have to transfer the call to the headset by using call transfer function of the headset or operating on the mobile phone. Please refer to your mobile phone's user's manual for further.
- ◆ Please be advised to turn off your mobile phone's Bluetooth function if you are not going to make a call with the headset in anytime soon.

5. Re-connecting with a Bluetooth device

1) Automatic connecting

Every time BTE018 is turned on, it will connect to the last connected device automatically.

2) Connecting manually

When BTE018 is in standby mode and doesn't connect to a Bluetooth device, press **MFB** button once, the headset will connect to the last connected device .

Remarks:

- ◆ BTE018 only tries to connect to the last connected HFP device.
- ◆ Please enable Bluetooth on your Bluetooth device before trying to connect.
- ◆ On some Bluetooth devices, take some Nokia mobile phones for example, you need to set up "allow automatic connecting" on the phone.

6. LED indicator

1) When it is charging

LED indicator	Status of BTE018
Red LED is on	Charging in progress
Red LED is off	Charging finished

2) When it is not charging

LED indicator	Status of BTE018
LED flashes red and blue alternately	Pairing mode
Blue LED flashes once every 2 seconds	Standby mode (not connected to a Bluetooth device)
Blue LED flashes twice every 5 seconds	Standby mode (connected to a Bluetooth device)
Blue LED flashes quickly	Incoming call
Blue LED flashes once every 4 seconds	Calling
Blue LED flashes once every 4 seconds	During a call
Red LED flashes	Low power

7. Indication tone

Indication tone	Status of BTE018
Two "DU" tones every 10 seconds	Microphone mute
A string of indication tones every 15 seconds	Low power

■ Care and maintenance

Read the following recommendations before using the headset. Following these you will be able to enjoy our product for many years.

- ◆ Consider turning the headset off before placing it in your pocket or bag. If the **MFB** button is accidentally depressed, your mobile phone may place an unintended call.
- ◆ Do not expose the headset to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- ◆ Don't use abrasive cleaning solvents to clean the headset.
- ◆ Do not expose the headset to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- ◆ Don't dispose of the headset in a fire as it will result in an explosion.
- ◆ Don't expose the headset to contact with sharp objects as this will cause scratches and damage.

- ◆ Don't attempt to disassemble the headset as it may get damaged if you are not professional.

In case the product doesn't function properly, send it to the store you bought it. The staff will help you to solve the problem.

■ FAQs

1 Why does red LED flash ?

The headset is low power, it needs to be recharged.

2 Why isn't red LED on when charging?

- a) Please make sure the charger connects well with the headset;
- b) When you doesn't use the headset for a long time, the battery may dry up. At this time, you need to charge the battery for 30 minutes, and then the red LED will be on.

3 How far is the effective range between the headset and Bluetooth mobile phone?

According to the Bluetooth standard, the max. controllable range of Class II headset is 10 meters. It varies under different environment.

4 What to do when my mobile phone can not search and find the headset?

Your mobile phone will not find the headset if the headset and your mobile phone are not under the pairing mode. Make sure the headset is under the pairing mode and in the effective working range, and then the headset can be paired and connected.

5 Why can't I hear the voice from the headset?

- a) Make sure the headset is power on;
- b) Ensure the volume of the headset is not too low or mute;
- c) Make sure the headset connects well with your mobile phone;
- d) Ensure the distance between the headset and your mobile phone is in the normal working scope.

6 Why is there no voice when making a call with the headset?

- a) Make sure your mobile phone is in the strong signal area;

b) Ensure the headset is in the function range.

7. I can't turn off the headset. What shall I do now?

When you start charging the headset, it will turn off automatically.

■ Specifications

Bluetooth version	Bluetooth V2.1+EDR
Bluetooth profiles	HSP and HFP
Operating distance	10 meters Class II
Talk time	Up to 3.5 hours
Standby time	80 hours
Charging input voltage/current	DC 5V --- 250mA
Charging time	About 1.5 hours
Dimensions	32×22×11mm
Weight	6g

Notes:

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
3. Excessive sound pressure from earphones and headphones can cause hearing loss.