

# **Android TV Box**

## **User Manual**


Welcome to use our tv box, We stand with you together always.




Press **HELP** key for HELP when using.

## How to setup before using:


1. Press “help” key of remote control or open browser for help when using.then it is will go to open browser and go to support page .there is many useful apps for android tv box.




2. you can click the app icon and download it.for example we want to install “KDPLAYER(KODI)” app.you can click the “KDPLAYER(KODI)“ icon.




3. when you click the “download” icon,then it is will open a note,then you just need click the “download” options.then it is begin to download.



4,when it is downloaded.you can choose the file and press “ok” key of remote control,then it is will ask you to install it.you can choose “install option ” and install it.




when you installed it,you can open the new app.






#### 4. NOTE:

after you downloaded the KDPALAYER(KODI), you can go to the support page and download the “AddOnTool”APK,it is will easy to use KDPALAYER(KODI)




## 5. how to use the “CetusPlay”, it is make a lot easy use your tv box.


1, you must install the apk on your phone first, you can use this link to download this apk, you can search “CetusPlay” in google store or app store.



2. Go to App center in side bar and click KODI or other free movies/TV shows app like Mobdro, UKTVNOW, Terrarium TV to install on phone.



3. Mind the TV screen and wait for the download, then just click install the certain apps you wan to install onto TV box.



# 1. Getting Started

## 1.1 Basic Operations

### 1.1.1 Power On/ Off and Sleep

1. Connect the box to the TV with HDMI cable, connect box to the power adaptor, Connect mouse, air mouse or other input devices with USB port
2. After the device and cable connected ,power led turn to blue .
3. After the device and cable disconnected, Power LED turns off
4. Under power on mode, press remote control's power button, device is entering into sleep mode.
5. Under sleep mode, device will be wake when you press remote control's power button,

### 1.1.2 Open applications

Use remote control's arrow keys to choose the wanted program, click OK button to open the selected program

### 1.1.3 Switch in the applications

Click "My Apps" to view recently used programs, click program icon to switch application arbitrarily

### 1.1.4 Close Applications

Click icon  \* to view recently used programs, choose one of them by click and hold, drag it to blank area to close the application

\* This function only operated in the condition of Mouse mode

### 1.1.5 Back To Home Screen


Click icon  to return to home screen

Click icon  on remote control to return to home screen

### 1.1.6 Read External Storage Data


#### Read U Disk

Insert U flash disk or removable hard disk into USB port in the status of power on, icon  appears in top left corner of the desktop, open “FileBrowser”, the identified USB(A:) will appear under “Local Disk”, U disk’s operation is available now



#### Read TF card


Insert TF card into the device in the status of power on, when icon  appears in top left corner of the desktop, open “FileBrowser”, the identified External Storage Card will appear under “Local Disk”, TF card’s operation is available now



### 1.1.7 WIFI Function

Home Screen → SETTINGS → Network → Select “Wi-Fi” to open WIFI function


Choose hotspot → Input Password → Connect to the network



### 1.1.8 Ethernet Function

Home Screen → SETTINGS → Network → Select “Ethernet” to open Ethernet function


Insert network cable, network will be connected automatically



### 1.1.9 WLAN Hotspot

Operations on the box :

Home Screen → SETTINGS → Other → More Setting → More... → Portable hotspot → Select “Portable Wi-Fi hotspot”



Select “Set up Wi-Fi hotspot” to set up “Network SSID”、“Security”、“Password” parameters



- \* Ensure connected to the wired network, the box can be used as wireless AP to support more wireless devices access in the family

### 2.1.0 The Step that how to reflash the box

- 1) Uncompress the downloaded firmware (ROM) to the root of and SD card(format your SD card first).
- 2) Insert the SD Card into powered-off Box (power cable not plugged in) with no external USB storage attached.
- 3) Using a toothpick, insert into the AV port of Box, press and hold the hidden button while plugging power in. Do not release until you see the screen of Robert Logo.
- 4) Update will run automatically. When it is done then choose “Reboot”. You can disregard any errors that display after the update, they are not relevant to your device.
- 5) When system has rebooted then you should first check to ensure wifi is working by going to Settings->Wi-Fi. Turn on the wifi if it's off and you should be able to connect.

# Q&A:

**How do I set the time?**

-From the home screen go to Settings>Time.

**How do I update?**

-The device automatically updates if your Internet is connected.

**Can I use this device on more than one TV at a time?**

-You can only connect the device to one TV at a time.

**How do I add a Movie or TV Show to favorites?**

-When a Movie or Show is highlighted, press the MENU button on your remote and select “Add to favorites”.

**Why do I experience buffering?**

-Buffering depends on your Internet speed and the speed /load of the server attempting to play from. Often this is resolved by choosing another source/ server. Run a speed test as well.

**How do I run a speed test?**

-Select the “Internet Speed Test” option from the Kodi main screen. We recommend at least 15 mbps download and 10 mbps upload.

**How do I remove the “Swipe down from top to exit full screen” message?**

-Press the CUESOR button on your remote to turn on the cursor on your screen. Next, use the arrow on your remote to navigate the cursor to the top of your screen and select OK when the cursor is positioned at the blue OK button. Once the popup is gone, press the CURSOR button again on your remote to disable the cursor.

**Can I use this device outside the U.S.?**

-Yes, as long as you have high speed internet.

**All videos are displayed on a corner of my TV.**

-Press SETUP on your remote>Go to display >Select 720p.

**How can I watch PPV fights?**

-PPV Fights will be available under the Sports menu in Kodi.

**Can I download Movies?**

-The main purpose of this device is for streaming and we do not recommend downloading.

**My Wi-Fi signal is strong but nothing will play.**

-Run a Speed Test.

**How do I reset my device?**

-Press SETUP on your remote and go to Backup and Reset >Factory Data Reset>Reset >Erase.

**My device is frozen in Kodi.**

-Press the Home button on your remote then select Clear Cache.

**My device is powered on but I do not see anything on my TV.**

-Check to make sure that your TV is set to the correct input source to which you have connected the HDMI cable. Also try to connect to a different HDMI port on your TV or use a different HDMI cable.

**I have no sound output my form my TV.**

-Press SETUP on your remote and go to Advanced. Turn off autodetect sound output then manually set sound output to HDMI.

## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 20cm separation distance between the user's body.