

BT310 Manual-Bluetooth Media keypad

.....Turn your PC into a Bluetooth Technology

System requirements

- IBM or compatible PC
- Windows and Macintosh Operating System
- Windows and Macintosh Operating System
- At least 10MB hard disk space
- Bluetooth dongle or system and Bluetooth software

OS support

- Windows XP
- Windows 2000
- Windows XP/XP64

Introduction

Thank you for your patronage of purchasing our Bluetooth keypad. For your own safety, please read this manual thoroughly before using this product. After you have read this manual, please keep it in place for reference when necessary.

Contents in this package

The following items are included in the package. Please make sure all items are accounted for as you open the package. If there was any item missing or damaged, please contact the reseller where the product was purchased or our support center.

- Bluetooth Media Keypad x 1
- Manual/warranty x 1
- 2 AAA Alkaline batteries x2

Specifications

- Dimensions: 147.8*83*28.04mm
- Weight: 160 +/- 20g (with Battery)
- Key Number: 19 Keys
- Battery: 2 x AAA batteries
- Battery Life: 2 Month (Base on average usage)
- Hot Keys : Volume up, Volume down, Mute, Skip back, Skip forward, play/pause, Stop, Rewind, Fast forward, Media Player

Remark: Media player key only support to Windows XP and above.

- LED Indicator:
Green Light on: Num lock key off

Green Light off: Num lock key on

Glittering Red Light: Battery low

Hot Key Functions



(Reference)

Warning

Zippy Technology Corporation and its respective distributors and resellers are not responsible for any malfunction, damage or personal injury incurred by:

Any malfunction, damage or personal injury caused by the malfunctioning or damage of the user's personal computer or misuse of this product. Any attempt to dismantle, change or modify this product in any manner.

Warning

Please do not use this product in ashy, wet, or oily environments. Failure to do so may shorten the life of this product and may cause bodily harm.

Please keep this product as far away from Radio Frequency interruption areas as possible.

This is not an outdoor product. Exposing this product to the elements may cause damages to the product and bodily harm to its users. Please do not use petroleum, benzene or thinner-based solution to clean this product.

Warranty Information

This product is backed by a One-Year Manufacturer's Warranty, starting from the date of purchase. The warranty covers for free repair in accordance with the contents stated herein but does not cover wear and tear and any malfunction or damages as results of improper usage as stated in this manual.

Installation Procedure

Before installing this product please make sure you have available Bluetooth system or Bluetooth dongle as basement.

Setting up the Bluetooth Keypad

1. Open the Bluetooth software of your system.
2. Press the "Refresh" or "Renew" the Bluetooth device.
3. Press the ID button of keypad.
4. Your system will find the BT310 keypad device on your Bluetooth dialog.
5. Then double click the BT310 keypad device icon, the system will show a link message and ask you to enter password. (This procedure may different by your Bluetooth software and system. Please read your system or software instruction.)
6. After your Bluetooth software show the link message, you can use keypad as well.

Battery Low

1. Low-Battery is indicated by the illumination of the keypad lens. Please replace the battery when the LED lights up.
2. We recommend using alkaline batteries for the keypad.
3. You may need to reset the Link after replacing new batteries for the keypad.

Warning

Please be careful when resetting the Link for the keypad. Objects with sharp point may break and leave behind shards.

Troubleshooting

Please visit our On-Line FAQ section for help.

FCC Statement on CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measure:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Mandatory repair charges are required for the following conditions, even within the guarantee period:


- (1) Malfunction or damage is due to misuse or improper alteration or repair.
- (2) Malfunction or damage is caused by the movement or fall during installation after the purchase.
- (3) Malfunction or damage is caused by a fire, salt, gas, earthquake, lightning, wind, water or other natural calamities, or abnormal voltage.
- (4) The manual is not presented.
- (5) Date of purchase, customer's name, name of the shop are not filled in or are altered.
- (6) Malfunction or damage is caused by other devices connected to the BT-310

To get the repair service, please disconnect BT-726 from other devices connected.

Date	Contents service
Person in charge	
Person in charge	

FCC Statement on CLASS B

This warranty is intended to provide free repair under the terms and period stated herein. Accordingly, this warranty shall not limit the legal rights entitled to the Customer. For more information concerning the repair after expiration of the guarantee period, please contact us or our retailer where you purchased this product. Names of other products mentioned in this Manual are the trademarks or registered trademarks of their respective owners.



All brand names, trademarks and logos are the properties of their respective owners.