

SI-LINK QUICK START GUIDE

1. Select an FM bandwidth on your car radio between 88 MHz-89.5 MHz that has little or no radio signal.
2. Plug your SI-Link 3.5mm stereo plug your line out or headphone input for the portable player. Turn both the portable player to the on-"play" position and turn your SI-Link on. The power light should be visible on the SI-Link. Fine tune your SI-Link using the signal adjustment dial at the top of the transmitter. Adjust the dial until the music from your portable sound source, hooked to your SI-Link, is clear and stable through your car radio.
3. In some high FM radio band traffic areas you may hear some minor interference while driving. This is due to the fact that the radio signal at the selected bandwidth is stronger in that specific area. It may clear up in a short drive distance or you may need to re-tune your SI-Link slightly or select another bandwidth by repeating step 1.
4. If the noise or distortion persists it may be a result of one of the following:
 - a) The power of Link is low, please replace the batteries
 - b) The power of portable player is low, please replace the batteries.
 - c) If the audio input level is too high, please adjust the volume of portable player down.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty:

Manufacturers warranty is valid for 90 days from proof of purchase.



Sonic Impact Technologies, LLC
San Diego, California USA
www.si-5.com

FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.