







## Quick Start




## Touch Screen and Navigation

Your phone features a capacitive touch screen, so you can gently tap, quickly swipe, or pinch with two fingers to navigate.

### Navigating Your Phone

- Use your fingertip to lightly touch the screen.
- Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
- Spread two fingers apart or pinch them together on the screen to zoom in or out on a web page or a gallery image.
- The Notifications bar at the top of the screen provides quick access to alerts including new messages, email, and voicemail. Swipe down on the black bar to see more details.
- To return to the previous screen, press .
- Press  to return to the main home screen. Press and hold  to access Google Now™.
- Press  to access menu options for the screen you are on. Press and hold  to access your recent apps.
- Tap  to access applications on your phone.



## Customize a Home Screen

Change the wallpaper, add shortcuts to apps and widgets to the home screen, and create folders to organize and personalize your phone.

### Set the Wallpaper

- ① Press and hold a blank part of the home screen and tap **Wallpaper**.
- ② Tap **Wallpaper for home screen** or **Wallpaper for lock screen**.
- ③ Tap **Gallery**, **Live**, **Photos**, or **Wallpapers** and choose the image or animation you want to use as the wallpaper.
- ④ Tap **OK** (for Gallery images) or **Set wallpaper**.

### Add Shortcuts to the Home Screen

- ① Press and hold a blank part of the home screen and tap **Widgets** or **Apps**.
- ② Press and hold the icon of the item you wish to add and then drag it to a home screen thumbnail at the bottom.
- ③ To move an icon, press and hold it and drag it to a new location. To delete it, drag it to **Delete** and release your finger.

### Organize Your Home Screens

- ① Press and hold an icon and drag it to **Folder**.
- ② To add apps, drag additional icons to the folder.
- ③ To rename a folder, tap it and then tap the name to bring up the keyboard. Enter a name and tap **Done**.

## GoPhone Account

### Auto Refill

Take the hassle out of refilling your account by enrolling in Auto Refill.

### From Your Device

- ① Call 611 from your phone.
- ② From the main menu, say "More options," and then say, "Set up auto pay."

### Online

- ① Visit [att.com/mygophone](http://att.com/mygophone).
- ② Under Auto Refill, select **Sign Up > Manage My Account > Auto Refill**.

### Add Money with a Credit Card, Debit Card, or Checking Account

- ① Call 611 from your phone and say, "Add money."
- ② Go to [att.com/mygophone](http://att.com/mygophone) and select the **Credit Card Payment** link.

### Add Money by Purchasing a GoPhone Refill Card




Add money by purchasing a GoPhone Refill Card, which is available at authorized retail locations nationwide. With most refill cards, you can add the value directly from your phone.

- ① Dial 611 from your phone and say "Add money."
- ② Enter **\*888\***, followed by your PIN, the **# key**, and then press **Send**.
- ③ Go to [att.com/mygophone](http://att.com/mygophone) and select the **Refill** link.




## Camera and Video Recording

Take pictures and record videos right from your phone with the camera and camcorder and then share them with friends and family.


### Take a Picture

- ① From the home screen, tap .
- ② Tap  to adjust your camera settings. Zoom in and out by pressing the volume key.
- ③ Tap  to take a photo.

### Record a Video

- ① From the home screen, tap .
- ② Tap  to start and tap  to stop recording video.

### Share a Picture or Video







- ① From the home screen, tap  > **Gallery**.
- ② Tap an album and then tap a photo or video. Tap **Share** and select an option for sharing.




## Contacts and Phone Calls

Keep the contact information of your favorite people in the address book. Call friends and family and check voicemail in just a few simple steps.




### Import Contacts from SIM card

- ① From the home screen, tap .
- ② Press  > **Import/Export** > **Import from SIM card**.
- ③ Tap  > **Export to phone**, tap the contacts you wish to import and tap , or tap  >  to import all contacts.


### Edit a Contact

- ① From the home screen, tap .
- ② Tap a contact name, then press **Edit**.
- ③ Change details as needed and tap **DONE**.

### Make a Call

- ① From the home screen, tap .
- ② Spell the name or phone number of a contact in the search box at the top of the screen, or tap  and enter a phone number. Tap the contact or tap  to place the call.





### Check Voicemail


- ① From the home screen, tap .
- ② Press and hold the **1 Key**.
- ③ Follow voice prompts to listen to messages.

## Text and Picture Messaging



Send text or picture messages to communicate privately and quickly.


### Send a Text Message

- 1 From the home screen, tap .
- 2 Tap  to start a new text message.
- 3 In the **To** field, enter a number or a contact name, or tap  to access your contacts.
- 4 Tap the **Type message** field and enter your message.
- 5 Tap  to send the message.



### Send a Picture Message

- 1 Follow steps 1-4 above.
- 2 Tap .
- 3 Tap **Pictures** and select desired picture.
- 4 Tap  to send the message.




*Please don't text and drive.*

## Bluetooth® and Wi-Fi®



Pair with other *Bluetooth* devices or connect to a Wi-Fi network.


### Connect to a Bluetooth Headset

- 1 From the home screen, press  and tap **System settings > Bluetooth**.
- 2 Tap  to turn *Bluetooth* on.
- 3 Your phone will automatically search for devices. Tap the name of the device to pair and connect with it.



### Connect to Wi-Fi Network


- 1 From the home screen, press  and tap **System settings > Wi-Fi**.
- 2 If Wi-Fi is off, tap  to enable it.
- 3 Tap a network name. Enter a password if required and then tap **Connect**.




## Email




Access your Gmail™, corporate email, and personal email wherever you are!


### Email Setup

- 1 From the home screen, tap .
- 2 Enter your email address and password and then tap **Next**.
- 3 Confirm email account settings and tap **Next**.
- 4 Name the account, enter your name as it will appear on outgoing messages, and tap **Next**. Your email will begin to synchronize with your phone.



### Create and Send an Email






- 1 From your email inbox, tap .
- 2 Enter an email address or tap  to access your contacts list.
- 3 Enter a subject and email message. To attach files to the email message, tap , tap **Attach file**, and make your selection.
- 4 Tap **Send** to send your message.



Note: To set up corporate email, contact your IT administrator.

## AT&T Services





Check out these handy apps from AT&T.

-  **AT&T Drive Mode™**: Silence notifications, set an auto-reply so people will know you're driving, and more.
-  **AT&T Locker™**: Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.
-  **AT&T Navigator®**: Get voice-guided, turn-by-turn driving directions and traffic updates.
-  **MobileTV**: Watch LIVE, on-demand, and downloadable mobile TV.
-  **AT&T Usage Manager**: You can track how much data has been used during the time cycle you set, set a mobile data limit and warning, see what apps have been using mobile data, or restrict background data for individual apps.

Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

## Network Indicators

Your 4G LTE wireless device will indicate which of the AT&T wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

-  **4G LTE**: Connected to the AT&T 4G LTE network.
-  **4G**: Connected to the AT&T HSPA+ network. The AT&T HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.
-  **3G**: Connected to AT&T's 3G network.
-  **Edge**: Connected to the AT&T EDGE/2G network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: [wireless.att.com/learn/articles-resources/wireless-terms.jsp](http://wireless.att.com/learn/articles-resources/wireless-terms.jsp), your AT&T Wireless Customer Agreement, Section 3.2 "Where and How Does AT&T Service Work?"

4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at [att.com/network](http://att.com/network).

## Find More Information

### On the Web

- Find tutorials at [att.com/Tutorials](http://att.com/Tutorials).
- Find device specifications, user manuals, troubleshooting, and user forums at [att.com/DeviceSupport](http://att.com/DeviceSupport).
- Manage your wireless account, including suspending service if your phone is stolen, at [att.com/myatt](http://att.com/myatt).
- View the User Guide at [www.zteusa.com/phones/zte-portland.html#manual](http://www.zteusa.com/phones/zte-portland.html#manual).

### Give us a call

- Call AT&T Customer Care at **1-800-331-0500** or dial **611** from any AT&T mobile phone for assistance with your service or device.

ZTE is a registered trademark of ZTE Corporation. © 2014 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.

Printed in China