

User manual

C210

Declaration

Please read the user's manual so as to keep your mobile phone in the best condition, The manual has been verified and reviewed to guarantee the accuracy. Instructions and descriptions contained herein are accurate at the time of publication. However, mobile phones developed afterwards and the contents of their manual are subject to modification without further notification. Our company reserves the rights in relation to the manual

■ Overview

Please read the following concise rules carefully. Nonobservance to the rules may lead to danger or violence of the laws. The user's manual gives details about the safety precautions.

■ Emergency call

Make sure the equipment is in the covered area of the network service and the calling function is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

■ Function Description

The phone is a perfect combination of humanized design and exquisite workmanship, the streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports TXT electronic book, Blue-tooth, dual SIM cards with one standby, network camera, camera, FM and etc, It makes your work more convenient and your free time more fun with the combination of keyboard, florid colored screen, pleasant bells, cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

1. Introduction

Insert the SIM card and the battery

Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers, SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.

■ **Inserting/taking out T-FLASH CARD**

Only use approved and compatible T-FLASH card applicable to the mobile phone. Approved memory card trade standard is applied; however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may damage not only the card and the mobile, but also the data stored in the card.

■ **Charging the battery**

Check the model number of the charger before using it to charge the mobile, Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger, Refer to the dealer for supply of relative approved accessories.

■ **Startup and shutdown**

Press the key of power supply to start up or shut down the mobile phone, If it is prompted to input PIN or UPIN, please input the required password (shown as **** on the screen).

2. Function of main menu

■ **Message**

Write a message: You may select to send the finished message from SIM card 1 or 2

■ **Contacts**

You may save the information of contacts including photo, names and telephone numbers in

the phonebook, which can save as much as 300 entries.

■ **Call log**

You can check all records for missed calls, dialed calls, received calls, rejected calls and you also can delete all of them.

■ **Camera**

In the options of camera, you can check Image viewer, DV mode and effect and settings. You can take a photo via pressing button 5.

■ **Image viewer**

Check the pictures in the phone and memory card.

■ **Video Recorder**

When you insert the TF card, you can Shoot Video via pressing button 5, You also can find setting options via selecting Options.

■ **Video player**

Check the video files in the TF card supported by the cell phone.

Play your favorite video files.

■ **Audio player**

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call.

■ **Record**

You can start voice recorder via pressing button 5, and when you press "stop" it will be saved automatically.

■ **FM radio**

Open FM menu, it will auto search the channel, press button 5 to pause or play FM, press button 4 and 6 to change the channel.

■ **SOS**

SOS switch setting

You can open or close SOS function

SOS number

you can set up to 5 numbers for SOS calls. When SOS function activated, the telephone will automatically call these 5 numbers 5 times repeatedly if there is no answer.

SOS message

You can edit to send this SOS message or not and you can edit the SOS content.

■ **Settings**

■ **Profiles**

You may customize the profiles and activate any profile in order to use a specific function.

You may set the ring setting, type, volume.

Display settings

You can change the wallpaper in this setting, a standby interface style, the standby display screen backlight ,Animation effect settings.

Phone settings

Refer to settings of basic functions, including time and format, display language,Input method settings, Adjust touch screen, Auto power on/off, Power saving mode and response time, reset all settings.

Security setting

You may set functions in relations to cell phone security.

Call settings

You can set Dual SIM, call divert, call waiting, call barring, hide ID and others.

Connections

You can make set according to your actual use of the operators in the network connection settings.

Restore the factory settings

Enter the correct password of the phone will have to change your phone settings back to factory default state value, the user of the function be used with caution. (Default password: 0000).

■ **Internet**

your mobile Internet support based on wireless application protocol (WAP) service. You can access a variety of WAP service. WAP service need network support, the WAP service availability, price and tax, please contact your network operator or provide you with the service providers of services required.

■ **Bluetooth**

You may establish wireless connection with other compatible devices with the Bluetooth

technology; you may send images, videos, music files and etc. with the Bluetooth technology;

- **Alarm**

You can set three alarms through this function..

- **Calculator**

A simple calculation can be performed.

- **Torch light**

Turn on/off torch as per your need.

Besides, you also can turn on/ off torch by long time pressing button 0 at main interface.

3. PC connect

- **USB**

Use the T-Flash inserted in the mobile phone as U-Disk. You can transfer music, videos, games and other files form PC to the T-Flash by USB cable. Enjoy it anytime and anywhere.

- **COM PORT**

Establish a modem on the local computer and construct a network, and the serial interface is connected after signing in with the account.

4. Maintenance and service

Refer to the local dealer for supply of accessories. Hereafter are some precautions for usage of the accessories, Only use batteries, chargers and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger, Keep the equipment dry, Don't keep the equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board. .Only use matched or approved antenna .

FCC Caution.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Specific Absorption Rate (SAR) information:

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the handset kept 10mm for body worn. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm for body worn. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm for body worn must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.