

When loud speaker function is activate, you can listen the tuner loud speaker if plug the earphone). Record, Append and File list. Note: Quality of record subscription is possibly influenced by environment like indoor or under shade. You can improve this situation as following: stand closer to the window or adjust the channel manually.

**Video player**  
This menu allows you to playback videos stored in your phone or memory card.

Enter video preview interface, press the OK key or the Left soft key (Options) to make the following operations: Play (Play this video). You may need to press the OK key to start playing when screen displays start interface. During playing, you can press the \* key or # key to adjust video volume for video with sound). Send, Rename, Delete, Delete all files. Sort by and Storage.

**Sound recorder**  
Your phone can record phone conversations made and record non-call sounds in AMR or WAV format. Select this option to enter the record interface directly, use the up navigator key to start record, press the Left soft key or OK key to pause/continue recording, use the Right soft key (Stop) to stop recording, select [Yes] to store the recorded audio.

Select this option, and press the Left soft key (Options) to make following operations available:

- **New record:** Record a new audio.
- **List:** Once that you have recorded audios, scrolling to the file and press the Left soft key (Options) will make following operations available: Play, Append\* (for AMR format), Rename, Delete, Delete all files, Use as send.
- **Settings:** Use the left or right navigator key to choose the storage, file format or audio quality.

## File manager

The currently available memory locations are shown in the file manager interface (if inserted memory card only), the Total and Free memory are shown on top.

Press the Left soft key (Options) to make the following options:

- **Open:** Enter or open the selected drive.
- **Format:** Format the currently selected drive; this will erase all current contents.
- **Rename:** Modify the name of the selected drive (the memory card only).
- **Details:** Show details of the selected drive (the memory card only).
- **Open:** Open the selected drive to see folders and files inside. Scroll to a folder and press the Left soft key (Options) for following options:
  - **Open:** Enter or open the selected drive.
  - **New folder:** Create a folder in the currently selected drive.
  - **Rename:** Modify the name of the folder (file, folder, file, folder).
  - **Delete:** Delete the current folder.
  - **Sort by:** Arrange the files according to name, time, size, or no sorting.

Scroll to a file (file types not supported will have an icon with question mark) and press the Left soft key (Options) for following options (in addition to the folder options above):

- **View/Play:** Depending on the file type, view an image or play a video or an audio. This option is not available for file types not supported by your phone.
- **Use:** Use the file, specific functions depending on file type.
- **Copy:** Copy the file to another folder.
- **Move:** Move the file to another folder.
- **Delete all files:** Erase all files in the current location.
- **Details:** Show details of the file.

## Phonebook

Stores and manages contacts that you often use.

There are two locations where you can store the names and numbers that you regularly use. In the SIM memory and in the phone memory. The volume of contacts can be saved in SIM card depends on SIM capacity.

Enter the Phonebook list via the menu, including all records saved in the phone and the SIM card. There are different icons before different records indicating its memory location.

As you are browsing, you could enter a character, characters or number and jump to contacts whose names (as saved in the phonebook) starting with or most closely matching with the characters entered.

After searching for the name, press the Green key to dial the number of record, and press the Red key to end dialing. Press the OK key to view the details of the selected record. Press the Left soft key (Options) to access the menu options:

- **View:** Display details of the currently recorded.
  - **Send text message:** Send a text message to the currently recorded.
  - **Send multimedia message:** Send a multimedia message to the currently recorded.
  - **Call:** Dial the currently selected contact number.
  - **Edit:** Modify the currently selected contactor record.
  - **Delete:** Delete the currently selected record.
  - **Copy:** Copy this record to SIM card if it is saved in phone and vice versa.
  - **Move:** Move this record to SIM card if it is saved in phone and vice versa.
  - **Copy:** Copy to move the record from the phone to SIM card, only the name and number of record can be transferred.
  - **Send contact:** Send selected contactor record to the other via SMS or MMS.
  - **Add to Blacklist:** Add the phone number to the black list.
- **Phonebook settings:** Select this option to enter the Preferred storage. Set default memory location to SIM or phone for saving new contacts.

**Speed dial:** Set phone's speed dial functions. Use the OK key to act. Enable speed dial option to turn speed dial function on or off. Select 'Set number', scroll to a key number (8 available; from 2 to 9), press the OK key and select 'Edit', scroll to the desired number to set as speed dial number for the key and press the OK key.

When a number is set as speed dial and the function is enabled, you can simply press and hold the corresponding numeric key to the number for instant and automatic dialing.

**My number:** Select and view my number (with name).  
• **Card view:** Select the vCard viewer.  
Extra numbers: Save and view up to 2 own numbers (with name), service dialing number and SOS number.

**Memory status:** View the service condition of the SIM card and phone's phone book. The capacity of SIM card depends on different SIM card.

**Copy contacts:** You can select 'SIM to phone, phone to SIM' option to copy the phone book you want.

**Move contacts:** You can select 'SIM to phone, phone to SIM' option to move the phone book you want.

**Delete all contacts:** Select to delete the contacts from SIM or the phone memory.

**Add new contact**

This menu allows you to add the new record to the SIM card or the Phone. Enter the phone number directly in standby mode, then press the OK key or the Left soft key to save the phone number in the SIM card or the Phone.

First you need to select storage: SIM or To Phone.

- **To SIM:** Select this option. Press the OK key or press the Left Soft key (Edit) to enter name input interface and input the corresponding name, then press the OK key or press the Left soft key (Options) to select Done and confirm.
- **To Phone:** Select this option. Press the Navigator key to switch to number column, enter the phone number directly and confirm, finally press the Right soft key (Done) and confirm to save, adding records to the SIM card will be done.
- **To Phone:** For adding new phonebook record to phone.

## Messages

Message service is a network dependent function, which allows you to send, receive and edit all kinds of messages. Please contact the network operator for more details.

### SMS

- Write message

Compose a new message, save and/or send it to the recipient. While composing, a text message can be up to 612 characters in length.

Press the Left soft key (Options) to select options when editing:

- **Send:** To send the composed message, input the recipient's number using the keypad or select a contact from Phonebook.
- **Input method:** Choose or change current input method.
- **Insert template:** Insert a pre-made but or composed template.
- **Advanced:** Select the phone number or name of the contact from the phone book that you want to insert, or insert bookmark from the internet services.

• **Save:** Save the message to Outlook.

• **Role:** 1. Select SIM card, you need to set the correct SMS service center number which can be obtained from network provider, 2. If [SMS settings/Common settings/Save sent message] is [On], the sent successfully/unsuccessfully SMS will be both saved to Outlook; otherwise the SMS will not be saved.

Received SMS messages can be stored either in phone or in SIM memory, and are accessed here.

When you have received the message, the tones or vibrations (as defined in the menu [User profiles/Profile options] Customize [Tone settings/Message]) to alert you and message mark will also be shown on the screen. Press the Left soft key [Read] or the OK key to read the new message, press the Right soft key [Back] to return, and you can also access the inbox to read the new message, if the message memory is full, the indication 'Memory full' and the message icon will be shown on the screen and linked. Before you can receive new messages, delete some of your old messages in the inbox folder. If the capacity of

new messages is beyond the capacity of the inbox, the information will be lost and incomplete.

In message list, press the OK key to read the selected message, press the Left soft key (Options) to make the following menu:

- **View:** Read the selected message.
- **Reply:** Reply SMS to the message sender directly.
- **Call recipient:** Call the message sender directly.
- **Forward:** Forward the message to someone else.
- **Delete:** Delete the messages.
- **Delete all:** Erase all received messages in the Inbox.
- **Save to Phonebook:** Save the sender to the phonebook.
- **Mail several:** Mail one or several files and make the following operation of copy, move, delete and so on.
- **Advanced:** Duplicate or transfer the currently selected message to the other memory from where it is currently stored. Also you can copy or transfer all messages 'From SIM' or 'From phone memory' to the other.

• **Outbox**  
Select [Save] option when editing or save the message that unsuccessfully sent. If activated [SMS settings/Common settings/Save sent message] save the successfully sent message in the Outbox.

Please refer to 'Index' for more information.

• **Templates**  
Keeps and maintains up to 10 frequently used short messages for input convenience in the future.

**SMS settings**  
Select to save SMS service parameters of SIM card.

• **Profile settings:** Set and save a SMS profile: Profile name, SMS/c address, Validity period and Message type.

• **Common settings:** Choose to activate/deactivate delivery report, notify path or save sent message.

• **Memory status:** View the percentage of the SMS memory consumption.

• **Preferred storage:** Select where to store messages, either in SIM or phone memory.

• **Preferred connection:** Select which type to connect network, either prefer GPRS, prefer GSM or GSM only.

### MMS

With this message service, you can send or receive message content of both picture and texts. All color pictures, animations and music can be delivered to the other side or received to your own phone. This service requires support from network Operator Company and the GPRS function must be opened. For details please contact network Operator Company.

- Write message

When writing message, you can select To, Cc, Bcc, Subject or Edit content.

• **To:** The phone number or E-mail address are both OK.

• **Cc:** Send the MMS to others at the same time. Phone numbers or E-mail addresses are both OK.

• **Bcc:** Send the MMS to others secretly at the same time. Phone numbers or E-mail addresses are both OK.

• **Subject:** Edit subject of the MMS.

• **Edit content:** Enter the text or add image, audio, attachment etc.

After composing, press the Right Soft key for 'Done' for the following options:

• **Send and send:** Send the composed message.

• **Save and send:** Send the message similarity to 'Send only' option, but also save a copy to 'Outbox'.

• **Save to Drafts:** Save the message to the Drafts.

• **Send options:** Set MMS message sending options.

• **Exit:** Exit this interface.

- Inbox

Received MMS messages can be stored either in phone and are accessed here. Pressing the OK key or the Left Soft key while viewing the message for following options:

• **View:** View the details of the message.

• **Download:** Available if the message has not been downloaded.

• **Reply:** Reply MMS to the sender.

• **Reply by SMS:** Reply SMS to the sender.

• **Reply all:** Write a reply to the sender and other recipients of the message.

• **Forward:** Send the received message to another person.

• **Delete:** Delete the message.

• **Delete all:** Erase all received messages in the Inbox.

• **Properties:** View the details of the messages such as the sender, Cc, Subject, Date, and Size.

• **Use details:** Draw sender's phone number and numeric string of no less than 3 numbers which are displayed in a list, select one to save, dial or send MMS etc.

• **Outbox**  
If (Save and send) option is selected when sending the message, the sent MMS will be saved to Outbox.

• **Drafts**  
Incompletely composed and saved messages can be organized and accessed here.

• **MMS settings**  
Set and save MMS service parameters.

• **Profiles:** Set, select and edit network MMS profiles. Inquire with your service provider for more details.

• **Common settings:**  
Composes the following content of MMS creation: Creation mode, Picture resizing, Best page time or Auto signature. If activated 'Auto signature', you can edit the signature.

• **Send:** Configure the MMS sending parameters: Validity period, Delivery report, Read report, Priority, Slide time or Delivery time.

• **Roaming:** Configure MMS network parameters: Home network, Roaming, Read report or Delivery report.

• **Filter:** Set to filter MMS receiving: Anonymous or Advertisement. Memory status: View the MMS Usage, Total, and Free memory status.