


# LET'S GET STARTED

Complete user manual available at gopro.com/help.


# SET UP



Insert a microSD™ card (sold separately).

#### NOTICE

The camera is not waterproof when the door is open.



To select a language, press the Mode button and follow the on-screen instructions.

# **CAPTURE VIDEO + PHOTOS**



Video



Time Lapse



Short press records in Video mode.



Long press records in Time Lapse mode.

# **CHANGE MODES + SETTINGS**


Move through the menus.

Select an option.





# **CAMERA MOUNTING**



Apply an adhesive mount to a clean surface at room temperature.

Insert the camera into the mounting frame.

Click the mounting buckle into the adhesive mount.

### MOBILE APPS

GoPro apps make it easy to control your camera, create awesome videos and share with friends.



### **CAPTURE APP**

Control your GoPro and share on the go.



#### QUIK™ APP

Automatic edits made awesome.



### SPLICE APP (iOS® ONLY)

Custom edits made simple.





### **DESKTOP APP**



#### GOPRO FOR DESKTOP

Access and enjoy your GoPro media. Create incredible videos with just a few clicks.

pgopro.com/apps

#### **UPDATE YOUR GOPRO**

Connect to Capture or GoPro for Desktop to check for updates and get the latest features.



### **GOPRO AWARDS**

Submit your best photos and videos to GoPro. Our favorites receive cash awards.

gopro.com/awards

