



English ..... 1-24
繁體中文 ..... 25-47
简体中文 ..... 48-70
Pedoman Pengguna ..... 71-95
Thai ..... 96-118

Contents
MyVoice 307 Overview ..... 3
Getting Started ..... 4
Charging Your Headset ..... 5
Indicator Light ..... 5-8
Pairing Your Headset with a Bluetooth Mobile Phone ..... 8-9
Using Your Headset ..... 9-11
Resetting Your Headset / Removing the Pairing History ..... 12
Troubleshooting ..... 13-14
Safety Information ..... 15-16
Care and Maintenance ..... 17-20
Declaration of Conformity ..... 20

Product Specifications
Bluetooth Specification: v2.0 + EDR Class 2
Headset and Handsfree
Range of Frequency: 2.4GHz spectrum
Nominal Charging Time: Within 3 hours
Talk Time\*: Up to 5 hours
Standby Time\*: Up to 140 hours
Dimensions: 41.5 (L) x 21.3 (W) x 11.4 (H) mm / 1.63(L) x 0.84(W) x 0.45(T) inch
Weight: 8.9 grams / 0.32 ounces

MyVoice 307 Overview
1. Multi-function Button (MFB)
2. Power On / Off
3. Answer / End a call
4. Last number redials
5. Voice dialing
6. Volume
7. Reject / Transfer a call
8. Status indicator
9. Built-in Rechargeable Battery
10. Microphone
11. Charging Socket
12. Earpiece

Getting Started
To use your MyVoice 307 Bluetooth headset ("headset"), please follow the steps below.
1. Ensure your headset is fully charged.
2. Pair your charged headset with a Bluetooth-enabled mobile phone.
Charging Your Headset
The headset comes with a built-in rechargeable battery. Prior to using the headset for the first time, it is recommended to fully charge the battery. Insert the charger's plug into the headset's USB charging socket and plug the mains charger to an AC wall outlet or plug to the PC notebook.

Charging Your Headset (cont'd)
Use only the supplied charger / USB charging cable to charge the headset.

Indicator Light
Headset Status
Charging
Fully charged
Low battery
Out of battery
Out of Range
Charging indication will be delayed for a few seconds if the headset has not been used for a long time or the battery is drained.
3 hours are required to fully charge the headset.

Talk and Standby Time
A fully charged battery can offer up to 5 hours of talk time and up to 140 hours of standby time. The headset remains in standby mode after being turned on.
Pairing Your Headset with a Bluetooth Mobile Phone
1) Ensure the headset is off.
2) To activate the pairing mode, press and hold the headset's MFB without releasing your finger until its status indicator showed long blue.
3) Activate your mobile phone's Bluetooth, search Bluetooth devices, select "OTE 307" and enter the passcode "0000". When the pairing is completed, the headset's status indicator will flash blue light rapidly five times.

Pairing Your Headset with a Bluetooth Mobile Phone (cont'd)
If the pairing cannot be completed within two minutes after the pairing mode has been activated, the headset's status indicator will stay blue five seconds and then turns to standby mode. Repeat steps 1 to 3 to pair the devices again.
Using Your Headset
Function Button Audio Status Indicator
Power Off Press and hold the MFB for 2 seconds a long beep Blue light for two seconds and then the light goes off
Incoming call Press the MFB once Ringtone on earpiece Quick flashing blue light
Answer a call Press the MFB once Flashing blue light
End a call Press the MFB once Flashing blue light
Adjust Volume Press the Volume Key once to increase/decrease by 1 step (Total 6 levels) Flashing blue light
Voice Dialing\* Press the MFB once a short beep Flashing blue light

Using Your Headset (cont'd)
Function Button Audio Status Indicator
Say the voice tag as soon as you hear the short beep and you must have recorded the voice tag into your mobile phone.
Last no Redial\* Press and hold the MFB for 2 seconds a short beep Flashing blue light
Reject a call\* Double click the MFB while speaking, press and hold the volume key for 2 seconds Flashing blue light
Call Transfer (headset to mobile phone)\* While speaking, press and hold the volume key for 2 seconds Flashing blue light
Call Transfer (mobile phone to headset)\* While speaking, press MFB once Flashing blue light

Using Your Headset (cont'd)
Function Button Audio Status Indicator
Say the voice tag as soon as you hear the short beep and you must have recorded the voice tag into your mobile phone.
Last no Redial\* Press and hold the MFB for 2 seconds a short beep Flashing blue light
Reject a call\* Double click the MFB while speaking, press and hold the volume key for 2 seconds Flashing blue light
Call Transfer (headset to mobile phone)\* While speaking, press and hold the volume key for 2 seconds Flashing blue light
Call Transfer (mobile phone to headset)\* While speaking, press MFB once Flashing blue light

Factory Reset
You may reset the headset to its default settings. Resetting will also remove the pairing history of your headset with the mobile phone.
1. Hold the volume key and plug charging cable into the charging socket until earpiece will beep 2 times.
2. Release the volume key.
3. The headset is reset.
i.Tech Bluetooth headset is designed to work with Bluetooth devices. Due to large variability between different Bluetooth devices from different manufacturers, interoperability between the headset and all Bluetooth-enabled products is not guaranteed.

Troubleshooting
I can't hear crackling noise.
To receive the best audio quality, it is recommended to wear your headset on the same side of the body as your mobile phone.
I can't hear anything in my headset.
Ensure the headset is turned on and is properly charged.
Ensure the headset is properly paired with the mobile phone.
Make sure that the mobile phone is connected with the headset - if it does not connect, either refer to the mobile phone's Bluetooth menu or by pressing the MFB once (see "Using Your Headset" and "Pairing Your Headset with a Bluetooth Mobile Phone").
I can't connect my headset with my mobile phone.
Ensure your headset is turned off and is properly charged.
Ensure the headset is properly paired with your mobile phone.

Troubleshooting (cont'd)
Ensure your mobile phone's Bluetooth feature is activated. Please refer to your mobile phone user guide for specific instruction.
Ensure the headset is within ten metres range of your mobile phone and there are no obstructions, such as walls or other electronic devices in between.
If the above steps do not solve your problem, please recharge the headset and remove your mobile phone's battery for a while.
I can't turn off the headset or the headset does not respond.
You may do a "hardware reset" on your headset if you can't turn it off or it doesn't respond.
Plug charging cable into the charging socket, the headset is reset

Safety Information
Check and observe local laws regarding the use of a mobile phone and a headset while driving. If you use the headset while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.
Never leave your headset above any air bag deployment area inside your car as serious injury may result when an air bag deploys.
Never allow children to play with the headset - small parts may be of choking hazard.
Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
Turn off your headset prior to boarding an aircraft. Do not use your headset inside an aircraft.

Safety Information (cont'd)
To prevent damage to your hearing, please do not set the listening volume too high.
Do not attempt to modify the headset.
Do not keep the headset near a wash basin or other wet places.
Do not use the headset outdoors in the rain.
Do not use the headset in stormy weather.
Do not clean the headset while it is being charged. Always disconnect the charger from the headset before cleaning.
Do not attempt to force open the built-in battery.
Only charge the headset's built-in battery in accordance with the instructions described in this user guide.

FCC RF Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Care and Maintenance
Headset
Turn off your headset before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile phone may place an unintended call.
Do not expose the headset to liquid, moisture or humidity, or rain as it is not waterproof.
Do not use abrasive cleaners to clean the headset.

Care and Maintenance (cont'd)
Do not expose the headset to extremely high or low temperatures.
Do not leave the headset in direct sunlight for an extended period of time.
Do not leave the headset near open flames such as cooking burners.
Do not dispose of the headset in a fire, as it will result in explosion.
Do not bring the headset into contact with any sharp objects, as this will cause scratches and damages.
Do not stick anything inside the headset, as this may damage internal components.
Do not attempt to disassemble the headset as it does not contain serviceable components.
If you do not plan to use the headset for a long period, please store it in a dry place that is free from extreme temperatures and dust.
Avoid charging the headset in extremely high or low temperatures.

Care and Maintenance (cont'd)
Dispose of the battery and the headset according to local regulations. Do not dispose of them as household waste.
Built-in Battery
Do not attempt to replace the headset's battery as it is in-built and is not changeable.
Dispose of the battery according to local regulations. Do not dispose of the battery as household waste.
Change the battery in accordance with the instructions supplied with this user guide.
Charger
Use only the charger supplied by the headset's original manufacturer to charge the headset. Other chargers may look similar but using them could be dangerous and could damage the headset.

Care and Maintenance (cont'd)
Do not attempt to disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.
Do not use the charger outdoors or in damp areas.
Declaration of Conformity
We, i.Tech Dynamic Limited, declare that the following product: Product Name: i.Tech MyVoice 307 Model No.: CS1-B307-XX is in conformity with the following essential requirements of Council Directive 1999/5/EC (referred to as R&TE Directive), Article 3.1.a, 3.1.b and 3.2., and the product is manufactured in accordance with Annex I of the above directive. A copy of the Declaration of Conformity can be found at http://www.itechdynamic.com.

Notes on Environmental Protection
After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collection points that are set up for this purpose or designated points of sale. However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

Federal Communications Commission (FCC) Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
15.121
You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.
15.105(b)
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to

Federal Communications Commission (FCC) Statement (cont'd)
provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

©2009 Hutchison Harbour Ring Enterprises Limited
All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. The contents of this publication are believed to be correct at the time of going to press. But any information, specifications, products or services mentioned, and product I.D. shown may be modified, supplemented or withdrawn without further notice. The Stylized i.Tech logos are trademarks owned by Hutchison Harbour Ring Enterprises Limited or its affiliates. All other trademarks or registered trademarks belong to their respective owners.
Bluetooth CE FC
Dispose of the packaging and this product in accordance with the latest provisions.
http://www.itechdynamic.com Printed in China 06/2009

MyVoice 307 藍芽耳機
用戶指南
Bluetooth

目錄
產品規格 ..... 27
藍芽規格 ..... v2.0 + EDR第2類
支援藍芽模式 ..... 耳機和免提
發音範圍 ..... 2.4 GHz
靜音充電 ..... 29-31
將耳機與藍芽流動電話配接 ..... 32
使用耳機 ..... 33-34
雙語拆解 ..... 35-37
安全指引 ..... 37-39
護理及保養 ..... 40-42
符合規條聲明 ..... 43

產品規格
藍芽規格: v2.0 + EDR第2類
支援藍芽模式: 耳機和免提
發音範圍: 2.4 GHz
靜音充電: 29-31
將耳機與藍芽流動電話配接: 32
使用耳機: 33-34
雙語拆解: 35-37
安全指引: 37-39
護理及保養: 40-42
符合規條聲明: 43
\*上述數據可能因應用戶習慣、不同的操作模式和流動電話設定而有所差異。

MyVoice 307 綜觀
1. 多功能按鈕 (MFB)
2. 電源開/關
3. 與流動電話配接
4. 接聽/結束通話
5. 最後來電重撥
6. 語音撥號
7. 調整音量
8. 拒接來電/轉駁來電
9. 內置可再充電電池
10. 麥克風
11. 充電器插座
12. 揚聲器

啓動
請根據以下步驟，操作MyVoice 307藍芽耳機(以下簡稱“耳機”)：
1. 確保您的耳機已完全充電
2. 將已充電的耳機配接至已經啟動藍芽的流動電話。
替耳機充電
耳機內置可再充電電池。在第一次使用耳機前，建議先為耳機完全充電。
將充電器插頭插入耳機的充電插座(見圖2)，然後將充電器連接至交流電源插座或個人電腦/手提電腦之中。

為耳機進行充電
圖1
圖2
只能使用包裝盒內提供的充電器 / USB充電線為耳機充電。

指示燈
耳機狀態
正在充電
完全充電
電池低
電池已耗盡
沒有訊號
狀態指示燈(圖1)
藍燈長期亮起
指示燈熄滅
閃動藍色2次
指示燈熄滅
每15秒閃動藍色4次，直接耳機重新配接，10分鐘後自己熄滅
若您長時間沒有使用耳機或電池已經耗盡，指示燈將延遲數秒發亮。
完全充電需時3小時。

將耳機與藍芽流動電話配接
1) 確保耳機已關閉。
2) 如果要啟動配接模式，請按住耳機的MFB按鈕，直至狀態指示燈顯示藍色。
3) 啟動流動電話的藍芽功能，搜尋藍芽設備，然後選擇“OTE 307”，並輸入密碼“0000”。當配接完成后，耳機的狀態指示燈會快速閃動藍灯5次。
當配接模式啟動後，若在2分鐘內未能完成配接過程，耳機的狀態指示燈會保持藍色5秒，然後轉為備用狀態。重覆1-3的步驟，再次完成配接。

使用耳機
功能 按鈕 音頻 狀態指示燈
啟動電源 持續按下MFB 一下短嗶聲 閃動藍色3次
當首次啟動耳機，耳機會進入配接模式，即狀態指示燈會閃亮綠色，你便可立即將耳機與流動電話進行配接
關閉電源 持續按下MFB 2秒 一下長嗶聲 閃動藍色2秒，然後熄滅
拒接來電\* 持續按下音量鍵2秒 一下短嗶聲 閃動藍色
來電轉駁(耳機至流動電話) 按下MFB一次 耳機响起轉音 快速閃動藍色
來電轉駁(手機至耳機) 按下MFB一次 通話時持續按下音量鍵2秒 閃動藍色
結束通話 按下MFB一次 通話時持續按下MFB 一次 閃動藍色
調整音量 按下音量鍵一次以增加/減少音量一級(共6級) 閃動藍色

使用耳機
功能 按鈕 音頻 狀態指示燈
語音撥號\* 按下MFB一次 一下短嗶聲 閃動藍色
當聽到短的嗶聲時，請說出語音標籤，您必需在您的流動電話錄下語音標籤。
最後來電重撥\* 按下MFB兩次 閃動藍色
拒接來電\* 持續按下音量鍵2秒 一下短嗶聲 閃動藍色
來電轉駁(耳機至流動電話) 按下MFB一次 通話時持續按下音量鍵2秒 閃動藍色
來電轉駁(手機至耳機) 按下MFB一次 通話時持續按下MFB一次 閃動藍色
\* 視乎流動電話支援而定

重設至出廠設定
您可以將耳機重設至出廠設定。重設期間亦會刪除耳機與流動電話的配接記錄。
1. 按住音量按鈕，並將充電線纜插入充電插座，直至耳機發出兩下嗶聲。
2. 放音量鍵。
3. 耳機已重設。
i.Tech藍芽耳機專為藍芽器材而設計。但因各生產商的藍芽器材設計存在一定差異，我們不能保證耳機與所有使用藍芽技術啟動的產品相兼容。

疑難排解
我的耳機沒有聲音
請確保耳機已啟動並完全充電。
請確保耳機與流動電話妥善配接。
請確保耳機與流動電話妥善地連接 - 如未能連接，請參照流動電話的藍芽菜單，或按MFB一次。(請參閱「使用耳機」及「將耳機與藍芽流動電話配接」一節)
耳機與流動電話不能連接
請確保耳機已關閉並適當充電。
請確保耳機與流動電話適當配接。
請確保流動電話的藍芽裝置已被啟用。詳細操作說明請參考流動電話用戶使用說明。

疑難排解
請確保耳機位於流動電話的10米範圍之內，而當中並沒有任何障礙物，例如牆壁或其它電子器材等。
如上步驟未能解決問題，請重新充電并把電池從手機取出一會。我不能關掉耳機或耳機沒有反應
如你不能關掉你的耳機或耳機沒有反應，可嘗試重新“設定耳機”。
將充電線纜插入充電插座，耳機現已重設。
安全指引
駕駛時請先查看當地有關使用流動電話及耳機的法例。使用本耳機時，必須保持集中，注意路面情況。為閣下安全着想，請小心駕駛。可考慮先把車輛停泊於路旁，再接聽或撥打電話。

安全指引
切勿把本耳機放在車內安全氣袋的位置上，因為當安全氣袋彈出時，可能會引致嚴重的傷害。
切勿讓兒童玩耍本耳機，細小的零件可能令兒童有窒息之危險。
醫院、爆炸地點或潛在爆炸環境的地方，可能會要求用戶关掉電子器材及無線電裝置。當進入特定範圍內時請留意有關指示。
登機前請先把耳機關掉，在飛機內不可使用本耳機。
為閣下聽覺着想，請勿把音量調得太。
切勿試圖對本耳機作出任何修改。
切勿把本耳機放置在洗手盆或其它潮濕的地方。
切勿在雨中或使用本耳機。
切勿在颶風時使用本耳機。

安全指引
當處於充電狀態時，請勿清潔本耳機。應先把耳機及充電器分開，再進行清理。
切勿強行打開本耳機的內置電池。
根據交通部低功率電波輻射性電機管理辦法規定：
第十二條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。
切勿使用具危險性的清潔劑清理耳機。
切勿將耳機暴露在溫度過高或過低的地方。

FCC RF 輻射暴露聲明：
本器材符合在不受控制環境下的FCC輻射暴露限制。最終用戶必須跟從特定的操作指引以符合RF暴露的要求。傳送器不能與任何天線或發射器共同放置。
護理及保養
耳機
將耳機放進口袋或手提袋前，請先關閉耳機。如果誤按多功能按鈕，您的手機可能會意外撥號。
因為耳機是不防水的，切勿讓耳機接觸液體，水分，瀉氣或雨水。
切勿使用具磨損性的清潔劑清理耳機。
切勿將耳機暴露在溫度過高或過低的地方。

護理及保養
切勿讓耳機長時間受陽光直射照射。
切勿讓耳機靠近明火，如香燭。
切勿棄置耳機於火中，因為這將導致爆炸。
切勿讓耳機接觸到任何尖銳的物體，因為這會造成劃痕和損毀。
切勿在耳機內戳刺任何物品，因為這可能會損害內部零件。
切勿嘗試拆解耳機，因為它並不包含任何維修組件。
如果長時間內不打算使用耳機，請將它儲存在乾燥的地方，避免極端的溫度和濕度。
請根據地方法規棄置電池和耳機。不要將它當作家庭廢物般棄置。

護理及保養
內置電池
切勿嘗試更換耳機的電池，因為它是內置的，且不能更換。
請根據地方法規棄置電池。不要將它當作家居廢物般棄置。
請按照本用戶指南附有的指示替電池充電。
充電器
請使用耳機製造商提供的原裝充電器，使用其它品牌的充電器可能會損毀耳機，甚至構成危險。
由於在拆解充電器時可能會接觸到高壓電流或構成其它危險，請勿嘗試拆解充電器。使用不正確組裝的充電器會引致觸電危險。
請勿在戶外或潮濕地方使用充電器。

符合規條聲明
i.Tech Dynamic Limited 在此聲明以下產品符合無線通訊設備指令 1999/5/EC所有重要規定(參照R&TE 指令)：項目3.1a, 3.1b及3.2。
產品名稱：i.Tech MyVoice 307
型號：CS1-B307-XX
此產品並根據上述指令中附錄II生產。
如希望獲取符合無線通訊設備指令之聲明文件之副本，請上網站 http://www.itechdynamic.com。

有關環保注意事項
自從在國家法律體系中實施歐盟指令2002/96/EU後，以下措施開始應用電器及電子產品不能作一般家居廢物處理。如在電器產品壽命終結時，消費者將根據法例規定，將產品棄置于特定的公共收集點或銷售點作回收用途，但細節須由相關國家的國家法律所定義。產品、說明書或包裝上的標誌，說明這類產品是受到這些法例的規定，循環使用或再用這些物料或使用其它形式的器材，將對環境保護有重大貢獻。

聯邦通訊委員會(FCC)聲明
本器材符合FCC條例第15節的要求。操作要視乎以下兩個條件：(1) 本器材可能不會產生有害的幹擾，以及(2) 本器材必須接受任何收到的幹擾，包括可能引起本器材的幹擾。
我們建議你將耳機戴在与手机的同一边，以达到最佳的接收效果。
我的耳机没有声音
请确保耳机已启动并完全充电。
请确保耳机与手机妥善配接。
请确保耳机与手机妥善地连接 - 如未能连接，请参照手机的蓝牙菜单，或按MFB一次。(请参阅「使用耳机」及「将你的耳机与手机配接」一节)
耳机与手机不能连接
请确保耳机已关闭并适当充电。

聯邦通訊委員會(FCC)聲明
這些限制特別設計，可以提供合理的保護以防止在家居安裝時出現的有害幹擾。本器材能產生、使用和放射無線電頻率能量。若未根據指示進行安裝和使用，可能對無線通訊作出有害的幹擾。但是，我們不能保證配接會在某一安裝地點發生。若本器材真的對收音機或電視接收造成有害幹擾，用戶可將器材開關和關閉以決定這些是否幹擾的來源。我們建議閣下可嘗試下列一種或多種的方法以減少幹擾的程度：
- 重新轉動或撥放天線位置
- 增加本器材與接收器的距離
- 將本器材插進與接收器不同的其它電源插座
- 請查詢零售商或具經驗的轉機/電器維修員尋求協助

請根據最新的條列圖本包裝和產品。
http://www.itechdynamic.com
中國印製 06/2009
Bluetooth CE FC

MyVoice 307 蓝牙耳机
用戶指南
Bluetooth

目錄
產品規格 ..... 50
藍芽規格: v2.0 + EDR第2類
支持藍芽模式: 耳机和免提
發音範圍: 2.4 GHz
靜音充電: 29-31
將耳機與藍芽流動電話配接: 32
使用耳機: 33-34
雙語拆解: 35-37
安全指引: 37-39
護理及保養: 40-42
符合規條聲明: 43

產品規格
藍芽規格: v2.0 + EDR第2類
支持藍芽模式: 耳机和免提
發音範圍: 2.4 GHz
靜音充電: 29-31
將耳機與藍芽流動電話配接: 32
使用耳機: 33-34
雙語拆解: 35-37
安全指引: 37-39
護理及保養: 40-42
符合規條聲明: 43
\*上述數據可能因應用戶習慣、不同的操作模式和流動電話設定而有所差異。

MyVoice 307 綜觀
1. 多功能按鈕 (MFB)
2. 電源開/關
3. 與流動電話配接
4. 接聽/結束通話
5. 最後來電重撥
6. 語音撥號
7. 調整音量
8. 拒接來電/轉駁來電
9. 內置可再充電電池
10. 麥克風
11. 充電器插座
12. 揚聲器

啓動
請根據以下步驟，操作MyVoice 307藍芽耳機(以下簡稱“耳機”)：
1. 確保您的耳機已完全充電
2. 將已充電的耳機配接至已經啟動藍芽的手機。
替耳機充電
耳機內置可再充電電池。在第一次使用耳機前，建議先為耳機完全充電。
將充電器插頭插入耳機的充電插座(見圖2)，然後將充電器連接至交流電源插座或個人電腦/手提電腦之中。

為耳機進行充電
圖1
圖2
只能使用包裝盒內提供的充電器 / USB充電線為耳機充電。

指示燈
耳機狀態
正在充電
完全充電
電池低
電池已耗盡
沒有訊號
狀態指示燈(圖1)
藍燈長期亮起
指示燈熄滅
閃動藍色2次
指示燈熄滅
每15秒閃動藍色4次，直接耳機重新配接，10分鐘後自己熄滅
若您長時間沒有使用耳機或電池已經耗盡，指示燈將延遲數秒發亮。
完全充電需時3小時。

將耳機與藍芽手機配接
1) 確保耳機已關閉。
2) 如果要啟動配接模式，請按住耳機的MFB按鈕，直至狀態指示燈顯示藍色。
3) 啟動流動電話的藍芽功能，搜尋藍芽設備，然後選擇“OTE 307”，並輸入密碼“0000”。當配接完成后，耳機的狀態指示燈會快速閃動藍灯5次。
當配接模式啟動後，若在2分鐘內未能完成配接過程，耳機的狀態指示燈會保持藍色5秒，然後轉為備用狀態。重覆1-3的步驟，再次完成配接。

使用耳機
功能 按鈕 音頻 狀態指示燈
啟動電源 持續按下MFB 一下短嗶聲 閃動藍色3次
當首次啟動耳機，耳機會進入配接模式，即狀態指示燈會閃亮綠色，你便可立即將耳機與手機進行配接
關閉電源 持續按下MFB 2秒 一下長嗶聲 閃動藍色2秒，然後熄滅
拒接來電\* 持續按下音量鍵2秒 一下短嗶聲 閃動藍色
來電轉駁(耳機至手機) 按下MFB一次 耳機响起轉音 快速閃動藍色
來電轉駁(手機至耳機) 按下MFB一次 通話時持續按下音量鍵2秒 閃動藍色
結束通話 按下MFB一次 通話時持續按下MFB一次 閃動藍色
調整音量 按下音量鍵一次以增加/減少音量一級(共6級) 閃動藍色

使用耳機
功能 按鈕 音頻 狀態指示燈
語音撥號\* 按下MFB一次 一下短嗶聲 閃動藍色
當聽到短的嗶聲時，請說出語音標籤，您必需在您的手機錄下語音標籤。
最後來電重撥\* 按下MFB兩次 閃動藍色
拒接來電\* 持續按下音量鍵2秒 一下短嗶聲 閃動藍色
來電轉駁(手機至手機) 按下MFB一次 通話時持續按下音量鍵2秒 閃動藍色
來電轉駁(手機至手機) 按下MFB一次 通話時持續按下MFB一次 閃動藍色
\* 視乎手機支持而定

重設至出廠設定
你可以將耳機重設至出廠設定。重設期間亦會刪除耳機與手機的配接記錄。
1. 按住音量按鈕，並將充電線纜插入充電插座，直至耳機發出兩下嗶聲。
2. 放音量鍵。
3. 耳機現已重設。
i.Tech藍芽耳機專為藍芽器材而設計。但因各生產商的藍芽器材設計存在一定差異，我們不能保證耳機與所有使用藍芽技術啟動的產品相兼容。

疑難排解
我听到「咔咔」的声响。
我们建议你將耳機戴在与手机的同一边，以达到最佳的接收效果。
我的耳机没有声音
请确保耳机已启动并完全充电。
请确保耳机与手机妥善配接。
请确保耳机与手机妥善地连接 - 如未能连接，请参照手机的蓝牙菜单，或按MFB一次。(请参阅「使用耳机」及「将你的耳机与手机配接」一节)
耳机与手机不能连接
请确保耳机已关闭并适当充电。

疑難排解
駕駛時請先查看當地有關使用手機及耳機的法例。使用本耳機時，必須保持集中，注意路面情況。為閣下安全着想，請小心駕駛。可考慮先把車輛停泊於路旁，再接聽或撥打電話。
切勿把本耳機放在車內安全氣袋的位置上，因為當安全氣袋彈出時，可能會引致嚴重的傷害。
切勿讓兒童玩耍本耳機，細小的零件可能令兒童有窒息之危險。
醫院、爆炸地點或潛在爆炸環境的地方，可能會要求用戶关掉電子器材及無線電裝置。當進入特定範圍內時請留意有關指示。
登機前請先把耳機關掉，在飛機內不可使用本耳機。
為閣下聽覺着想，請勿把音量調得太。
切勿試圖對本耳機作出任何修改。

安全指引
將耳機放進口袋或手提袋前，請先關閉耳機。如果誤按多功能按鈕，您的手機可能會意外撥號。
因為耳機是不防水的，切勿讓耳機接觸液體，水分，瀉氣或雨水。
切勿使用具磨損性的清潔劑清理耳機。
切勿將耳機暴露在溫度過高或過低的地方。

安全指引
切勿把本耳機放置在洗手盆或其它潮濕的地方。
切勿在雨中或使用本耳機。
切勿在台风时使用本耳机。
當處於充電狀態時，請勿清潔本耳機。應先把耳机及充电器分开，再进行清理。
切勿強行打开本耳机的内置电池。