




i.Tech MusicClip 803 Bluetooth Headset User Guide



\* For optimized performance, please use a "3-pole" 3.5mm jack stereo headphones

Table with 4 columns: Function, Button, OLED Display, Status indicator. Includes rows for Last no. Redial, Reject incoming call, Eot Miss call, Call Waiting, Change Ringtone.

Table with 4 columns: Function, Button, OLED Display, Status indicator. Includes rows for Enter FM Music mode, Scan Station, Fine Tune Frequency, Mute Radio, Resume Music Radio.

Care and Maintenance
Headset
• The provided stereo headphones is a complementary item, it is NOT covered under warranty.
• Turn off your headset before placing it in your pocket or bag.



i.Tech MusicClip 803 藍芽耳機 用戶指南



啓動
請根據以下步驟，操作 MusicClip 803藍芽耳機（以下簡稱「耳機」）：
1. 確保您的耳機已完全充電。




Table with 4 columns: 功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 轉換鈴聲, 啟動/取消隨機播放, 進入數據庫, 選擇數據庫, 確認數據庫, 播放, 暫停, 下一首曲目.

Table of Contents
English ..... 2-24
繁體中文 ..... 25-48
简体中文 ..... 49-72

Getting Started
To use your MusicClip 803 Bluetooth headset ("headset"), please follow the steps below:
1. Ensure your headset is fully charged.
2. Pair your charged headset with a Bluetooth-enabled mobile phone.

Table with 4 columns: Function, Button, OLED Display, Status indicator. Includes rows for Shuffle On / Off, Enter Folder Selection, Select Folder, Confirm Folder, Play, Pause, Next Track.

Resetting Your Headset
In case your headset is not functioning or not respond to any key pressed, following the instructions below to reset it:
1. Use a small pinpoint object to press on the RESET hole on the headset.

Care and Maintenance (Cont'd)
Built-in Battery
• Do not attempt to replace the headset's battery as it is in-built and is not changeable.
• Dispose of the battery according to local regulations.

目錄
產品規格 ..... 27-28
MusicClip 803瞭解 ..... 29
啟動 ..... 30
替耳機充電 ..... 30
將耳機與藍芽流動電話配接 ..... 32-33
使用耳機 ..... 33-39
電話功能 ..... 33
MP3音樂功能 ..... 35
A2DP音樂功能 ..... 37
FM收音機 ..... 38
存取及播帶數據檔案 ..... 39
重設耳機 ..... 40
疑難排解 ..... 40-42
安全警語 ..... 42-43
護理及保養 ..... 44-45
符合規格聲明 ..... 46

替耳機充電 (續)
指示燈
耳機狀態 狀態指示燈
• 備用
• 電量低
• 電池已耗盡
• 充電中
• 完全充電
• 沒有訊號

Table with 4 columns: 功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 上一首曲目, 向前快速歌曲, 向後快速歌曲, 啟動/取消FM收音機, 確認數據庫, 播放, 暫停, 下一首曲目.

Table of Contents
Product Specifications ..... 3-4
Clip Music 803 Overview ..... 5
Getting Started ..... 6
Change Your Headset ..... 6
Indicator Light ..... 7
Pairing Your Headset with a Bluetooth Mobile Phone ..... 8-9
Using Your Headset ..... 9-15
Phone Calls ..... 9
MP3 Music enjoyment ..... 11
A2DP Music enjoyment ..... 13
FM Radio enjoyment ..... 14
Store and Carry Data Files ..... 15
Resetting Your Headset ..... 16
Troubleshooting ..... 16-18
Safety Information ..... 18-19
Care and Maintenance ..... 20-21
Declaration of Conformity ..... 22

Charging Your Headset (Cont'd)
Indicator Light
Headset Status Status Indicator Light
• Standby
• Low battery
• Out of battery
• Charging
• Fully charged
• Out of Range

Table with 4 columns: Function, Button, OLED Display, Status indicator. Includes rows for Shuffle On / Off, Enter Folder Selection, Select Folder, Confirm Folder, Play, Pause, Next Track.

Troubleshooting (Cont'd)
• Make sure that the mobile phone is connected with the headset - if it does not connect, either refer to the mobile phone's Bluetooth menu or by pressing the MFB once (see "Using your headset" and "Pairing Your Headset with a Bluetooth Mobile Phone").

Declaration of Conformity
We, i.Tech Dynamic Limited, declare that the following product:
Product Name: i.Tech MusicClip 803
Model No.: CS1-8033-XX
is in conformity with the following essential requirements of Council Directive 1999/5/EC (referred to as R&TE Directive): Article 3.1.a, 3.1.b and 3.2. and the product is manufactured in accordance with Annex II of the above directive.

Table with 2 columns: 藍芽規格, 藍芽規範支援, 頻率範圍, 額定充電時間, FM頻率, 顯示屏, 通話時間, A2DP音樂串流時間, 備用時間, MP3音樂播放時間, 支援音樂系統, 閃存, 尺寸, 重量

將耳機與藍芽流動電話配接
1) 確保耳機已關閉。
2) 如果要啟動配接模式，請持續按下手機的MFB按鈕5秒，直至指示燈閃動藍色和OLED顯示屏會顯示 "Pairing" 圖標。

Table with 4 columns: 功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 上一首曲目, 向前快速歌曲, 向後快速歌曲, 啟動/取消FM收音機, 確認數據庫, 播放, 暫停, 下一首曲目.

Table with 2 columns: Bluetooth Specification, Bluetooth Profiles Supported, Range of Frequency, Nominal Charging Time, FM Frequency, Display, Talk Time, A2DP Music Streaming Time, Standby Time, MP3 Music Playing Time, Support Music Format, Flash Memory, Dimension, Weight

Pairing Your Headset with a Bluetooth Mobile Phone
1) Ensure the headset is off.
2) To activate the pairing mode, press and hold the headset's MFB for 5 seconds without releasing your finger until its status indicator blinking blue and the OLED display show "Pairing" icon.

Table with 4 columns: Function, Button, OLED Display, Status indicator. Includes rows for Previous Track, Fast Forward Song, Fast Backward Song, Enable / disable EO, A2DP Music enjoyment, Enter A2DP Music mode.

Troubleshooting (Cont'd)
The PC does not connect the device.
• Make sure to connect the headset to PC with the provided USB cable only.
• Check whether the USB cable is firmly attached to both the headset and the PC.

Federal Communications Commission (FCC) Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Table with 4 columns: 最低系統要求, Windows® 2000, XP, Vista, Pentium III 800 MHz處理器或更高版本, 128 MB RAM, 500 MB 硬盤空間, 互聯網連接 Microsoft® Internet Explorer 6.0 或更高版本, Sound card (聲效卡), USB埠

Table with 4 columns: 電話功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 關閉電源, 來電, 接聽/結束通話, 調整音量

Table with 4 columns: 功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 連接成功, 連接失敗, 播放, 暫停, 下一首曲目, 上一首曲目

Table with 2 columns: Minimum System Requirement, Windows® 2000, XP/Vista, Pentium III 800 MHz processor or higher, 128 MB RAM, 500 MB hard disk space, Internet connection Microsoft® Internet Explorer 6.0 or later, Sound card, USB port

Table with 4 columns: PHONE CALL, Function, Button, OLED Display, Status indicator. Includes rows for POWER ON, PAIRING, POWER OFF, Incoming call, Answer / End a call, Adjust Volume

Table with 4 columns: Function, Button, OLED Display, Status indicator. Includes rows for Connection Success, Connection Fail, Play, Pause, Next Track, Previous Track

Safety Information
• Turn off your headset prior to boarding an aircraft. Do not use your headset inside an aircraft.
• To prevent damage to your hearing, please do not set the listening volume too high.

FCC RF Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.




Table with 4 columns: 功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 最後來電重撥, 拒接來電, 退出未接來電畫面, 來電時接聽您保留現有通話, 拒接來電, 退出未接來電畫面

Table with 4 columns: 功能, 按鈕, OLED顯示屏, 狀態指示燈. Includes rows for 進入FM音樂模式, 轉檔電臺, 微調頻率, 收音機靜音, 恢復靜音收音機, 儲存及攜帶數據檔案