

iShower²



User Manual V1- 8/29/14

Table of Contents

1. In the Box.....	2
--------------------	---

2. Getting Started	2
2.1 Battery Replacement	2
2.2 Power On & Off	3
2.3 Pairing.....	3
2.4 Mount Installation	4
2.5 Mount Removal.....	4
3. Using the iShower ²	4
3.1 Navigating between users.....	4
3.2 Overriding Users	5
3.3 Play/Pause/Forward/Back	5
3.4 Clock	5
3.5 Calls.....	6
3.6 Reset.....	6
4. Problem Solving.....	6
5. Disclaimer	7
6. Regulations.....	7

1. In the Box

- 1 iShower²
- 1 Mount and Adhesive
- 3 AA Batteries

2. Getting Started

2.1 Battery Replacement

To replace your iShower² batteries, follow these steps:

- Lift the iShower² Standing Mount
- Rotate the iShower² door lock from the lock to the unlock position
- Remove the battery door panel from the left side
- Replace with 3 AA batteries
- Ensure the batteries are in place and replace the battery door and move the iShower²

2.2 Power On & Off

To power on the iShower²:

- Press and hold the power button for 2 seconds until the display reads "HI". You will see the iShower² logo blinking.

To power off the iShower²:

- Press and hold the power button until the display reads "BYE".

2.3 Pairing

To Pair your iShower² to your iPhone, iPad, iPod touch or Android device for the first time follow these steps:

- Go to your device settings and turn Bluetooth on. For specific questions on how to pair with your device, please refer to the manual that comes with your device.
- Power On the iShower²
- Hold the Bluetooth/Pair button for 5 seconds on the iShower² to enter Setup Mode. In Set up Mode, the screen will display USE1 Open.
- Press the Play/Pause button to select USE1. The iShower² will try to pair for 30seconds. You are now ready to pair with your device.
- Select iShower² in your Bluetooth settings. Your device will now complete the pair with the iShower².
- Once connection is has been made, the iShower² logo will stop blinking and turn solid.

Note: On iPhone, iPad and iPod touch devices the iShower² will send a pairing request that must be accepted by the user. On most Android devices the iShower² will pair once it is tapped on in your Bluetooth settings.

To connect additional iShower² users (up to 5) follow these steps:

- Go to your device settings and turn Bluetooth on. For specific questions on how to pair with your device, please refer to the manual that comes with your device.
- Power On the iShower²

- Hold the Bluetooth/Pair button for 5 seconds on the iShower² to enter Setup Mode.
- Use the forward and back buttons to select the proper USE#.
- Press the Play/Pause button to select the displayed user for setup. The iShower² will try to pair for 30 seconds.
- Select iShower² in your Bluetooth settings. Your device will now complete the pair with the iShower².
- Once the connection has been made, the iShower² logo will stop blinking and turn solid blue.

2.4 Mount Installation

- Peel off protective cover on back of the mount.
- Clean and dry the surface you are attaching the mount to.
- Place mount at desired location and press firmly.

2.5 Mount Removal

Wear safety glasses while removing the mount

- Insert a putty knife blade (or similar tool) between the mount and the wall. While gently pulling, use the blade to break the bond between the wall and the mount. The adhesive is not reusable.

Note: Be sure the tool you use will not damage the wall.

3. Using the iShower²

3.1 Navigating between users

To navigate between different users on your iShower² follow these steps:

- Press Bluetooth/Pair button, this will enter User Select Mode. The iShower² will display the last user connected.
- Use forward and back buttons to select USE#. The iShower² will only display users that are paired.
- Press Play/Pause to select user. If a user is in range and Bluetooth is on, the iShower² will connect and begin playing audio. If the iShower² does not connect, it will display USE# Fail. Make sure your device is within range, on and ready for Bluetooth. Repeat steps to attempt connection.

3.2 Overriding Users

To override users on the iShower² follow these steps:

- Choose Selected Use# which you wish to override.
- Hold the Bluetooth/Pair button for 5 seconds.
- Press the Play/Pause button. The iShower² will try to pair for 30 seconds.
- Tap on the iShower² in your Bluetooth pairing list to pair the new user.

3.3 Play/Pause/Forward/Back

- To play tracks from your iShower² press the play button.
- To pause a track from your iShower² press the pause button.
- To skip to the next track on your iShower² press the forward button.
- To listen to a previous track press the back button.

3.4 Clock

The clock function allows you to get a quick glimpse of the current time on your iShower².

To set the clock on your iShower²:

- Hold the clock button until the display starts blinking the current set time.
- Use the Forward and Back buttons to adjust the desired time.

- Press the clock button to set time.

To Display Clock time:

- Press the clock button to display the time. The time will display for 5 seconds.

3.5 Calls

- To receive calls from your iShower² press the Backwards button.
- To ignore/end a call on your iShower² press the Forward button.

Note: You can only receive calls from the iShower².

3.6 Reset

- Hold the Play/Pause button and Bluetooth/Pair button at the same time for 10 seconds with the iShower² powered on.
- The iShower² will display "CLR Pair" 5 times, then power off.
- This will reset the iShower² to factory settings. All of your users saved will be erased.

Note: When trying to set up a previously paired Device with the iShower², you will need to select "forget this device" from your Bluetooth settings options in order to create a new, clean connection.

4. Problem Solving

The following information covers some of the most common questions with the iShower². If you need further assistance please review the iShower² FAQ page at <http://idevicesinc.com/support> or contact a member of our Customer Experience Team at support@idevicesinc.com

Q. Can the iShower² be submerged in water?

A. No. The iShower² is water resistant, not water proof

Q. Can I stream to multiple iShower²'s at once?

A. No, due to limitations with Bluetooth you are only able to stream to one iShower² at a time.

Q. How many users can pair with the iShower²?

A. You can pair up to 5 users per device

Q. What is the battery life?

A. The battery life is up to 15 hours.

Q. What is the Bluetooth range?

A. The Bluetooth range is up to 200ft.

Q. What happens if I walk out of range and lose my connection?

A. If you walk out of range and your connection is lost you must press the Bluetooth pairing button on the iShower² for 5 seconds to re-establish your connection when back in range. Once connected, press play to resume listening.

5. Disclaimer

The iShower² is not to be used by children or persons with reduced physical, sensory, mental capabilities or lack of experience and knowledge, unless they have been given instruction or supervision. Do not submerge the iShower² as it was built to be water-resistant, not waterproof. The iShower² requires 3 x AA batteries. Batteries included.

6. Regulations

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the distance between the equipment and the receiver
- Connect the equipment to outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/Tv technician for the help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada - Industry Canada (IC)

This device complies with Industry Canada license-exempt RSS Standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes:

(1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interference, y compris celles pouvant causer un mauvais fonctionnement de l'appereil