



### Online Setup Guide

Pairing instructions for Universal  
Smart Key

**Press to Continue**

## FCC STATEMENT

**MODEL: URSSA-G040**

**FCC ID: X32-URSSG040**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications to this device not expressly approved by (iKeyless LLC) could void the user's authority to operate the equipment.

## ISED REGULATORY STATEMENT

### MODEL: URSSA-G040 IC: 8797A-URSSG040

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**Year**

**Make**

**Model**

## **KEY PAIRING PROCESS:**

### **STEP 1 (of 2) KEY ACTIVATION**

**NOTE: Follow the steps below to ACTIVATE your new key. Once you have activated your key, follow STEP 2 (of 2) KEY PAIRING to pair the key to your vehicle.**

1. First, simultaneously press the LOCK and PANIC buttons on the remote. The light under the PANIC button will illuminate and stay on.
2. Using ACTIVATION CODE \_\_\_\_, enter the first digit using the LOCK button, the second digit using the PANIC button, and the third digit using the UNLOCK button.

3. Now, simultaneously press the LOCK and PANIC buttons on the remote.
  - a. The light will now blink back the ACTIVATION CODE you originally entered., with a pause between each digit. If this does not match, go back to Step 1 to start over.

### **3. Cont**

- b. If the light blinks rapidly this indicates an error. Go back to ACTIVATION step 1 and retry the steps using your ACTIVATION CODE.

NOTE: You may re-enter activation codes anytime before the key is paired to your vehicle. After the key is paired to your vehicle, do not attempt to re-enter or change the button code. This will cause the key to not work.

4. Move on to STEP 2 (of 2) below to PAIR the key to your vehicle.

## **KEY PAIRING PROCESS:**

### **STEP 2 (of 2) KEY PAIRING**

- 1. Go to [URL], following the instructions to download the app compatible with your device (Either through the Apple Store or Google Play Store), following the in-app instructions to complete your pairing process.**

**NOTE:** If at any point the **device** continues to beep rapidly, please refer to the FAQ section for more information.

## FAQ

Q: The EZ Installer beeps 8 times after pushing the button to initiate the pairing process and will not pair the new key.

A: Your vehicle allows a maximum of 8 paired keys. If the vehicle already has 8 keys paired to it, a new key cannot be paired. If the EZ Installer beeps 8 times early in the pairing process, this indicates that the maximum number of keys have been paired. Please contact Car Keys Express customer service at 888-598-8910.

Q: Can I use the same EZ Installer on other vehicles?

A: No, the EZ Installer will be locked to the first vehicle it is used on. You may add more keys to the same vehicle again as needed, but it will not work on different vehicles. If the EZ Installer sounds 2 beeps at 1 second intervals, then beeps rapidly, this signifies that the device has already been used on another

vehicle. Visit [CKESimpleKey.com](http://CKESimpleKey.com) or your local retailer to purchase additional keys.

Q: The EZ Installer sounds 2 or 3 beeps at 1 second intervals 3 times then beeps continuously.

A: When problems occur during the pairing process, EZ Installer will beep an error code, followed by continuous faster beeps. The number of error beeps correspond to specific error codes, explained below.

Two distinct beeps at 1 second intervals indicate the device has already been used on another vehicle. The EZ Installer can only pair Simple Keys to one vehicle. The EZ Installer will be locked to the first vehicle it is used on. You may add more keys to the same vehicle again as needed, but it will not work on different vehicles.

Three distinct beeps at 1 second intervals indicate the EZ Installer could not detect an original, existing key. Ensure an

existing, working key is present, remove the EZ Installer, and begin the pairing process again. Please contact Car Keys Express customer service at 888-598-8910 for any questions.

Q: The EZ Installer was unplugged during the pairing process.

A: The EZ Installer must remain plugged into the on-board diagnostic (OBD) port until pairing is complete. If the EZ Installer becomes unplugged during the pairing process, turn the ignition to the OFF position, remove the key, and begin the pairing process again.

Q: The vehicle won't start with the new key or old keys after attempting to pair.

A: Please call Car Keys Express customer service at 888-598-8910.