

Thank you for purchasing and using wireless bluetooth headset
This manual will help you how to use your bluetooth headset, before
using bluetooth headset, you must understand and be familiar with
bluetooth function of your manual or other bluetooth active devices
using bluetooth, such as computer bluetooth function.

Safety rules

- 1: in order to ensure safety Please abide by the rules, mentioned in this manual before using bluetooth headset, we strongly recommend that you read this manual.
- 2: please reasonable control volume and time when using headphones
- avoid headphones into the water, so as not to damage the timbre or headsets.
- 4: please don't dismantle the product maintenance that may cause a fire Electronic breakdown or damage to the product completely These are out of place in the warranty.
- 5: please do not wipe off the product oil and other volatile liquid.
- 6: please don't use this product in dangerous places.

The attachment list USB charging line bluetooth headset is 1 \* 1 \* 1 \* audio line








The general function

How to connect to: 1. Close the headset

Press and hold multifunction button for 5 seconds until the bluetooth indicator light flashing fast, red light blue light. Ear opportunity voice ring out into pairing mode.

3. Wearing headphones, according to the phonetic matching with



	Switch on/off the	Hold the multifunction button for 5
	phone	seconds, until the LED lights flashing
	Answer/hang up	Gently press multifunction button
	the phone	
	Decline a call	According to the multifunction button 2
		seconds refuses to long
	Replay the recent	Without talking to the multifunction
	call number	button
	Play/pause the music	Gently press a stir round switch
		The thumbwheel switches up for a song
	The volume on the	Don't put up for the volume
	add/song	Thumbwheel switches down for the next
	Small volume/the	song Don't put down for the volume
		reduction

# Bluetooth headset charging

- 1. Connect the charger to the outlet on the headset
- 2. During charging, the indicator light turn red
- 3. The headset when fully charged The red indicator light Unplug the charger from the outlet to the headphones.
- Repeat charging and discharging of headphones will decrease over time and cause the battery efficiency. It is normal for all rechargeable batteries.

prompt

Must choose normal manufacturer production certification of the charger

If the product don't (more than one year) for a long time, the charge, please

Matching models: BL - 17 A

The bluetooth specification: 4.2

Bluetooth protocol: HFP1.6 HSP1.2 AVRCP1.4 A2DP1. 2

Stereo audio: APTX

Communication distance: 10 meters

40 mm speaker impedance: the speaker impedance 32 euro

Standby time: about 300 hours

Playing time: 7 to 8 hours Charging time: 1-2 hours

Battery capacity: 300 ma 3.7 volts

Size (length \* width \* height):

Weight:

Ask and answer simple

1. Why can't my headphones on?

Answer: for the first time to use, to ensure the headset is full of electricity, without electricity, led to the headset can't boot up.

2. Play the headphone no sound?

A: check the playback devices with bluetooth headset is establishing effective connection, if not normal audio devices connected, please connect again. At the same time, adjust the phone or bluetooth headset volume to the volume level.

3. Mobile phone can't search the bluetooth headset?

A: please confirm whether the bluetooth is visible model (device), if long time not match, the bluetooth pairing function automatically shut down, please open the bluetooth again to visible model (device). If the cell phone application error, please restart the phone If bluetooth headset error please restart the headphones.

## Safety rules

- 1: please do not dismantle or modified for any reason at all headphones, otherwise may cause headset fails or burned, these are out of place in the warranty.
- 2: do not use the equipment in contact with liquid to wet, otherwise it will cause severe damage to equipment, the equipment and the water damage, the manufacturer will not warranty.
- 3: please do not put headphones in temperature too low or too high (0 °, 45 ° C below or above) environment.
  - 4: please avoid using equipment near children or animals eyes light.
- 5: do not use the equipment in thunderstorm weather. May lead to operation of the equipment and increase the risk of electric shock.

After-sales service and support

If you buy the product non-artificial damage problem, please go back to the dealer or our warranty.

Protect repair card

Warranty period:

The product quality guarantee period for: since the acquisition in December.

Free services:

During the warranty period, any belongs to the quality of the product itself caused as a result of the user with this warranty card and shopping card, please contact with dealers to enjoy free maintenance.

The following will not be free maintenance:

- 1: no warranty card or product maintenance label has been destroyed
  - 2: removed or drop caused by the faults and artificial damage
  - 3: the fault caused by water
  - 4: fault or damage is caused due to force majeure

## Customer service information

The customer name	
Contact phone number	
Contact address	
The product name	
The product name	
Product model	
Purchase date	
dealers	
Maintenance date	

Manufacturer: shenzhen jie bolang electronic co., LTD

Address: 9F, Building 5, Second Lane, First Industrial Park, Jiazitang, Guangming New District, Shenzhen City, Guangdong, China

Manufacturers call: 0755-29519556

#### § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### § 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### § 15.105 Information to the user.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

### \* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.