




kitsound.co.uk

All trademarks are acknowledged as the property of their respective owners. Unless otherwise stated their use does not imply that the trademark owner is affiliated with KitSound or endorses the products herein.

Your product and batteries must be recycled or disposed of properly. Please contact your local recycling centre for more information on proper disposal.



JB. 5359-b / Made in China. © KitSound™ 2017.
Christchurch, Dorset, BH23 4FL, UK



HAWAII 1.0 WIRELESS SPEAKER

USER MANUAL



Please read this manual carefully before use.

Box contents

- KS Hawaii wireless speaker
- Micro USB Charge cable
- User manual

Functions

1. LED input indicator
2. On/Off switch
3. Micro USB charging port
4. Aux-in port
5. LED charge indicator



IPX5 rating

The speaker is rated IPX5. This means it protects from water jets at any direction, but is not impervious to large amounts of water.

Please do not directly immerse in water.

Instructions for use

Charging the speaker

1. Connect the USB charging cable to the Micro USB charging port (3) and plug into power
2. The LED charge indicator (5) will be red whilst charging which will take up to 2 hours
3. Once fully charged the LED charge indicator (5) will turn off

Note: Allow up to 4 hours for the first charge.

Pairing the speaker to your device

1. Turn speaker on, and it will enter pairing mode, with the LED input indicator (1) flashing blue quickly
2. Turn your iOS, Android, or Windows device's Bluetooth ON and search for new devices
3. Select 'KS HAWAII 1.0'. If asked for a passcode, enter '0000', and the device will pair

Note: 'Bluetooth' is a trademark of Bluetooth SIG, Inc. This product is in no way affiliated with or endorsed by Bluetooth SIG Inc.

Re-pairing or pairing new devices

1. Turn wireless connectivity off on any previously paired devices
2. Follow the 'Pairing the speaker to your device' instructions
3. If a previously paired device is not present within the wireless connectivity range then the speaker will re-enter pairing mode

Playing music on your speaker

Wireless

When connected wirelessly, play the music on your device and the sound will play through the speaker. Some devices may require you to select the audio output.

Auxiliary

1. Plug the cable into the speaker's Aux-in port (4) and your device
2. The LED input indicator (1) will glow a solid red colour

Changing the volume

When playing music via wireless and auxiliary inputs all volume and track controls are operated from the master device e.g. smartphone or tablet.

Please note:

Your device will have an internal amplifier and if it is playing digital files like MP3s it will also have an integrated DAC (Digital Audio Converter). If you turn the volume up to 100%, your device will be sending a distorted signal. To avoid this, and to get the best quality from the speaker, we recommend that you do not run your device any higher than 95% volume. Some devices output higher than others, so you may need to reduce the volume if you experience distortion.

Care for your Hawaii 1.0

Please DON'T:

- Submerge the Hawaii speaker in water
- Drop the Hawaii speaker as this will invalidate your warranty
- Open up the Hawaii speaker. There are no user serviceable parts inside
- Expose the Hawaii speaker to extreme temperatures or rapid changes of hot to cold or vice versa

Please DO:

- Clean the Hawaii speaker with a soft dry cloth and no detergents

Specifications

S/N	69 dB
Wireless connectivity type	V4.1
Wireless connectivity distance	up to 10 m
Frequency response	100 Hz – 18 kHz
Drivers	1 x 40 mm
Output RMS	1 x 3 W @ 4 ohm
Play time	up to 4 hours
Charging time	up to 2 hours

Troubleshooting

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us at: support@kitsound.co.uk

Hereby, Kondor Ltd declares that the radio equipment type, KSHAW1 Hawaii 1.0 Wireless Speaker, is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
<http://kondor.co.uk/product-documents>

The use and operation of this speaker is beyond our control. Warranty of the KS Hawaii 1.0 is limited to defects caused by faulty manufacture or defects in materials only. No warranty whatsoever is given or implied for damage caused by the user under any circumstances.

This does not affect your statutory rights.

Please do not attempt to open this product. There are no user serviceable parts inside, in particular if your product has an embedded, non-replaceable battery, do not attempt to access or remove the battery as this may cause personal injury and will damage the product.

Making any attempt to open the product or carry out repair voids any and all warranties.

We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.