

SIZE CHART FOR MEN'S WET & SEMIDRY SUITS

USUAL SIZES		46	48	50	52	54	56	58	
AQUALUNG SIZES		1/XS	2/S	3/M	4/ML	5/L	6/XL	7/XXL	
PARTS TO MEASURE		1	2	3	4	5	6	7	Minimum tolerance
HEIGHT	centimeters	155-156	163-169	166-175	172-181	178-187	184-190	190-.....	± 4
WEIGHT	kilograms	47-63	54-70	61-79	70-89	80-97	88-107	96-.....	± 3
HIP CIRCUMFERENCE	centimeters	85	92	96	101	107	120	125	± 5
WAIST CIRCUMFERENCE	centimeters	76	81	86	89	96	101	106	± 5
CHEST CIRCUMFERENCE	centimeters	86	90	95	97	102	110	115	± 5
NECK to WRIST (B)	centimeters	72	75	78	80	85	88	92	± 2
WRIST CIRCUMFERENCE	centimeters	16	17	18	19	20	22	23	± 1
ANKLE CIRCUMFERENCE	centimeters	21	22	22	24	26	28	29	± 1
CALF CIRCUMFERENCE	centimeters	32	33	33	34	35	38	40	± 1
CROTCH to ANKLE (F)	centimeters	65	68	71	73	75	78	80	± 1,5
NECK to ANKLE (B)	centimeters	128	134	139	143	148	155	160	± 3
BICEP CIRCUMFERENCE	centimeters	27	29	30	32	34	37	40	± 1
HEAD CIRCUMFERENCE	centimeters	53	55	57	59	61	63	64	± 2
FOREHEAD to NAPE	centimeters	45	45	46	47	48	49	50	± 2
*B = Back *F = Front									

SIZE CHART FOR LADY'S WET & SEMIDRY SUITS

USUAL SIZES		38	40	42	44	46	48	
AQUALUNG SIZES		1/XS	2/S	3/M	4/ML	5/L	6/XL	
PARTS TO MEASURE		1	2	3	4	5	6	Minimum tolerance
HEIGHT	centimeters	150-160	160-163	163-166	166-170	169-172	175-.....	± 4
WEIGHT	kilograms	47-50	50-54	54-61	61-65	65-72	73-.....	± 3
HIP CIRCUMFERENCE	centimeters	76	80	82	87	91	95-.....	± 5
WAIST CIRCUMFERENCE	centimeters	62	65	68	73	77	81	± 5
CHEST CIRCUMFERENCE	centimeters	72	74	77	82	88	92	± 5
NECK to WRIST (B)	centimeters	67	68	70	73	76	79	± 2
WRIST CIRCUMFERENCE	centimeters	15	16	17	18	19	20	± 1
ANKLE CIRCUMFERENCE	centimeters	20	21	22	23	24	25	± 1
CALF CIRCUMFERENCE	centimeters	30	31	32	33	35	36	± 1
CROTCH to ANKLE (F)	centimeters	67	69	71	73	77	80	± 1,5
NECK to ANKLE (B)	centimeters	124	129	132	139	145	150	± 3
BICEP CIRCUMFERENCE	centimeters	25	26	28	29	30	31	± 1
HEAD CIRCUMFERENCE	centimeters	50	53	56	59	62	63	± 2
FOREHEAD to NAPE	centimeters	45	46	46	47	48	49	± 2
*B = Back *F = Front								