

SHINOLA MONSTER

Using Your Automatic Dive Timepiece

SPECIFICATIONS

MOVEMENT

Your Shinola Monster utilizes the SW200-1 automatic movement from Swiss movement manufacturer Sellita. It features 26 jewels and holds a power reserve of 38 hours.

CASE

Designed and tested to withstand depths of 1000 feet, your Shinola Monster features a unidirectional bezel, a screw-down crown, an anti-magnetic shield and sapphire crystal with an anti-reflective coating.

DIAL

The Shinola Monster boasts a distinctive dial design. With illuminated indices that emit continued light for easy visibility, the Shinola Monster's dial was designed to be easily viewable when submerged underwater up to 1000 feet.

QUALITY STANDARD

At Shinola we work hard to ensure that our watches uphold strict standards of quality and durability. The Shinola Monster is tested in-house to meet ISO 6425, the industry standard for water resistance, durability and reliability in dive watches.

MANUAL

FUNCTIONALITY

SCREW-DOWN CROWN

The components of your Shinola watch are made of the finest materials and have been rigorously inspected to meet our strict criteria. Your watch features a screw-down crown, which adds an extra level of watertightness. To safeguard your investment, it is important to understand how this type of crown works:

- 1 To make the crown operational, unscrew it from the case by turning it counterclockwise until it releases. Once released, follow the instructions for setting the time/date as described in the next sections.




- 2 To reseal the crown, press it in against the case until the threads engage, and turn clockwise until tight. It is important to reseal your crown to maintain watertightness.





CHANGING YOUR BRACELET

PLIER TOOL

1. Lay your watch face down on a soft cloth.
2. Adjust **Screw A** so that the distance between the two forks is equal to the length of the spring bar.
3. Insert forks into the cutouts of the bracelet where the spring bar is exposed, pinch to engage and compress spring bar end and remove the bracelet from the lug.
4. Once the bracelet has been removed, use the other watch strap tool to punch the spring bars out of the bracelet then insert spring bars into your new strap.
5. Using your hands, place one end of the spring bar on the new Shinola strap into the lug and use the other fork tool to hold back the spring bar while sliding it into position. Make sure the strap with the buckle attached is on the 12 o'clock side of watch. Repeat this step on the 6 o'clock side.




A



CHANGING YOUR STRAP

STANDARD SPRING BAR / FORK TOOL

1. Lay your watch face down on a soft cloth.
2. Insert forked end of tool between the edge of the strap and the lug.
3. Engage spring bar end and push/pull back on it to release from the lug.
4. Remove spring bar from end of strap, place in your new Shinola strap.
5. Using your hands, insert one end into the hole on the inside of the lug.
6. Use forked end of tool to hold back spring bar end while sliding the strap into position.
7. Release spring bar with tool and make sure the end inserts into the hole.



AUTOMATIC SW200-1

Refer to crown functionality on page 5.

WINDING WHILE STOPPED




- 1 The maximum power reserve can be restored by turning the crown clockwise around 30 times.

SETTING THE DATE

- 1 Pull the crown out to position II (watch still running).
- 2 Turn the crown clockwise until the required date appears.
- 3 Push the crown back into position I.

SETTING THE TIME

- 1 Pull the crown out to position III (watch stopped).
- 2 Turn the crown counterclockwise, until the current time is displayed (remember the 24-hour cycle).
- 3 Push the crown back into position I.



CARE AND PRECAUTIONS

Each Shinola timepiece is designed and manufactured to the highest of standards. Unlike most other mechanical objects, a watch operates non-stop. In order to ensure optimal performance and longevity from your Shinola timepiece, please review the simple guidelines for care and precautions.

CARE

- Clean your watch with a soft cloth and water only.
- After saltwater use, rinse watch under tap water and wipe dry with a soft cloth.
- Metal bracelets should be cleaned periodically. Clean with a soft brush dipped in mild soapy water and dry thoroughly with a soft cloth.

PRECAUTIONS

Your timepiece is a complex integration of parts and components brought together by skilled craftsmen. There are certain actions or environmental situations that may damage or impede your timepiece's ability to perform optimally.



It is important to avoid the following conditions: extreme heat or cold, as well as prolonged periods of exposure to direct sunlight.

Your timepiece should not be affected by magnetic fields generated by household items such as televisions and stereos, but avoidance of other strong electric fields or static electricity, which may interrupt mechanism, is suggested. It is also important to avoid extreme shock or impact.

AUTOMATIC LIMITED LIFETIME WARRANTY

At Shinola every watch is assembled in our Detroit factory and combines meticulous hand-assembly with the most advanced technology available to ensure our watches are both beautiful and built to last. We are so confident in our high-quality manufacturing standards that select Shinola watches are warranted for life under our limited lifetime warranty. It's an industry-leading guarantee and a testament to our core values.

Terms and conditions of the Shinola Automatic Watch Limited Lifetime Service Warranty

IN ORDER TO QUALIFY FOR YOUR SHINOLA AUTOMATIC WATCH WARRANTY YOU MUST REGISTER YOUR PRODUCT. THIS WARRANTY IS NOT TRANSFERABLE AND MAY BE VOIDED UNDER THE TERMS HEREOF.

1. The Shinola Automatic Watch Limited Lifetime Service Warranty covers all original series automatic watches: Runwell Automatic & Shinola Monster collection. This guarantee does not cover Detroit watches or Shinola quartz watches.

The Shinola Automatic Watch Limited Lifetime Service Warranty covers defects to material and workmanship under the natural useful life of the watch.

2. In case of defects caused by faulty workmanship covered by the limited lifetime warranty, any defective component (subject to exclusions below) will be repaired or the watch will be replaced free of charge.

3. Exclusions

- a. All straps, including bracelets
- b. Movement beyond its natural movement life (5 years for Automatic Movements)*
- c. Watch plating (PVD plating)
- d. Damage resulting from improper handling, lack of care, accidents or normal wear and tear
- e. Water damage
- f. Pre-owned vintage watches sold in as-is condition
- g. Re-furbished watches

* 5 years from the original date of purchase or date of most recent "Automatic Service" by Shinola, whichever is later. For more information on submitting repairs & servicing requests, please see the "Repairs & Servicing" section of the Shinola Helpdesk – [linked here](#).

4. This Warranty shall be VOIDED IF:

a. The watch has been damaged by accident, negligence or persons as determined by Shinola in its sole and absolute discretion.

b. If the watch is repaired, serviced, or engraved by any service provider other than Shinola.

5. If you have not registered your watch with Shinola this warranty does NOT apply.

6. If your watch requires complete replacement, and is covered by the warranty, Shinola shall replace your watch with the same model. If the model is no longer in production, a watch of equal value and similar style will be provided.

7. For service work that is not covered under this warranty, you will be notified of repairs needed and applicable charges. Shinola will commence such repairs only upon your prior approval to such charges or return the product, at your request.

REQUESTING WARRANTY AND OTHER WATCH REPAIR

Should you require work under warranty, please complete a repair form by visiting us at Shinola.com or a Shinola retail store. While they will not void the warranty, repairs and/or maintenance performed by Shinola's authorized repair partners is not covered under warranty; you will assume all cost associated with such repairs; Shinola will not provide reimbursement. Do not send original packaging, as it will not be returned. Shinola highly recommends you insure your parcel and adequately protect the watch during shipment. Shinola is not responsible for product lost or damaged during shipment. For service work that is not covered under this warranty, the service center may perform the services you request for a charge dependent on watch style and type of work requested. Such charges will be notified and agreed by you prior to performing the services.

The warranties and remedies above are exclusive and in lieu of all other warranties, terms or conditions, express, implied or statutory, as to any matter whatsoever, including, without limitation, warranties of merchantability, fitness for a particular purpose, accuracy, satisfactory quality, title, and non-infringement, all of which are expressly disclaimed by Shinola. Shinola shall not be liable for incidental, consequential, indirect, special or punitive damages or liabilities of any kind arising out of or in connection with the sale or use of this product, whether

based in contract, tort (including negligence), strict product liability or any other theory, even if Shinola has been advised of the possibility of such damages and even if any limited remedy specified herein is deemed to have failed of its essential purpose. Shinola's entire liability shall be limited to replacement or repair at Shinola's sole option. However, some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental consequential damages so the above limitations and exclusions may be limited in their application to you. When implied warranties may not be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights; you may have other rights that may vary depending on local law. Your statutory rights are not affected.

WE'RE HERE TO HELP

If you have any concerns or questions, don't hesitate to contact us. There are three ways to get in touch. Fill out the contact form on our website at [Shinola.com](https://www.shinola.com), give us a call, or send us an email.

MONDAY-FRIDAY
9AM-5PM EST

1.844.SHINOLA
(1.844.744.6652)

CUSTOMERSERVICE@SHINOLA.COM

SHINOLA
DETROIT