



The secret to
a great night's sleep

AIR PURIFIER

Operating Instructions



Model: 38060

Please read these instructions and retain for future reference.



GENERAL CARE AND SAFETY GUIDE

Read all instructions before using this appliance and keep them for future reference.

Warning: In order to avoid overheating, do not cover the Purifier.

- Use only the voltage specified on the rating plate of the heater.
- Do not cover or restrict airflow to the inlet or exhaust grilles in any manner as the appliance may overheat and become a fire risk.
- Keep all objects at least 0.5 meter from the front, sides and rear of the appliance.
- Do not block air inlets or outlets in any manner. Check the openings from time to time for accumulated dust. Ensure long shag carpet does not obstruct airflow under the unit.
- Do not place appliance close to a radiant heat source.
- Do not insert foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire or damage to the appliance.
- Do not operate any appliance with a damaged cord, plug or after the appliance malfunctions or has been dropped or damaged in any manner. Return to a qualified electrical person for examination, electrical or mechanical adjustment, service or repair.
- This appliance is intended for household use only, not for commercial or industrial use.
- Use this appliance only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electric shock or injury.
- The most common cause of overheating is deposits of dust or fluff in the appliance. Ensure these deposits are removed regularly by unplugging the appliance and vacuum cleaning air vents and grilles.
- Do not use abrasive cleaning products on this appliance. Clean with a damp cloth (not wet) rinsed in hot soapy water only. Always remove plug from the mains supply before cleaning.
- This appliance heats up slightly when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Switch off and use handles where provided when moving.
- Always operate on a flat horizontal surface.
- Do not operate with cord set coiled up as a build-up of heat is likely, which could be sufficient to become a hazard.
- The use of an extension cord with this appliance is not recommended.
- Do not remove plug from power socket until the appliance has been switched off.
- Do not remove plug from power socket by pulling flex - always grip plug.
- Always unplug appliance when not in use.
- Do not allow cord to come in contact with heated surfaces during operation.
- Do not run cord under carpeting, throw rugs or runners etc. Arrange cord away from traffic areas so that it will not be tripped over.
- Do not twist, kink or wrap the cord around the appliance, as this may cause the insulation to weaken and split. Always ensure that all cord has been removed from any cord storage area.
- Do not store appliance while it is still hot.
- The appliance must not be located immediately below a socket - outlet.
- If the supply cord is damaged, it must be replaced by a qualified electrical person in order to avoid a hazard.
- Do not use this appliance outdoors, or on wet surfaces. Avoid spilling liquid on the appliance.
- Always switch off the heater at the controls and at the power outlet then unplug heater from the power outlet when not in use.
- Do not use this heater with programmer, timer or any other device that switches the heater on automatically since a fire risk exists if the heater is covered or positioned incorrectly.
- Do not run the cord under carpeting or cover the cord with run runners or the like. Arrange cord away from traffic areas and where it will not be tripped over.
- Important - This heater is intended for floor use only. Do not mount on ceiling or walls.
- The heater must not be located immediately below a socket - outlet. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- Children should be supervised to ensure that they do not play with the appliance.



ABOUT YOUR AIR PURIFIER

Read all instructions before using this appliance and keep them for future reference.

Warning: In order to avoid overheating, do not cover the Purifier.

HOW THE AIR PURIFIER WORKS

1. The air purifier removes up to 99.97% of airborne allergens as small as 0.3 microns, including ragweed pollen, grass pollen, tree pollen, household dust, dust mite debris, pet dander and smoke from the air passing through the filter.
2. This appliance has an independent ionizer feature which, when turned on, releases negative ions into outgoing filtered air to help the air purification process.

PRODUCT FEATURES

Three Speed Settings

For optimum air filtration, operate your air purifier continuously on the highest setting. Its rugged motor has been designed to give many years of use.


For quieter operation (such as in a bedroom), select the sleep mode.

Timer

The timer allows you to run your air purifier at your convenience, for up to 8 hours. With 4 settings including 1H, 2H, 4H and 8H.

Ionizer

This appliance has an independent ioniser feature which, when turned on, releases negative ions into outgoing filtered air to help the air purification process.





OPERATING INSTRUCTIONS

Read all instructions before using this appliance and keep them for future reference.

Warning: In order to avoid overheating, do not cover the Purifier.

PRE-OPERATING INSTRUCTIONS

1. Carefully unpack your air purifier.
2. Select a firm level place where there are no obstructions to the air inlet or filtered air outlet.
3. Press the tab of air inlet grill, and then pull the air inlet grill backwards to remove it.
4. Detach the HEPA filter and then unpack the PE bag carefully.
5. Replace the HEPA filter back in position, make sure that the primarily efficient filter shall be pointed outwards.
6. Replace the air inlet grill back in position.

OPERATING INSTRUCTIONS

IMPORTANT: • Remove all PE bags from filters before use. • Do not point air outlet towards wall.

TO OPERATE YOUR AIR PURIFIER:

1. Plug into a 220-240V electrical outlet, two beeps "Bi-Bi" can be heard.
2. Press down the power switch, one beep "Bi" can be heard and its corresponding LED turns on, the air purifier starts to run under the default speed (Medium setting). If you want to select other settings, you can press "Speed control button" to select your desired speed setting (High setting and Sleep mode). After select, its corresponding LED will turn on.

Note: It is suggested to make the air purifier run under the default setting (Medium setting) if it is needed to be run continuously. For quieter operation (such as in a bedroom), select the sleep mode. When in an environment with polluted air, it is suggested to select High setting to quicken the air circulation.

Note: All the indicators will dim when the air purifier works under "Sleep mode" for some time.

3. You can activate the timer after turn on the air purifier and select your required speed setting by following the operation as below: press down "Timer" button on the control panel, one beep "Bi" can be heard. There are 4 settings including 1H, 2H, 4H and 8H. After select your required timing, its corresponding LED turns on. When the timer expires, the air purifier will power off automatically and the LED will extinguish.
4. To release negative ions into the filtered air, press the "Ionizer button", and one beep "Bi" can be heard and its corresponding LED will turn on.
Note: The ionizer will not work unless the unit is running.
5. If you want to make the air purifier stop running, just need to press "Power switch" once. And the air purifier will stop working after hearing one beep "Bi".






The secret to a great night's sleep

FILTER REPLACEMENT INSTRUCTIONS

Read all instructions before using this appliance and keep them for future reference.

Warning: In order to avoid overheating, do not cover the Purifier.

1. On average, HEPA filter needs to be replaced every 6 months. Filter life will vary depending on air quality and usage.
2. Turn off and unplug the air purifier before attempting to replace the filter.
3. Press the tab of air inlet grill to open the grill and then remove the HEPA filter.
4. To replace the HEPA filter, discard the old HEPA filter. Do not attempt to clean. And then install a new HEPA filter well in position, make sure that the primarily efficient filter shall be pointed outwards.
5. Replace the air inlet grill back in position.





The secret to a great night's sleep

CLEANING & MAINTENANCE

Read all instructions before using this appliance and keep them for future reference.

Warning: In order to avoid overheating, do not cover the Purifier.

1. Turn the air purifier off and unplug it before cleaning.
2. The outside of the air purifier can be cleaned with a soft, clean dampened cloth.
3. The filtered air outlet and air inlet grill on the unit can be cleaned of dust with a small, soft brush.
4. If you wish to clean the inside of the air purifier, please only use a dry, soft cloth to wipe it down.
5. Do not wash the HEPA filter.

WARNING: Do not allow moisture to come in contact with the main housing of the air purifier.



The secret to a great night's sleep

TROUBLESHOOTING

Read all instructions before using this appliance and keep them for future reference.

Warning: In order to avoid overheating, do not cover the Purifier.

PROBLEM

- | |
|--------------------------|
| • Unit will not operate. |
| • Decreased air flow. |

SOLUTION

- | |
|--|
| • Check to make sure the unit is plugged in. |
| • Check to make sure the unit is on. |
| • Make sure the filter is properly installed and firmly close the air inlet grill. |
| • Check condition of the filter and replace if necessary. |
| • Check to ensure nothing is blocking the air inlet and filtered air outlet. |
| • Please replace the HEPA filter if it has been operated for more than one year. |
| • Be sure the plastic bag has been removed from the filter. |

Information on Waste Disposal for Consumers of Electrical & Electronic Equipment

This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment (WEEE).

Any WEEE marked waste products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used.

For proper treatment, recovery and recycling; please take all WEEE marked waste to your Local Authority Civic waste site, where it will be accepted free of charge.

If all consumers dispose of Waste Electrical & Electronic Equipment correctly, they will be helping to save valuable resources and preventing any potential negative effects upon human health and the environment, of any hazardous materials that the waste may contain.



After Sales Service

Your product is guaranteed for three years from the date of purchase.

Within this period, we undertake to repair or exchange this product free of charge provided it has been installed and operated in accordance to these instructions.

Your rights under this guarantee are additional to your statutory rights, which in turn are not affected by this guarantee.

Should you require after sales service you should contact our customer services help desk on 0151-448 6974. It would assist us if you can quote the model number, series, date of purchase, and nature of the fault at the time of your call. The customer services help desk will also be able to advise you should you need to purchase any spares.

Please do not return a faulty product to us in the first instance as this may result in loss or damage and delay in providing you with a satisfactory service.

Please retain your receipt as proof of purchase.



©Silentnight Group Limited 2016

All rights reserved

Licensed by JELC

Exclusively manufactured for and distributed

by BML LIVERPOOL L24 9WD UK ©2016

All Rights Reserved.

Product may vary slightly from the image shown.

Specifications will however remain the same.