



Firmware Version: 3.00rc048

Published Date: 2020/01/06

Content:

Upgrading Instructions:	2
Upgrading by using Web-UI.....	2
New Features:.....	3
Changes of MIB & D-View Module:.....	3
Problems Fixed:	3
Known Issues:	3
Related Documentation:	3

Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version
2.02rc019	2014/12/22	DAP-2310	B1
2.06rc029	2015/07/06		
2.07rc031	2016/03/23		
2.10rc036	2016/03/23		

Upgrading Instructions:

D-Link AP supports firmware upgrading via Web-UI. You may download the firmware from D-Link web site <http://tsd.dlink.com.tw>.

Upgrading by using Web-UI

1. Connect a work station to the LAN port of Access Point.
2. Open the web browser of work station and entering the IP address of the AP. The system default IP address is 192.168.0.50.
3. Enter administrator's username and password, user name is "admin" and leave the password field blank by default.

To update the AP's firmware, click **Maintenance > Firmware and SSL Certification Upload**

The screenshot shows the D-Link Web-UI interface for a DAP-2310 device. The top navigation bar includes Home, Maintenance, Configuration, System, Logout, and Help. The left sidebar shows a tree view with DAP-2310, Basic Settings, Advanced Settings, and Status. The main content area displays the 'System Information' page with the following details:

Model Name	DAP-2310
Firmware Version	v3.00 11:01:36 10/31/2019
System Name	D-Link DAP-2310
Location	
System Time	01/06/2020 17:07:06
Up Time	0 Days, 00:1:33
Operation Mode	Access Point
MAC Address	c4:a8:1d:91:b1:10
SSID 1~7	c4:a8:1d:91:b1:11 ~ c4:a8:1d:91:b1:17
IP Address	192.168.0.205

New Features:

1. Use QCA's WDS
2. Remove AP Array
3. Support Nuclias Connect
4. Support DDPv5/APP
5. In default settings, the network IP address setting is Dynamic IP
6. Support MDNS
7. Modify Time zone settings
8. Update country selection table
9. Move IP filter settings page from Captive Portal to Filter folder, behind WLAN Partition (AP GUI). IP filter function is independent feature and can work with all non-captive portal attenuation
10. Default admin user name/password is admin/admin
11. Add setup Wizard when first login

Changes of MIB & D-View Module:

None

Problems Fixed:

Firmware Version	Problems Fixed
V3.00r048	None

Known Issues:

Firmware Version	Known Issues
V3.00r048	None

Related Documentation:

- DAP-2310 User Manual v3.00