


NP4DLM Parts Diagram



Ref No.	Part No.	Description
1	P04001	Oil Sump
2	P04002	Handle Assy
3	P04003	O-ring (Oil Sump)
4	P04004	Pump Cylinder Assy
5	P04005	Trestle
6	P04006	O-ring
7	P04007	Oil Fill Cap
8	P04008	Inlet Port
9	P04009	Inlet Cap Set
10	P04010	Fan Blade
11	P04011	Rear Cover Assy
12	NBP2	Battery Pack
13	P04013	Motor
14	P04014	Base Plate
15	P04015	Controller PCB
16	P04016	Cover Plate
Not Shown	NC2	Charger
Not Shown	NKR-4DL	Pump Rebuild Kit
Not Shown	RC16038	Oil Drain Cap