



pTron



Avento Classic
Wireless Neckband

Instruction Manual

Product Description:



1. Volume - / Next Song
2. Power/Multi-function Button (MFB)
3. Volume + / Previous Song
4. LED Indicator
5. Micro USB Charging Port
6. Built-in Battery

-1-

Charging & Battery:

1. Switch off the wireless headset before charging.
2. Plug micro USB cable into the charging port and other side of the cable to DC5V/1A USB charger or other charging devices. LED indicator light will be steady red during charging.
3. Charge the headset for 1.5-2 hours. After full charge the LED light will turn to Blue.

Power ON: Long press the MF button until blue LED light flashes. You will hear a voice prompt "Power On".

Pairing Mode: Long press the MF button until blue & red LED light flashes alternatively. You will hear a voice prompt "Pairing".

Wireless Headset & Phone Pairing:

1. Keep the phone and the headset within 1 meter range or closer to each other.
2. Long press the MF button until blue & red LED light flashes alternatively. You will hear a voice prompt "Pairing".

-2-

3. Open Bluetooth function on your phone and search for the available Bluetooth devices. Click on "pTron BT" to connect. You will hear a voice prompt "pTron BT is Connected". Blue light will blink at regular intervals.

Note: If there is no pairing between the headset and phone for 10 minutes. Then, pairing mode will stop and red & blue LED light will stop blinking. Please follow 1 to 3 steps again.

4. When headset is paired and connected to your phone. pTron Bluetooth headset will re-connect automatically to your phone provided your phone's Bluetooth is On.

Power OFF: " Press the MF button until the red LED light blinks and goes off. You will hear a voice prompt "Power Off".

Reject a Phone Call: Long press MFB for 2 seconds.

Call Answer/Hang-up: Press MFB once or use your phone.

Last Call Redial: In standby mode, press MF button twice to call the last call.

Music Play/Pause: Press MF button once.

Next Song: Long press "-" button.

Previous Song: Long press "+" button.

Volume +: Short press "+" button to increase the volume.

Volume -: Short press "-" button to decrease the volume.

Voice Assistance: Press the power button for a second to awake Google Assistant/Siri.

-3-

Specifications:

Connectivity: Advanced Wireless
Transmission Range: Up to 10 m
Frequency Response: 20Hz - 20kHz
Speaker Impedance: 16Ω
Speaker Sensitivity: 104±3dB
Mic Sensitivity: -42±3dB
Driver Size: 10 mm Dynamic
Charging Voltage: DC5V/1A
Battery Capacity: 90mAh, Li-Polymer
Playback Time: 3.5 Hours
Talk Time: 3 Hours
Standby Time: 60 Hours
Charging Time: 2 Hours

Disclaimer:

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.

-4-