

## VANKYO SUPPORT

North America    [support@vankyo.com](mailto:support@vankyo.com)  
United Kingdom    [support.uk@vankyo.com](mailto:support.uk@vankyo.com)  
España    [support.es@vankyo.com](mailto:support.es@vankyo.com)

## Leisure E30T/Leisure E30TB/Leisure E30WT USER MANUAL

Please read this manual thoroughly before using and keep it for future reference.



[www.vankyo.com](http://www.vankyo.com)



[info@vankyo.co.uk](mailto:info@vankyo.co.uk)



[info@vankyo.es](mailto:info@vankyo.es)

**ENGLISH**

**WHAT'S INCLUDED**

Projector

Remote (Batteries Not Included)

User Manual

HD Cable

Power Cable

**NOTICE**

**Recommended**

**NOT Recommended**

Power Supply  
Power Cable

Correct connection method: Projector connected to PC and Monitor.

Incorrect connection method: Projector connected to PC and Monitor (marked with a red X).

[www.epson.com](http://www.epson.com)

## HOMEPAGE

Input Source Options

Screen Mirroring for iOS devices

WiFi Status

USB Disk Imported Settings

Screen Mirroring for Android Devices

The Categories of Keystroke Head

### KEYSTONE CORRECTION

**Step 1:**  
Select **on the Homepage** to enter the interface of Settings, then select **Project Images Setting**. To enter the interface of **Properties**, click **on the sidebar to directly enter the interface of Properties**.

### Step 2:

Select **Point** in the option of **Keystone Advanced** and the **Manual Keystone** option will be displayed. You can correct the **Vertical keystone** distortion manually until the shape is evenly rectangular.

\* Select **Sides** in the option of **Keystone Advanced** and the **4-Point Keystone** option will be displayed. You can correct the **image** shape by **four corners**.

**MULTIMEDIA CONNECTION**

**USB Disk/Memory Card Connection**

**Step 1** Turn on the projector and insert your USB disk/memory card into the USB port/memory card slot.



**Step 2** Go to **Home** and select the file category you would like to display among **Movie**, **Mus**, **Photo** and **Office Suite**. Then, enter the selected USB disk/memory card check all files listed.

- \* **Icons file**
  - Press **Menu** to correspondingly read files listed.
  - Go to **OK** on the projection/Press **OK** on the remote for a certain video file to enter full-screen display.
  - Go to **OK** on the projection/Press **OK** on the remote when playing a video file to bring up the toolbar to correspond to video playing.
- \* **Audio file**
  - Select **Music** to correspondingly read audio files listed.
  - Go to **OK** on the projection/Press **OK** on the remote for a certain audio file to enter full-screen display, then press **OK** on the remote to start playing.
- \* **Audio format supported:** AAC/MP3/LAAC/MP4/AC3/MP3/AMR/AMR/MP2

**\*Photo files**

- Select **Photo** to correspondingly read photo files listed.
- Go to **OK** on the projection/Press **OK** on the remote to open a certain photo file to enter full-screen display.

**Image Format supported:** JPEG/JPEG/IMG

**\* Document files**


- Select **Office Suite** to correspondingly read document files listed.
- Go to **OK** on the projection/Press **OK** on the remote to open a certain file.
- Go to **OK** on the projection or press **OK** on the remote to jump the cursor to the toolbar at the top.

**Text Format supported:** DOC/DOCX/SLIDE/PPPT/PPPT/TXT

➤ Go to **OK** on the projection or press **OK** on the remote to go back to **Home**


**HD Connection**

**Step 1** Turn on the projector and connect your device to the **HD 1.2 Port** of the projector with the provided "HD Cable".



**Step 2** Select **HD 1.2** on the right side of the **Homepage** as the input source, then the contents of your device will be projected to the screen(s).

- 1. Windows 7 or higher system, press the "Windows Logo + P" key combination to access four display modes.**


  - ❑ **For Windows 7 or higher system, press the "Windows Logo + P" key combination to access four display modes.**
  - ❑ **PC screen only option displays contents on computer screen only.**
  - ❑ **Duplicate option displays the same contents on both computer screen and projected screen.**
  - ❑ **Extend option displays the display between the computer screen and the projected screen.**
  - ❑ **Second screen only option displays contents only on the projected screen.**
- AV Connection**

**Step 1:** Turn on the projector and connect your device to the AV Port of the projector with an AV cable.




(Not provided)
- Step 2:** Select AV on the left side of the **HomePage** as the input source, then the contents of your device will be projected to the screen wall.



**Step 1:** Activate Screen Mirroring/MultiPlay Mirroring on your iOS device and search for the projector.

**Step 2:** Select Leasim X000 from the searching list to connect.



**Step 3:** The contents on your iOS device will be mirrored to the wall/screen.

**Step 1:** Activate Multi-Screen function on your Android device and search for the projector.

**Step 2:** Select Leasim X000 from the searching list to connect.

**Step 3:** The contents on your Android device will be mirrored to the wall/screen.



**For Android system**

To activate this function, please make sure your Android device supports **Multi-screen/Wireless Display**. Names may differ from our Android device to another.


**Step 1:** Turn On the Wi-Fi switch in your Android device.

**Note:**

- 1 The fluency of screen mirroring will be affected by the network environment: a bandwidth of 100Mbps or more is recommended when using screen mirroring.
- 2 Make sure your mobile device is close to the projector when using wireless connection. A distance within 10m is recommended.
- 3 Some mobile devices may not support screen mirroring due to the compatibility.

**SETTINGS**

Select  on the upper right corner of the **HomeApp** to enter **Settings** interface.




### Other Setting

- 1. Power On Option**
  - \* If you select **Standby**, the projector will directly power on when you plug in power cord or use electrical switch for the next use.
  - \* If you select **Standby**, you need to press **⏻** to turn the projector on when you plug in power cord or use an electrical switch for the next use.
- 2. Scheduled On/Off**
  - \* Set the start duration for the projector to shut down automatically. Options include OFF, 0:05, 2:00min, 3:00min, 4:00min or 12:00min.

### Well-Setting

1. Change **Projection Mode** among **From Desktop**, **From Desktop**, **From Ceiling** and **From Ceiling**.
2. Enter **Repeat** (Maximum 5 times) to connect image multiple times.
3. Enter **Image Zoom** and use the **Up/Down** button to enlarge/shrink the image.

### Projection Distance & Size



\* The recommended projection distance varies with different projection modes. Please adjust the distance between the wall/screen and the projector properly as needed.  
 \* Actual distance will improve the image quality and projection images.

### Language Setting

Select a language for the projector.

### System Update

1. Select **Update** the firmware version via a USB disk with update file named as **FWUPDATE**. Contact our customer service to get the update file.
2. **Online Update** (Contact our customer online when a new version is available).
3. **Restore Factory** Restore the projector to the factory settings.

[illegible]

| FCC Statement                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | FCC Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <p>This device complies with the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <p><b>Note:</b></p> <p>The FCC warning has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This device uses technologies and features designed to maximize energy use. All tested and certified models, in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off/on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>—Reorient or relocate the receiving antenna.</li> <li>—Increase the distance between the equipment and the receiver.</li> <li>—Connect the equipment to a outlet on a circuit different from that to which the receiver is connected.</li> <li>—Consult the dealer or an experienced radio/television technician for additional suggestions.</li> </ul> <p>This equipment complies with radiation exposure limits set for an uncontrolled environment. This transmitter must not be used in a space where it is subject to any other interference or restriction.</p> <p>The FCC warning must be installed and approved with minimum distance from the installation body.</p> | <p>The device complies with the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.</p> <p>The following measures may be taken to correct the interference:</p> <ol style="list-style-type: none"> <li>1) Reposition the receiving antenna.</li> <li>2) Reposition the equipment and the receiver.</li> <li>3) Connect the equipment to a power outlet on a circuit different from that to which the receiver is connected.</li> <li>4) Consult the dealer or an experienced radio/television technician for additional suggestions.</li> </ol> <p>This equipment complies with radiation exposure limits set for an uncontrolled environment. This transmitter must not be used in a space where it is subject to any other interference or restriction.</p> <p>The FCC warning must be installed and approved with minimum distance from the installation body.</p> |



ESPAÑOL



Proyector



Mando a distancia (No incluido la batería)



Manual del Usuario



Cable HD



Cable de Corriente

ATENCIÓN

Recomendado

Evitar: sobrecalentamiento, humedad, golpes, vibración



NO Recomendado





ESPAÑOL



Proyector



Mando a distancia (No incluido la batería)



Manual del Usuario



Cable HD



Cable de Corriente

ATENCIÓN

Recomendado

Evitar: sobrecalentamiento, humedad, golpes, vibración



NO Recomendado





ESPAÑOL



Proyector



Mando a distancia (No incluido la batería)



Manual del Usuario



Cable HD



Cable de Corriente

ATENCIÓN

Recomendado

Evitar: sobrecalentamiento, humedad, golpes, vibración



NO Recomendado



[illegible]

### PÁGINA DE INICIO

### Paso 2


Seleccione **Fronte** en la opción de **Keystone** **extendido** y se mostrará la opción **Keystone manual**. Puede configurar la distribución **Keystone** manualmente hasta que la forme sea rectangular o se uniforma.

Seleccione **Lado** en la opción de **Keystone** **extendido** y se mostrará la opción **Keystone de 4 puntos**. Puede configurar la forma de la imagen en cuatro esquinas.

[illegible]


**Paso 6:** Deslice hacia arriba la pantalla de su dispositivo móvil iOS y, a continuación, pruebe **Activar pantalla táctil** y luego el proyecto.

**Paso 6:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 7:** La pantalla de su dispositivo iOS se proyectará a la pantalla portátil después de una conexión correcta.

**Paso 8:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 9:** La pantalla de su dispositivo Android se proyectará a la pantalla portátil después de una conexión correcta.



**Paso 10:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 11:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.




**Paso 12:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.




**Paso 13:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.




**Paso 14:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.




**Paso 15:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.




**Paso 16:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 17:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.




**Paso 18:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 19:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 20:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 21:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 22:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 23:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 24:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 25:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 26:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 27:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 28:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 29:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 30:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 31:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 32:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 33:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 34:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 35:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 36:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 37:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 38:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 39:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 40:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 41:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 42:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 43:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 44:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 45:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.



**Paso 46:** Seleccione **Leísmo XXXX** de los resultados de la búsqueda por contenido.

**Configuración wifi**

Conectar el proyector al Wi-Fi del servidor.

**Configuración de imagen de proyección**

1. Cambio modo de proyección entre Esporádico/Normal. Esporádico: pausa. Tecla: **transm.**

2. Ajustar la **Resolución** (Formato/Frame/Luma) para corregir la distorsión de la imagen.

3. **Trigone Zoom digital** y **zoom** botón **Amplio/Redu** para ampliar/reducir la imagen.

**Configuración de idioma**

Seleccionar un idioma para el proyector.

**Actualización del sistema**

1. **Actualización en línea:** Actualice el firmware en línea cuando haya una nueva versión disponible.

2. **Actualización local:** Actualice el firmware a través de un disco USB con un archivo de actualización descargado de [www.3dmax.com](http://www.3dmax.com). Descargue con cuidado los archivos de actualización para evitar dañarlos.

3. **Restaurar BIOS:** Para restaurar el proyector.

**Otras funciones**

**1. Opción de encendido**

Si selecciona **Directa**, el proyector se enciende directamente cuando conecta su cable de alimentación a una toma de corriente en el primer uso.

Si selecciona **Calentamiento**, debe presionar **ON** para encender el proyector cuando conecta su cable de alimentación a una toma de corriente en el primer uso.

**2. Ajustado programado**

Establezca la hora del temporizador para que el proyector se encienda automáticamente. Las opciones incluyen: **agregar: 10 minutos, 20 minutos, 30 minutos, 60 minutos y 120 minutos.**

**3. Ajuste de la**

**Ajuste de la**

Comparar la **Versión del sistema** y la **Dirección MAC** del proyector.

**DISTANCIA Y TAMAÑO DE PROYECCIÓN**

La distancia de proyección recomendada varía con los diferentes formatos de proyección. Agrega la distancia entre la pantalla y el proyector y selecciona la distancia apropiada.

El tamaño ambiental necesario a la distancia de la proyección apropiada.

| ESPECIFICACIONES           |                                                                                               |                              |                         |
|----------------------------|-----------------------------------------------------------------------------------------------|------------------------------|-------------------------|
| Tecnología del LED         | CDD                                                                                           | Fuente de luz                | LED                     |
| Resolución                 | Nativa 1920x1080                                                                              | Tamaño de pantalla           | 576, 1209, 1680, 1980P  |
| Tipo de instalación        | Dielante/Detrás/Cubo                                                                          | Ratios de aspecto            | 4:3/16:9Auto            |
| Enfoque                    | Manual                                                                                        | Kytening digital             | E50F                    |
| Altavoz                    | 3WxHans                                                                                       | Fuente de alimentación       | AC 100-240V/50/60Hz     |
| Dimensiones de la caja     | 240x210x10mm                                                                                  | Peso neto de la caja         | 1.9kg                   |
| Formatos de foto admitidos | JPG/JPEG/BMP/TIF                                                                              | Formatos de sonido admitidos | MPEG1/MPEG2/AC3/WMA/MP3 |
| Torreles de montaje        | Modulares                                                                                     | Número de torresita          | 4                       |
| Formato de video admitido  | A/V/PAL/NTSC/SECAM/HD/SD/2K/4K/HDC/SD/SBS/PSA/1284/720P/1080I                                 |                              |                         |
| Fuentes                    | HDMI v1.2 / DVI-D / Salida de audio L/R / IN v1.2 / Paralela para Tarjetas de Memoria x1 o x2 |                              |                         |
| Formato de texto admitido  | DOC/DOCX/XLS/XLSX/PPPT/PPSX                                                                   |                              |                         |