

X2™ QUICK PROGRAMMING GUIDE

Hunter®

CONTROLS



Set Current Date Set Current Time

Turn Dial to DATE/TIME



< > + -

< > + -

MANUAL WATERING

Run a Program

Turn Dial to RUN, Press and Hold Right Arrow




< > + =

< > + -

Run a Single Station

Turn Dial to MANUAL, Set RUN TIME,
Turn Dial to RUN



< > + =

< > + -

ADD WI-FI



<https://hunter.direct/WAND>

PROGRAMMING OVERVIEW


1 Select a Program

Press PROGRAM (PRG) button to choose program A, B, or C for setup



2 Set Watering Start Times

Turn Dial to START TIMES




< > + -

< > + =

3 Set Station Run Times

Turn Dial to RUN TIMES




< > + -

< > + =

4 Set Watering Days

Turn Dial to WATER DAYS



< > + -

< > + =

Circle = Velcro

X2 WATERING SCHEDULE

Hunter®

PROGRAM A PROGRAM B PROGRAM C

DAYS OF THE WEEK	M	T	W	T	F	S	S	M	T	W	T	F	S	S	M	T	W	T	F	S	S
INTERVAL OR ODD/EVEN																					
NON-WATER DAYS																					
PROGRAM START TIMES	1																				
	2																				
	3																				
	4																				

A program is a watering schedule that includes a start time(s), run time(s), and water day(s).
 A start time is the time of day the stations in the program start watering.
 A run time is the watering length per station (zone).
 One start time is needed to run the entire program.

STATION	LOCATION	STATION RUN TIME	STATION RUN TIME	STATION RUN TIME
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				



<https://hunter.direct/X2help>

Dieline