

ipixo

1080p Outdoor Camera
User Manual

Contents

- 2 What you'll need
- 3 Let's get started
- 4 Installing the Camera
- 5 Live View
- 6 Motion and Sound Detection
- 7 Area Detection
- 8 Schedule
- 9 Home Management
- 10 Sharing the camera
- 13 Multi Camera View
- 14 Web View
- 16 Safety information

This user manual has all the information you need to make the most out of Camera.

Please keep this manual for future reference and ensure you have read all safety instructions carefully before use.

The manual is subject to change without notice. The updates will be added into the new version of the manual.

What you'll need

This is what you will need to set up your Outdoor Camera



Wi-Fi broadband

A working internet connection
on a 2.4Ghz frequency channel



Compatible Device

An Apple or Android
Smartphone or Tablet PC



Clan at Home account

Download the Clan at Home
app and register



Indoor Mains Power Supply

Direct access to an indoor
power socket



Phillips Bit

A power drill with Phillips
driver bit



Drill Bit

To install on surfaces such as
brick or concrete

Safety information


Let's get started

Please complete set up before mounting the camera

Connect the camera to the mains using the power adapter provided.

The red LED will come on once plugged in and the camera will chime before it is ready to connect.

If you would like the camera to record, you will be required to insert a Micro SD Card. The camera will support any sized Micro SD Card up to 128GB



What do the flashing lights mean?



Solid Red
Starting up



Flashing Red
Ready to connect



Solid Blue

Add the Camera to the Clan at Home App

If you're setting the camera up for the first time, you will need to:

1. Download the Clan at Home app from the Google Play Store or Apple App Store
2. Open the app and "register" to create an account
3. Create a Home
4. Then add Camera

If you already have a Clan at Home account, simply press the "+" icon on the top right corner and follow the on-screen steps.

You will be asked to enter your Wi-Fi router password and use the Camera to scan the QR code created on your smartphone, then the camera will connect to your Wi-Fi network.


If you need help with this, please refer to the Quick Start Guide included with Camera.

Installing the Camera

Choose a good spot

The Camera has an adjustable head and a wide field of view so you can position it in any direction you want.

We recommend that you mount the Camera at around 3 metres above the ground, this is the ideal position for the Camera to sense movement, see faces and talk through the speaker and microphone.



Ensure that the Camera is mounted in a position that allows you to see over a large area of your home and surroundings with an unblocked, clear view.


Test the Wi-Fi signal

Before mounting the Camera, we recommend that you test the Wi-Fi strength in the area that you'd like to place it. Ensure the Camera is still plugged in to a mains power supply and take it outdoors.

Hold the Camera in the position that you would like to mount it and check that the live stream is working well in the app.


Working well? Great, continue to the next page.


Can't see the live stream? Your Wi-Fi may not be strong enough in that area, you may need to find another spot or move your Wi-Fi router closer.



Live View


Once setup is complete, select the Camera in the Clan at Home app



-  Change the video quality from Standard definition to High Definition
-  See your Wi-Fi Signal Strength
-  Select to customise motion detection settings
-  Click to turn microphone on or off
-  Click to record video manually, this will save to your phone gallery
-  Click to take a snapshot manually, this will save to your phone gallery
-  Click to view recorded footage from the SD card
-  Click to view recorded footage from the cloud service.
-  See Full-Screen
-  Turn the speaker on or off
-  See more Settings


Motion and Sound Detection

To set up the Motion and Sound detection, follow the steps below:




Step 1

Click on the Settings icon to bring up the Camera settings



Step 2

Select Detection alert setting




Step 3

Turn the setting on and choose the sensitivity


Selecting a sensitivity level minimises false alerts

When movement or sound is detected, the Camera will send you alerts straight to your Smartphone or Tablet device.


If your device is locked when the Camera detects something, you will receive a notification on your home screen as long as you are signed in to the Clan at Home app



Area Detection




Step 1
Click on Surveillance
area setting.



Step 2
Select the area you wish to monitor,
click Save

Schedule



Step 1
Click on schedule





Step 2
Click Add

Step 3
Choose your settings and click Save on the top right hand corner to set the schedule

Home Management

You will have created a “Home” when you registered a Clan at Home account.

To manage the settings of your home, follow these steps:



Step 1

Click on your Home name in the top left corner

Step 2

Select Home Management

Step 3

Click on your “Home”


You can also add a new Home from this page.

Step 4


Change settings, change location or add a family member.

Add a Family Member

You are able to add Family Members to your home, this gives them access to all Clan devices in that home automatically so you don't have to share each device individually.




Step 1
Click Add members



Step 2
Fill in the members name and
Clan at Home account details
Setting the member as an
administrator gives them full
access to device settings.

Click Save




Step 3
The new family member will appear
under the list of Family members

Sharing Camera

You are able to add share the Camera with your family and friends so they can also view the camera.


Sharing the device will only give them access to live-view, to give full access to Camera settings, please see "Add a Family Member" on Page 9

Your family member must have a registered Clan at Home account.




Step 1

Click on the Camera




Step 2

Select Settings icon to bring up settings for the camera



Step 3





Click share devices



Step 4

Click Add

Sharing Camera



Step 5

Enter Email address used to create account.

Click save to share the camera.

Step 6

It will now appeared as a Shared device


Step 7

A notification will be received on the phone that the Camera has been shared to


Step 8

The camera will now appear under Received devices

Multi Camera View




Web view




Step 1

Go to the following website on your PC. <https://ipc-eu.ismartlife.me/login> and a QR Code will be displayed




Step 2

Go into the Clan at Home App and click on Me in the bottom right hand corner



Step 3

Click on the square on the top right hand corner




Step 4

Using your phone scan the QR code

Ensure the QR code is within the Green square

Click Confirm Login

Web view



1. Select the home where you would like to view your cameras.
2. Select your camera.
3. Speaker – Listen in on what is going on around your camera.
4. Full screen
5. Cloud Service – View the ~~rec~~orded footage from the Cloud Service.
6. Multi Camera View – Select how many cameras you would like to see at once.

Safety Information

These instructions are intended to ensure that user can use the camera correctly to avoid danger or property loss.

Only use the original power adapter and accessories from the manufacturer.

Do not connect several cameras to one power source as adapter overload may cause over-heat or fire hazard.

Do not place the camera in extremely hot, cold, dusty or damp locations (the operating temperature should be -20°C ~ +55°C)

Do not drop the camera or subject it to physical shock. If you notice any smoke, odours or unusual noise coming from the camera, immediately unplug from power, and then contact iPixo customer services.

It is not permitted to open the camera yourself or to have it opened, neither is it permitted to repair the camera yourself or to have it repaired. This will void the warranty.

Disconnect the camera from all power sources before cleaning it. Use a clean, dry cloth to clean the product.

Do not use any abrasive agents, corrosive cleaning products or any substances that contain bleach or solvents to clean the camera.