



WIRELESS GAMING CONTROLLER

Just Plug & Play...

USER MANUAL

1. Product Information

Key Function



Mode and LED indicator

- Xinput mode ■■■■■
- Direct input digital mode ■■■■
- PS3 - CH1 (■■■■■) CH2(■■■■■) CH3(■■■■■) CH4(■■■■■)
- CH5(■■■■■) CH6(■■■■■) CH7(■■■■■)
- Direct input analog mode ■■■■
- Android mode ■■■■

2. Application - This controller is only applicable for -

- Windows PC
- PS3
- Android 4.0 or above - You need to have a OTG cable to connect the controller with your phone.

How to connect with Android Phone -

Step 1 - ON the OTG function from your phone settings.

Step 2 - Connect Phone With OTG Cable to start playing.

Caution - You need to be sure that the game you are playing on your phone supports an external amuzator/controller. As some of the action/shooting games do not offer the advantage of a controller on phone.

3. Driver Description -

- Windows 7/8/8.1/10 - Just Plug and Play
- Windows XP - Sometimes need the driver. Download from the link below or CD.
- If you need Vibration function is Direct Input (which works on old games).
- Download the driver from the link below or CD. <http://bit.ly/RPMEuroGamesPCController>

4. How To Start and Connect -

- Insert the Dongle.
- Wait for 2-3 minutes for Dongle to automatically download the driver.
- Once the driver is installed, Press HOME button 2 times to connect.

5. How to Switch Off -

- Press Button "Z" and "Select" for 5-8 Seconds, the controller will automatically switch off.

Troubleshoot -

- What if the lights start blinking fast when HOME button is pressed 2 times to connect the controller?
- This means the controller is not connected. You need to Switch Off the controller. Put the Dongle in different USB Port. Try connecting it again. If it still does not connect then uninstal/remove the Dongle driver and Restart your PC. It should work now. If you still experience the problem, please reach out to us at - rpmeurogames@gmail.com

How to know when the controller is fully charged?

When the controller is in charging mode it starts blinking lights slowly. When the controller is fully-charged it will stop blinking when it is in "Switch On" mode and LEDs will light normally. If it is "Switch Off", then all lights would go Off.

Need A Dongle?

Write to us at - rpmeurogames@gmail.com, we will dispatch a new one at earliest, charging you just the courier amount.

Liked the product?
Give Us A Review!!

