

2019 Audi Maintenance Schedule - All Models

MY 2019 Maintenance Intervals - USA

This applies to the all gas and hybrid models

Service intervals in miles												
	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Minor Maintenance (Every-1 year) ¹	X		X		X		X		X		X	
Standard Maintenance (Every 2 years) ²		X		X		X		X		X		X
Additional Maintenance Items	Refer to the Additional Maintenance Items Table below											

- 1) First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.
- 2) First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.

NOTE: The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Check all completed items

Minor Maintenance

- Brake system - Check the thickness of the brake pads
- Engine oil and oil filter - Change oil and replace filter
- Multi-point inspection - Complete
- Service reminder indicator display - Reset display
- Tire repair kit - Check and record the completeness and expiration date (if equipped)

Standard Maintenance (Includes All Minor Maintenance Items)

- Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open
- Brake system - Check for damage and leaks, condition of brake hoses and the presence of the bleeder caps; Check the thickness of the brake pads.
- Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions (A4, S4, A4 allroad®, A5, S5, RS 5, A6, A7, A8 L, Q5, SQ5, Q7, and Q8)
- Convertible top - Lubricate latch mechanism (A5 Cabriolet, S5 Cabriolet only)
- Door hinge (including door stay) and door latch - Lubricate
- Engine cooling system - Check freeze protection and coolant level
- Engine oil and oil filter - Change oil and replace filter
- Engine, transmission, final drive, steering - Visual inspection for leaks and damage
- Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, license plate lights, and hazard warning lights
- First aid kit - Check and enter expiration date YYYY / MM _____
- Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play
- Headlights - Check adjustment
- Hood safety catch - Lubricate (A3, S3, RS 3 only)



Standard Maintenance (continued)

- Horn - Check function
- Instrument cluster - Check warning and indicator lights
- Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination
- Multi-point inspection - Complete
- Plenum chamber and water drain valves: Check for dirt. (A8 L, Q7, Q8 only)
NOTE: Time spent cleaning of item is a separate charge for service time
- Road test - Perform
- Rollover protection - Check the rollover protection when the convertible top is open (A3 Cabriolet only)
- Safety belts - Check function
- Service reminder indicator display - Reset display
- Spare tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
- Spoiler - Lubricate rear spoiler (TT, TT Roadster only)
- Sunroof systems - Check function (if equipped)
- Tires - Check condition and tire tread wear. Check and record the tread depth
- Tires - Check tire inflation pressure and adjust if necessary
- Tire repair kit - Check and record the completeness and expiration date (if equipped)
- Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted
- Warning triangle - Check if present (if equipped)
- Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function
- Wiper blades - Check condition and replace if necessary

Additional Maintenance Items		
Work to be completed	Interval	Model Application
<input type="checkbox"/> Air filter - Replace	Every 60,000 miles	All vehicles
<input type="checkbox"/> AWD clutch - Change fluid (if equipped)	Every 3 years regardless of mileage	A3 45 TFSI, S3, RS 3, Q3 45 TFSI, TT Coupe 45 TFSI, TT Roadster 45 TFSI, TTS, TT RS Coupe only
<input type="checkbox"/> Brake fluid - Change	Every 2 years regardless of mileage	All vehicles
<input type="checkbox"/> Dust and Pollen filter - Replace	Every 20,000 miles or 2 years, whichever occurs first	All vehicles
<input type="checkbox"/> Fragrance cartridges - Change (if equipped)	Every 2 years regardless of mileage	A6, A7, A8 L, Q8 only
<input type="checkbox"/> Panoramic sunroof systems - Check drainage system by fluid check according to Elsa (if equipped)	Every 20,000 miles or 2 years, whichever occurs first	All vehicles
<input type="checkbox"/> Rear axle, quattro® Sport - Oil and ATF fluid changes	Every 60,000 miles	RS 5 only
<input type="checkbox"/> Ribbed V-belt compressor drive - Replace	Every 60,000 miles	Q7 55 TFSI only
<input type="checkbox"/> Ribbed V-belt starter/generator drive (including tensioner) - Replace	Every 60,000 miles	A6 45 TFSI only
<input type="checkbox"/> Spark plugs - Replace	Every 30,000 miles or 3 years, whichever occurs first	RS 3, RS 5, TT RS Coupe, A8 L 60 TFSI only



Additional Maintenance Items		
Work to be completed	Interval	Model Application
<input type="checkbox"/> Spark plugs - Replace	Every 40,000 miles or 6 years, whichever occurs first	S3, TTS, A4 40 TFSI, A4 45 TFSI, S4, A4 allroad® 45 TFSI, A5 45 TFSI, S5, A6 45 TFSI, A6 55 TFSI, A7 55 TFSI, A8 L 55 TFSI, Q5 45 TFSI,-SQ5, Q7 45 TFSI, Q8 55 TFSI only
<input type="checkbox"/> Spark plugs - Replace	Every 60,000 miles or 6 years, whichever occurs first	Q7 55 TFSI only
<input type="checkbox"/> Spark plugs - Replace	Every 80,000 miles or 6 years, whichever occurs first	A3 40 TFSI, A3 45 TFSI Q3 45 TFSI, TT Coupe 45 TFSI, TT Roadster 45 TFSI only
<input type="checkbox"/> S-Tronic transmission - Change fluid	Every 40,000 miles	RS 3 A4 40 TFSI, A4 45 TFSI, A4 allroad® 45 TFSI, A5 45 TFSI A6 45 TFSI, A6 55 TFSI, A7 55 TFSI, Q5 45 TFSI, TT RS Coupe only
<input type="checkbox"/> S-tronic transmission - Change fluid	Every 80,000 miles	A3 40 TFSI, A3 45 TFSI, S3, TT Coupe 45 TFSI, TT Roadster 45 TFSI, TTS Coupe only



MY 2019 Oil Capacity Chart

Model	Engine	Engine oil Approx. qty. w/filter change	Audi Oil Spec* **See Engine Oil Type Chart on next page for specific viscosities
A3	2.0L TFSI	5.7L (6.0 qt)	504*
A3 B-cycle	2.0L TFSI	5.7L (6.0 qt)	508*
RS 3	2.5L TFSI	7.1L (7.5 qt)	504*
S3	2.0L TFSI	5.7L (6.0 qt)	504*
A4/A4 allroad	2.0L TFSI	5.2L (5.49 qt)	504*
A4 B-cycle	2.0L TFSI	5.2L (5.49 qt)	508*
S4	3.0L TFSI	7.25L (7.7 qt)	508*
A5	2.0L TFSI	5.2L (5.5 qt)	504*
S5	3.0L TFSI	7.25L (7.7 qt)	508*
RS 5	2.9L TFSI	7.6L (8.0 qt)	504*
A6	2.0L TFSI	5.2L (5.5 qt)	508*
A6	3.0L TFSI	7.6L (8.0 qt)	508*
S6	2.9L TFSI	7.6L (8.0 qt)	504*
A7	3.0L TFSI	7.6L (8.0 qt)	508*
S7	2.9L TFSI	7.6L (8.0 qt)	504*
A8 L	3.0L TFSI	7.6L (8.0 qt)	508*
A8 L	4.0L TFSI	9.5L (10.0 qt)	504*
Q3	2.0L TFSI	5.7L (6.0 qt)	508*
Q5	2.0L TFSI	5.2L (5.5 qt)	508*
SQ5	3.0L TFSI	7.25L (7.7 qt)	508*
Q7	2.0L TFSI	5.2L (5.5 qt)	504*
Q7	3.0L TFSI	6.8L (7.2 qt)	504*
Q8	3.0L TFSI	7.6L (8.0 qt)	508*
TT	2.0L TFSI	5.7L (6.0 qt)	508*
TTS	2.0L TFSI	5.7L (6.0 qt)	504*
TT RS	2.5L TFSI	7.1L (7.5 qt)	504*

**Engine Oil Types

(Edition 04.2018)

CAUTION

All quantities are approximate. Always refer to the Repair Manual and/or the Maintenance Procedures for correct filling instructions.

Refer to Technical Bulletin 2010043 for engine oils meeting the required Audi oil quality standards.

Part numbers are for reference only. Always check with your parts department for the latest information.



Note:

Developed by Castrol®, in strategic co-operation with Volkswagen Group, the following Castrol® products meet VW/Audi specifications.

502 00 / 505 00 / 505 01

– Castrol EDGE® Professional® 5W40

508 00 / 509 00

– Castrol EDGE® Professional® 0W20 Long Life IV

504 00 / 507 00 Diesel Oil

– Castrol EDGE® Professional® 5W30 LL03

501 01 / 505 00

– Castrol EDGE® Professional® 10W60 Super Car (Formerly Castrol EDGE® Professional TWS 10W60)

2019 Audi Maintenance Schedule - Audi e-tron

MY 2019 Audi e-tron Maintenance Intervals - USA

Service intervals in miles												
	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Minor Maintenance (Every 1 year) ¹	X		X		X		X		X		X	
Standard Maintenance (Every 2 years) ²		X		X		X		X		X		X
Additional Maintenance Items	Refer to the Additional Maintenance Items Table below											

- 1) First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.
- 2) First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.

Check all completed items

Minor Maintenance

- Brake system - Check the thickness of the brake pads
- Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions
- First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)
- Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play
- Instrument cluster - Check warning and indicator lights
- Multi-point inspection - Complete
- Service reminder indicator display - Reset display
- Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
- Tires - Check condition and tire tread wear; Check and record the tread depth
- Tires - Check tire inflation pressure and adjust if necessary
- Tire repair kit - Check and record the completeness and expiration date (if equipped)
- Wiper blades - Check condition and replace if necessary

Standard Maintenance (Includes All Minor Maintenance Items)

- Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open
- Brake system - Check the thickness of the brake pads
- Brake system - Check for damage and leaks, condition of brake lines and the presence of the bleeder caps
-
- Charging socket - Check for contamination and damage
- Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions
- Cooling system for electrical components - Check coolant level and add if necessary according to procedure in ElsaPro
- Door hinges (including door stay) - Lubricate
- Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, brake lights, license plate lights, and hazard warning lights
- First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)
- Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play
- Front axle drive - drain coolant (with small cover removed)
- Headlights - Check adjustment



Standard Maintenance (continued)

- High voltage cooling system - Check for damage and leaks
- High voltage safety instruction labels - Check safety instruction labels for legibility
- High voltage system components - Check for damage and leaks; check cables and insulation for damage and proper mounting
- Horn - Check function
- Instrument cluster - Check warning and indicator lights
- Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination
- Motor compartment - Check transmission, final drive, and steering for leaks
- Multi-point inspection - Complete
- Panoramic sunroof system - Check function and drainage system by fluid check according to Elsa (if equipped)
- Plenum chamber and water drain valves: Check for dirt, and clean if necessary
NOTE: Time spent cleaning of item is a separate charge for service time
- Road test - Perform
- Safety belts - Check function
- Service reminder indicator display - Reset display
- Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
- Sunroof system - Check function (if equipped)
- Tires - Check condition and tire tread wear. Check and record the tread depth
- Tires - Check tire inflation pressure and adjust if necessary
- Tire repair kit - Check and record the completeness and expiration date (if equipped)
- Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted
- Warning triangle - Check if present (if equipped)
- Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function
- Wiper blades - Check condition and replace if necessary

Additional Maintenance Items	
Work to be completed	Interval
<input type="checkbox"/> Brake fluid - Change	Every 2 years regardless of mileage
<input type="checkbox"/> Dust and Pollen filter - Replace	Every 20,000 miles or 2 years, whichever occurs first
<input type="checkbox"/> Fragrance Cartridges - Change (if equipped)	Every 2 years regardless of mileage
<input type="checkbox"/> Rear axle drive - Replace coolant cartridge (with cover removed)	Every 30,000 miles or 2 years, whichever occurs first