

ThinkCentre M75q-1

Setup Guide

Guide de configuration

Einrichtungsanleitung

Guida di configurazione

Installatiegids

Manual de Configuração



Lenovo

For Barcode Position Only

Printed in China
PN: SP40KXXXXX

Initial Setup


Configuration initiale | Erstkonfiguration | Configurazione iniziale |
Eerste installatie | Configuração inicial



* For selected models | Sur certains modèles | Bei ausgewählten Modellen | Per alcuni modelli | Voor bepaalde modellen | Em modelos selecionados

Overview

Présentation | Überblick | Panoramica | Overzicht | Descrição geral



1. Power button
2. Storage drive activity indicator
3. Microphone connector
4. Headset connector
5. USB-C™ connector (USB 3.1 Gen 1)
6. Always On USB 3.1 connector Gen 1
7. ThinkCentre® LED
- * 8. Optional connectors (2)
9. Security-lock slot

10. Wi-Fi antenna slot
11. Ethernet connector
12. USB 2.0 connectors (2)
13. USB 2.0 connector
14. HDMI™ 1.4 out connector
15. USB 3.1 connector Gen 1
16. DisplayPort® 1.2 out connector
17. Power adapter connector

* For selected models

i Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

1. Power button
2. Storage drive activity indicator
3. Microphone connector
4. Headset connector
5. USB-C™ connector (USB 3.1 Gen 1)
6. Always On USB 3.1 connector Gen 1
7. ThinkCentre® LED
- * 8. Optional connectors (2)
9. Security-lock slot
10. Wi-Fi antenna slot
11. Ethernet connector
12. USB 2.0 connectors (2)
13. USB 2.0 connector
14. HDMI™ 1.4 out connector
15. USB 3.1 connector Gen 1
16. DisplayPort® 1.2 out connector
17. Power adapter connector

* For selected models

i Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

1. Power button
2. Storage drive activity indicator
3. Microphone connector
4. Headset connector
5. USB-C™ connector (USB 3.1 Gen 1)
6. Always On USB 3.1 connector Gen 1
7. ThinkCentre® LED
- * 8. Optional connectors (2)
9. Security-lock slot
10. Wi-Fi antenna slot
11. Ethernet connector
12. USB 2.0 connectors (2)
13. USB 2.0 connector
14. HDMI™ 1.4 out connector
15. USB 3.1 connector Gen 1
16. DisplayPort® 1.2 out connector
17. Power adapter connector

* For selected models

i Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

1. Power button
2. Storage drive activity indicator
3. Microphone connector
4. Headset connector
5. USB-C™ connector (USB 3.1 Gen 1)
6. Always On USB 3.1 connector Gen 1
7. ThinkCentre® LED
- * 8. Optional connectors (2)
9. Security-lock slot
10. Wi-Fi antenna slot
11. Ethernet connector
12. USB 2.0 connectors (2)
13. USB 2.0 connector
14. HDMI™ 1.4 out connector
15. USB 3.1 connector Gen 1
16. DisplayPort® 1.2 out connector
17. Power adapter connector

* For selected models

i Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

1. Power button
2. Storage drive activity indicator
3. Microphone connector
4. Headset connector
5. USB-C™ connector (USB 3.1 Gen 1)
6. Always On USB 3.1 connector Gen 1
7. ThinkCentre® LED
- * 8. Optional connectors (2)
9. Security-lock slot
10. Wi-Fi antenna slot
11. Ethernet connector
12. USB 2.0 connectors (2)
13. USB 2.0 connector
14. HDMI™ 1.4 out connector
15. USB 3.1 connector Gen 1
16. DisplayPort® 1.2 out connector
17. Power adapter connector

* For selected models

 Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

1. Power button
2. Storage drive activity indicator
3. Microphone connector
4. Headset connector
5. USB-C™ connector (USB 3.1 Gen 1)
6. Always On USB 3.1 connector Gen 1
7. ThinkCentre® LED
- * 8. Optional connectors (2)
9. Security-lock slot
10. Wi-Fi antenna slot
11. Ethernet connector
12. USB 2.0 connectors (2)
13. USB 2.0 connector
14. HDMI™ 1.4 out connector
15. USB 3.1 connector Gen 1
16. DisplayPort® 1.2 out connector
17. Power adapter connector

* For selected models

 Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

Customer Replacement Units (CRUs)

xxxxxxxxxxxx | xxxxxxxxxxxx | xxxxxxxxxxxx | xxxxxxxxxxxx |
xxxxxxxxxxxx

- Bottom cover
- Coin-cell battery
- Computer cover
- Dust shield
- * • External optical drive box
- * • External optical drive
- Internal speaker
- * • Keyboard
- M.2 solid-state drive
- Memory module
- * • Mouse

Refer to the *User Guide* for CRU definition.

- Power adapter
- * • Power adapter bracket
- Power cord
- Storage drive
- Storage drive bracket
- System fan
- * • Vertical stand
- * • VESA® mount bracket
- * • Wi-Fi card shield
- * • Wi-Fi card

- Bottom cover
- Coin-cell battery
- Computer cover
- Dust shield
- * • External optical drive box
- * • External optical drive
- Internal speaker
- * • Keyboard
- M.2 solid-state drive
- Memory module
- * • Mouse

Refer to the *User Guide* for CRU definition.

- Power adapter
- * • Power adapter bracket
- Power cord
- Storage drive
- Storage drive bracket
- System fan
- * • Vertical stand
- * • VESA® mount bracket
- * • Wi-Fi card shield
- * • Wi-Fi card

- Bottom cover
- Coin-cell battery
- Computer cover
- Dust shield
- * • External optical drive box
- * • External optical drive
- Internal speaker
- * • Keyboard
- M.2 solid-state drive
- Memory module
- * • Mouse

Refer to the *User Guide* for CRU definition.

- Power adapter
- * • Power adapter bracket
- Power cord
- Storage drive
- Storage drive bracket
- System fan
- * • Vertical stand
- * • VESA® mount bracket
- * • Wi-Fi card shield
- * • Wi-Fi card

- Bottom cover
- Coin-cell battery
- Computer cover
- Dust shield
- * • External optical drive box
- * • External optical drive
- Internal speaker
- * • Keyboard
- M.2 solid-state drive
- Memory module
- * • Mouse

Refer to the *User Guide* for CRU definition.

- Bottom cover
- Coin-cell battery
- Computer cover
- Dust shield
- * • External optical drive box
- * • External optical drive
- Internal speaker
- * • Keyboard
- M.2 solid-state drive
- Memory module
- * • Mouse

Refer to the *User Guide* for CRU definition.

- Bottom cover
- Coin-cell battery
- Computer cover
- Dust shield
- * • External optical drive box
- * • External optical drive
- Internal speaker
- * • Keyboard
- M.2 solid-state drive
- Memory module
- * • Mouse

Refer to the *User Guide* for CRU definition.

- Power adapter
- * • Power adapter bracket
- Power cord
- Storage drive
- Storage drive bracket
- System fan
- * • Vertical stand
- * • VESA® mount bracket
- * • Wi-Fi card shield
- * • Wi-Fi card

- Power adapter
- * • Power adapter bracket
- Power cord
- Storage drive
- Storage drive bracket
- System fan
- * • Vertical stand
- * • VESA® mount bracket
- * • Wi-Fi card shield
- * • Wi-Fi card

- Power adapter
- * • Power adapter bracket
- Power cord
- Storage drive
- Storage drive bracket
- System fan
- * • Vertical stand
- * • VESA® mount bracket
- * • Wi-Fi card shield
- * • Wi-Fi card

Additional information

Informations complémentaires | Zusätzliche Informationen | Informazioni aggiuntive | Aanvullende informatie | Informações adicionais

European Union – compliance with the Radio Equipment Directive

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type ThinkCentre M75q-1 is in compliance with Directive 2014/53/EU.

The full text of the system EU declaration of conformity and the EU wireless module declarations are available at the following Internet addresses:

- For desktop and all-in-one computers:
<https://www.lenovo.com/eu-doc-desktops>
- For workstations:
<https://www.lenovo.com/eu-doc-workstations>

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

Technology	Frequency band [MHz]	Maximum transmit power
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

Union européenne – Conformité à la directive concernant l'équipement radio

Lenovo (Singapore) Pte. Ltd., déclare par la présente que les catégories d'équipement radio de type ThinkCentre M75q-1 sont conformes à la directive 2014/53/EU.

Le texte complet de la déclaration de l'UE de conformité du système et les déclarations de l'UE sur les modèles sans fil sont disponibles aux adresses suivantes:

- Pour les ordinateurs portables:
<https://www.lenovo.com/eu-doc-desktops>
- Pour les tablettes:
<https://www.lenovo.com/eu-doc-workstations>

Cet équipement radio utilise les bandes de fréquences suivantes et une alimentation à haute fréquence maximum:

Technologie	Bande de fréquence [MHz]	Niveau de puissance de transmission maximal
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

Europäische Union – Erfüllung der Funkanlagen-Richtlinie

Lenovo (Singapore) Pte. Ltd. erklärt hiermit, dass das Funkgerät vom Typ ThinkCentre M75q-1 der EU-Richtlinie 2014/53/EU entspricht.

Die vollständige EU-Konformitätserklärung für das System sowie die EU-Richtlinien für drahtlose Module finden Sie unter den folgenden Internetadressen:

- Bei Notebook-Computern:
<https://www.lenovo.com/eu-doc-desktops>
- Bei Tablets:
<https://www.lenovo.com/eu-doc-workstations>

Dieses Funkgerät arbeitet mit den folgenden Frequenzbändern und der folgenden maximalen HF-Leistung:

Technologie	Frequenzband [MHz]	Maximale Übertragungsleistung
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

Unione Europea - Conformità alla direttiva sulle apparecchiature radio per l'Unione Europea

Pertanto, Lenovo (Singapore) Pte. Ltd., dichiara che il tipo di apparecchiatura radio ThinkCentre M75q-1 è conforme alla direttiva 2014/53/EU. Il testo integrale della dichiarazione di conformità dei sistemi dell'UE e delle dichiarazioni dei moduli

wireless dell'UE sono disponibili ai seguenti indirizzi Internet:

- Per i computer notebook:
<https://www.lenovo.com/eu-doc-desktops>
- Per i tablet:
<https://www.lenovo.com/eu-doc-workstations>

Questa apparecchiatura radio funziona con le seguenti bande di frequenza e di alimentazione a radiofrequenza massime:

Tecnologia	Banda di frequenza [Mhz]	Potenza di trasmissione massima
WLAN 802.11b/g/n	2400 - 2483,5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13,98 dBm
Bluetooth BR/EDR/LE	2400 - 2483,5	< 20 dBm

Europese Unie - naleving van de richtlijnen inzake radioapparatuur

Hierbij verklaart Lenovo (Singapore) Pte. Ltd. dat de radioapparatuur van het type ThinkCentre M75q-1 voldoet aan Richtlijn 2014/53/EU.

De volledige tekst van de EU-verklaring van conformiteit van het systeem en de EU-verklaringen inzake draadloze modules zijn beschikbaar op de volgende internetadressen:

- Voor notebookcomputers:
<https://www.lenovo.com/eu-doc-desktops>
- Voor tablets:
<https://www.lenovo.com/eu-doc-workstations>

Deze radioapparatuur werkt met de volgende frequentiebanden en maximaal radiofrequentievermogen:

Technologie	Frequentieb and [MHz]	Maximaal zendverm ogen
WLAN 802.11b/g/n	2400 - 2483,5	< 20 dBm

Technologie	Frequentieb and [MHz]	Maximaal zendverm ogen
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13,98 dBm
Bluetooth BR/EDR/LE	2400 - 2483,5	< 20 dBm

União Europeia - conformidade com a Diretiva de Equipamento de Rádio

Pelo presente, a Lenovo (Singapore) Pte. Ltd. declara que o tipo de equipamento de rádio do ThinkCentre M75q-1 está em conformidade com Diretiva 2014/53/UE.

O texto integral da declaração de conformidade da UE do sistema e as declarações da UE do módulo sem fios estão disponíveis nos seguintes endereços na Internet:

- Para os computadores portáteis:
<https://www.lenovo.com/eu-doc-desktops>
- Para tablets:
<https://www.lenovo.com/eu-doc-workstations>

Este equipamento de rádio funciona com as seguintes bandas de frequência e potência de radiofrequência máxima:

Tecnologia	Banda de frequência [MHz]	Energia máxima transmitida
WLAN 802.11b/g/n	2400 - 2483,5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13,98 dBm
Bluetooth BR/EDR/LE	2400 - 2483,5	< 20 dBm

E-manual

Manuel en ligne | E-Handbuch | Manuale elettronico | E-handleiding
| Manual electrónico



Second Edition (January 2020)

© Copyright Lenovo 2019, 2020.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce | Reuse | Recycle

