


LifeFitness

LIFE CYCLE LC9500HR

END OF LIFE




Customer Support Services
PARTS MANUAL

rev. 21 May 2009



Manual	Part Number
Service Manual	M051-00K46-B004
Operator Manual	M051-00K20-B125
Installation Instructions	M051-00K20-A287
Hardware Kit	AK46-00065-0000

	Page
Frame Components	4
Side Shrouds, Handlebar Shrouds and Cap	5
Alternator, Wheels, and Stabilizer Bar	6
Console Assembly	7
Accessory Tray	8
Handlebar Assembly	9
Crankarm Assembly	10
Freewheel Pulley/Clutch Assembly	11
Idler Arm Assembly	12
Seat w/Seat Post Assembly	13
Seat Plunger Assembly	14
Alternator Control Assembly	15



Frame Components



Side Shrouds, Handlebar Shrouds and Cap



Alternator, Wheels, and Stabilizer Bar





Console Assembly

AK46-00057-0001 Eng/Met
AK46-00057-0003 Ger/Eur
AK46-00057-0004 Spn/Eur
AK46-00057-0005 Spn
AK46-00057-0006 Eng
AK46-00057-0007 Frn/Eur
AK46-00057-0008 Itl/Eur
AK46-00057-0009 Dut/Eur
AK46-00057-0010 Frn
AK46-00057-0011 Por


Overlay Bezel Assembly

AK46-00058-0001 Eng/Met
AK46-00058-0003 Ger/Eur
AK46-00058-0004 Spn/Eur
AK46-00058-0005 Spn
AK46-00058-0006 Eng
AK46-00058-0007 Frn/Eur
AK46-00058-0008 Itl/Eur
AK46-00058-0009 Dut/Eur
AK46-00058-0010 Frn
AK46-00058-0011 Por




Console Case (Grey)
0K36-01187-0009



Battery Cover
0K36-01035-0007




Screw
0017-00101-1104

Screw
0017-00101-0823







NOTE: Bearing Kit Number GK18-00004-0023

