

# Mobi Pro Quick-Start Guide

Welcome to Mobi Pro and Eyefi Cloud—the ultimate cloud-connected WiFi SD card.

Your Mobi Pro card includes a full year of Eyefi Cloud, giving you the power to access all of your photos on a variety of devices, including your smartphone, tablet, PC, Mac, and even a smart TV.

This document will help you get started with Eyefi Mobi and Eyefi Cloud quickly:

- [Set up Mobi Pro to Transfer to a Mobile Device](#)
- [Set up Mobi Pro to Transfer to a Computer](#)
- [Configure Advanced Mobi Pro Options](#)

**Note:** You will need to uninstall any older versions of Eyefi apps from your computer, smartphone, or tablet before you set up your Mobi Pro card.

## Set up Mobi Pro to Transfer to a Mobile Device

The quickest way to start enjoying the benefits of Mobi Pro is to use our mobile app:

1. Download the free EyeFi Mobi app from Apple's App Store, Google Play, or Kindle App store.
2. Follow the on-screen instructions and activate your card.
3. Launch the app and sign up for Eyefi Cloud within the app to sync your photos automatically to your smartphone, tablet, PC, or Mac.

If you want to transfer RAW files to your mobile device, please go to the Mobi app's settings to enable wireless RAW transfer; by default this setting is turned off for mobile devices.

To configure the more advanced Mobi Pro options including selective transfer, RAW transfer, and infrastructure network support, you will first need to [download and install the Eyefi Mobi desktop app](#).

## Set up Mobi Pro to Transfer to a Computer

To enable your Mobi Pro card's more advanced features, such as selective transfer or transferring files via an existing home or studio network, you'll need to configure the settings via one of the Eyefi Mobi desktop apps.

1. [Download the Eyefi Mobi Desktop app](#).
2. Install the application and follow the on-screen instructions to activate your Mobi Pro Card

3. Sign up for an Eyefi Cloud account (one year is included as part of your Mobi Pro purchase). Eyefi Cloud syncs your photos to all your devices instantly.

For more detailed setup instructions, please see [Set Up Mobi Pro for Windows](#) and [Set Up Mobi Pro for Mac](#).

## Configure Advanced Mobi Pro Options

1. Select **Configure Advanced Options** when presented with the choice or go to the Eyefi Mobi Desktop app's **Options** or **Preferences** menu.
2. Place your Mobi Pro into the supplied card reader and insert it into a USB port or insert your Mobi Pro card into your SD card slot.
3. Select the advanced options you would like to configure:
  - **Wireless RAW Transfer:** RAW Transfer is turned ON by default. If you shoot in RAW on your camera those files will transfer automatically and wirelessly to your mobile device or computer.  
If you want to transfer RAW files to your mobile device, you will need to enable Wireless RAW Transfer in the Mobi app's settings; by default this setting is turned off for mobile devices.
  - **Selective Transfer Mode:** By default, your Mobi Pro card automatically transfers every photo that you shoot. If you enable Selective Transfer mode you will need to use the Protect or Lock key on your camera to mark the photos or videos you wish to transfer wirelessly.
  - **Infrastructure Network:** This allows you to add your Mobi Pro card to a home or studio network so you can connect to it without disconnecting your computer from the Internet or other network connections. We recommend you only connect to trusted Wi-Fi networks. This feature is not designed to work with public Wi-Fi hotspots. If an infrastructure network is not available, your Mobi Pro card will still connect via its own direct network.

Anytime you wish to change your Mobi Pro card's advanced features you will need access to a Windows PC (Windows 7 or later required) or a Mac (OS X 10.10—Yosemite or later required).

Now get out there and start taking pictures!