Legal Information

READ CAREFULLY AND KEEP THIS MANUAL FCC Information **Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the limits Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

**Revient or relocate the receiving antenna.

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- Rain/Moisture Warning

 Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.

 Do not submerge in water.

 Do not open this product or attempt to repair the unit yourself should it not be working.

Rating Label Definitons

Direct Current

Limited Warranty

90 Days Limited Warranty In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Go to our website portal to receive an SRO number.
 Provide proof of the date of purchase within the package (dated bill of
- Prepay all shipping costs to the authorized service center, and remember
- to insure your return.

 Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.

 Describe the defect or reason you are returning the product.
- Your product will be repaired or replaced, at our option, for the same or

similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

Customer Service Dept. 36 c/o Southern Telecom 400 Kennedy Drive Sayreville NJ 08872

Should have any questions or problems concerning this product, please visit our website at SouthernTelecom.com and click on Product Support.

Warranty Service Not Provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided not event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

TRIGHTING OF WATERING

LIMIBATION OF WATERING

THE MARRANT STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL

OTHER WARRANT IS SEPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTES OF

MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED NO

VERBAL OR WRITTEN INFORMATION GIVEN BY AT INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE

A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE REQUESTED.

REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE REQUESTED.

RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS

OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMED OF WARRANTES AND LIMITED

WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK EXCEPT TO THE EXTENT

PROHIBITED BY APPLICABLE LAW ANY IMPLIED WARRANTY OF REFINANCES FOR

A REPLACEMENT OF THE STATE OF THE STATE OF THE PART OF THE STATE OF THE PART OF THE STATE OF THE PART OF THE STATE OF

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Printed in China/Designed in the U.S

Aroma Diffuser with Compact Design



User Guide MDB1037

Getting Started

Questions & Support

If you have any questions or problems concerning this product, please visit our website at **SouthernTelecom.com** and click on **Product Support.**

- MDB1037- Aroma Diffuser (x1)
- USB Power Cable (x1)
- User Manual (x1)


Before You Begin...

- The amount and intensity of aroma produced will vary.
 Factors that affect production of aroma can include water type, humidity, temperature, air current, and/or type or brand of essential oil used.
- It may take up to a half hour before you can smell the essential
- Aroma Operation Time: Up to 3 hours
- Water Tank Capacity: 50 mL
- The suggested room size for this device is -100 ft² (this may vary greatly by environment, type of essential oil used, etc.).
- Only 100% natural essential oil should be used with this product. Oil containing chemical fragrance, spice, or other impurities may cause malfunctions.

 ONLY use the supplied power cable. If using a USB adapter,
- it MUST be a 5V/1A USB adapter (not included).

 When not in use, the diffuser should be stored in a dry, cool
- location, away from sources of water or heat.
 It is recommended that the diffuser be covered to protect it
- from exposure to dust if it will not be in use for a long period


Location of Controls



Setup & Use

- 1. Remove the lid and insert the pin of the supplied USB power cable to the DC 5V/0.8A power jack. Insert the USB connector into a 5V USB adapter (not included) and plug into a wall
- Socket.

 2. Turn right side up and fill the tank with room temperature water until the MAX level line is reached.
- 3. Add 2 3 drops (~0.1 0.15 mL) of essential oil.
- 4. Cover the water tank with the lid and place on a flat, sturdy surface.
- 5. Press the power button on the front of the diffuser to turn ON. The LED indicator will turn ON





When finished using, drain any remaining water from the tank, carefully rinse, and let dry. If you would like to more thoroughly clean the diffuser, use a small amount of neutral detergent such as dish soap.

Precautions and Warnings

- Do not fill the oil cup over MAX level line.
 Do not turn the aroma function on when the oil cup is empty.
- 3. Do not touch the inside base of the tank.
 4. Clean regularly per the maintenance instructions in this user
- manual to avoid malfunctions.

 5. Always unplug the power adapter before maintenance.
- 6. Always pour any remaining oil out of the oil cup and wipe with a clean, dry cloth.
- Essential oils can stain. In the event of a spill or leakage, please wipe away any water or oil with a soft cloth. 8. Do not let aroma blow directly onto furniture, clothing, art,
- or any valuable objects. 9. Keep away from direct sunlight, heat sources, air conditioners,
- 10. Always keep on a stable flat surface. Do NOT place on a carpet, bed, cushion or other non-flat, non-stable surface.
- 11. Keep away from electronic equipment. 12. Do not tip the product as it may cause oil to enter the
- mechanism and cause malfunction.
- 13. Do not use for more than 5 hours at a time.
- 14. Never move the product while in use.
- 15. Do not touch any part of the product with wet hands.
- 16. Keep out of reach of children and pets. Children should not be left unsupervised near this product. This unit is not to be used by children or any person(s) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given express supervision and instruction.
- 17. Keep the DC power jack clear of pathways, and do not forcefully pull or remove from the unit.
- 18. If smoke or burning smell is detected, immediately unplug