



2.0MP Smart HD PT Camera iB-HDP203SAM



User Manual

Please read the user manual carefully before using it.

iOS	Search "Guard_PTCAM" in App Store and install or scan the QR code.
Android	Search "Guard PTCAM V2" in Play Store and install or scan the QR Code.




IOS


Android

Step 1-: Connect power to the camera.


Step 2-: Wait for the Voice prompt "Access point established", to connect your mobile to Camera Wi-Fi (SSID named "MVxxxxxx")

Step 2-: Follow the below instructions on iBall PTCAM app:






1) Connect your phone to camera SSID




2) Open camera App



3) Click on "+" and select "Add networked device"



4) Input device ID or scan the QR code, click on "Add to the list"



5) Click on Set ★ and go to Network Settings



6) Select Station mode (Router connection mode), Select required Wi-Fi, Enter router Wi-Fi password

7) Wait for the voice prompt " Wi-Fi Connected" to access the camera over Internet.

FAQs

1. If Wi-Fi SSID contains special symbols, then camera might fail to connect to Wi-Fi.

2. Camera prompt is stuck on "Connecting"


(a) Check if your Wi-Fi is 2.4 GHz. Camera doesn't support 5 GHz.

(b) Reset the camera and reconfigure it


(c) DHCP should be ON

3. To reset the password of the camera, press the reset button for 5 seconds.


Video Playback



Search the record files



Select playback from time playback



Video playback interface



Device Setting

1) Network Settings:

- AP Mode: The Camera works as an independent Access Point (Hotspot).
- Station Mode: The camera is connected to the router.



Network Settings

2) Recording Settings:

- Auto Record: Continuous video recording (Note: Old videos will be overwritten, if memory card is FULL)
- Alarm video: Start video recording on motion detection
- Video & Audio: Audio will be recorded with video
- Video resolution: Set video recording quality (HD/SD)



Recording Settings

3) Date & Time setting: Set date and time of the camera



Date & Time Settings

4) Alarm setting:


Alarm ON/Alarm OFF: Switch various alarm settings ON/OFF

Alarm Area: Set motion detection area

Alarm Sound: Buzzer on motion detection

Voice Prompt Language: Camera voice prompt language

Save: Save the settings



Alarm Settings

More Functions



Notification Settings

App Password setting

About the app

Exit the app

**TECH. SUPPORT**

022-33825100/1860-30042255
support@iBall.co.in

**LIVE CHAT**

www.iBall.co.in

• Warranty: All iBall products are governed by iBall Warranty Terms. Refer www.iBall.co.in • Product specifications are subject to change without notice • All trademarks, logos, brands and product names are properties of their respective owners • Actual product/accessories may differ from the image shown • For any technical help on iBall products, please contact support@iBall.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website (www.iBall.co.in/e-waste).

www.iBall.co.in

1 year warranty

Ver.: 1.0.1