

MODEL PART DIAGRAM






PACKAGE CONTENTS



- (1) Pre-Filter
- (8) Activated Carbon Filters 2) True HEPA Filters
- Alexa Setup Guide / Wi-Fi Setup Guide
- * For a Certified Refurbished Air Purifier, there will be 4 New Carbon Filters and 1 True HEPA Filter included: equivalent to a 1-year supply.

WHERE TO USE



Allow 12 ~ 18 in. of space between TVs, radios, and other electronics Electromagnetic interference from certain electronics may cause product malfunction

Manual

Place indoors away from direct sunlight

Direct exposure may cause product malfunction or failure.


Only place on hard, flat surfaces

Flimsy or slanted surfaces may result in abnormal noise and vibrations.

Allow at least 12 ~ 18 in. from walls for maximum air flow

1

CONTROL PANEL



01. Auto Mode Indicator

The LED "Auto" light will indicate when Auto Mode is activated.

02. Air Quality Indicator

Color coded LED light indicates one of three levels of Air Quality: Red (poor), Amber (fair), and Blue (good).

03. Fan Speed Indicator

Indicates the current fan speed



04. Sleep Mode Indicator

The LED "Sleep" light will indicate when Sleep Mode is activated

05. Filter Replacement Indicator

LED light indicates when it is time to change the filter.

06 Filter Reset Button

After replacing the True HEPA Filter, use a small object such as a paper clip, to press and hold the Filter Reset Button for at least 5 seconds until the Filter Replacement Indicator turns off

07 Smart Sensor

Detects the amount of odorous gas in the environment. When in Auto mode, the fan speed adjusts according to the detected amount of gas.

08. Power Button

2

Turns the unit on or off. During the first 30 seconds of powering up, the Air Quality Indicator will cycle through Blue, Amber and Red colors.

· Smart sensor takes approximately 4 minutes to detect the air quality in the environment before normal operation begins.

09-1. Fan Speed/Auto/Sleep Buttons

Use the Fan Speed arrow buttons to set the desired fan speed. Fan Speeds cycle over in this sequence: Auto, Low, Medium, High, Turbo, Sleep, Auto,

Auto Mode:

· Auto Mode automatically adjusts fan speeds according to your indoor air quality. The fan speed will adjust to low when air quality is good, medium when fair, and to high when poor.

Sleep Mode:

When Sleep Mode is activated, the Air Quality Indicator LED light is disabled.

- Fan speed will automatically set to minimum speed (lower than 'Low') which will be nearly silent.
- · When Sleep Mode is active, PlasmaWave® will be disabled but it can be turned back on

09-2. PlasmaWave® Button

Press and hold the two arrow buttons <> + <> for

Press the Plasmawave® button when the unit is on to enable or disable this feature. By default, PlasmaWave[®] is enabled whenever the unit is powered on.

"When the unit is running, you may hear a chirping or buzzing sound. The sound is from large particles passing through PlasmaWave®, it is normal and does not signify product failure."

10. PlasmaWave® Indicator

Indicates whether PlasmaWave® is enabled or disabled.

11. Wi-Fi Button

- Press for 3 seconds to activate pairing mode.
- · When Wi-Fi is paired, press the button to turn Wi-Fi off or back on.

12. Wi-Fi Indicator

- Enables or disables the Wi-Fi feature.
- · When in the pairing state, the Wi-Fi LED flashes.

· When paired successfully, the Wi-Fi LED will be a solid white light.

13. Light Sensor


Detects the amount of ambient light in the environment. When in Auto Mode, the light sensor detects when to put the unit into Sleep Mode.

Winix Smart Wi-Fi Setup

Before you begin, make sure you have a wireless router that is 2.4Ghz or newer and have a Smartphone that is Android 5.0 and later or iOS 10.0 and later. Reference the Winix Smart Wi-Fi Set Up Guide for more details.

- Latest Phone Operating System requirements are subject to change based on future phone technology and app version updates.
- · Make sure to disable any VPN networks before connecting your unit.
- 1. Download the Winix Smart app on your device.
- · available via Google Play store or iTunes App store.
- 2. Run the app and follow the setup guide to connect your device to the unit.
- ① Select "New Unit" and choose C545 to connect to this model
- ② Read the notice and select "OK".
- ③ Enter the password to your Wi-Fi network.
- 4 Press and hold the Wi-Fi button on the unit's control panel until it beeps
- The Wi-Fi strength indicator will begin to blink. ⑤ Connect to the Winix Smart network via your
- device's network menu 6 Selecting "Next" will connect your unit to your
- device.
- ⑦ Define the unit settings (Name and Location).
- When set up is complete, the Winix Smart Indicator will light up.

4-STAGE AIR PURIFICATION



Designed to catch larger airborne particles found

03. True HEPA Filter

Winix True HEPA captures 99.97%* of airborne allergens including pollen, dust, smoke, pet dander, and other particles as small as 0.3 microns. *Based on independent laboratory tests conducted on inanimate particles as small as 0.3 microns.

02. Activated Carbon Filter

Reduces VOCs and household odors from cooking,

04. PlasmaWave®

Winix PlasmaWave® Technology reduces airborne Bacteria¹ & Influenza A Virus².

¹Tested against P. aeruginosa, Salmonella typhimurium, E. Coli, and Staph A. in a 4m³ chamber and unit must operate continuously for 1 hour to achieve 99.9% reduction. ²Tested against Influenza A Virus H3N2 in a 1m³ chamber and unit must operate continuously for 1 hour to achieve 99 6% reduction

MAINTENANCE

When to Replace Filters

Filter	Indicator Light	When to Service	When to Replace
Pre-Filter	none	Clean once every 14 days	Permanent
Activated Carbon Filter	none		Replace every 3 months
True HEPA Filter	Check Filter	Can NOT be WASHED	Lasts Approx. 12 months

- When the Check Filter Indicator LED is on, it is time to replace the Filter.
- · Intervals between filter replacement may vary depending on environment.

INITIAL OPERATION



1. Remove the front panel by grasping its upper edge and gently pulling forward.



2. Remove the Pre-Filter, then the bag of filters



3. Remove filters from protective plastic bag.



- 4. Install the filters until they fit securely in place. 03. True HEPA Filter (back)
- 02 Activated Carbon Filter (middle) 01. Pre-Filter (front)



5. After filters are installed, close the front panel




. Insert the power cord into an electrical outlet.

REPLACING FILTERS



CLEANING CARE

Cleaning the Filters:



Use a vacuum cleaner or soft brush to clean the Pre-Filter.

- · If it is excessively soiled, rinse in room temperature
- · Do not use detergent or soap.
- · Allow the filter to dry for 24 hours or more before using. • Intervals between filter cleaning may vary depending on the air quality.
- · Do not use hot water over 104°F or volatile fluids such as paint thinner



Do not use benzene, alcohol, or other volatile fluids, which may cause damage or discoloration.

3

Resetting Filter Life:

After replacing your True HEPA Filter, place the Pre-Filter back in and close the Front Panel. While the unit is on, hold the Filter Reset Button for at least 5 seconds until you hear the beep. After the beep, the Filter Replacement Indicator will disappear. Your Winix True HEPA is now reset.

Cleaning the Exterior & Interior:





Wipe with a soft damp cloth using room temperature

· Afterwards, wipe it down with a clean, dry cloth. Open the front panel and clean the interior with a

• For optimal performance, clean every 1 - 2 months.

NOTICE.

· When cleaning the unit, always unplug the power cord first and then wait until the unit has cooled down.

- · Never disassemble, repair, or modify this unit yourself.
- Do not use flammable sprays or liquid detergents. · Do not allow children to clean or maintain the unit.
- · Before cleaning or maintaining, ensure unit is unplugged.

SAFETY AND CAUTIONS

Before operating this equipment, carefully read and follow these safety cautions.

Ensure filters are inserted before running unit. Running the unit without filters can shorten the lifespan of the unit and cause electric shock or injury. Be sure foreign objects are NOT inserted into the

Objects can include pins, rods, and coins.

Do not touch any part of the interior of the unit with

The high voltage may cause electric shock.

Ensure unit intake and outlet vents do not become

Blockage may lead to increased internal termperatures, causing product failure and deformation.

Do not use the unit as a step stool or place heavy objects on the unit

Personal injury may occur or product failure and deformation

WARNING

Follow these instructions to reduce the risk of serious. injury or death and to reduce risk of damaging the unit.

- If the power cord is damaged, it must be replaced by a special cord. Reassembly is available from the manufacturer or its service agent.
- This appliance is not intended for use by a person (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge of the unit, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- · Children should be supervised to ensure that they do not play with the appliance.
- This unit is not intended to be used to preserve documents or art conservation

Do not pull on the power cord when unplugging the

Do not tie or knot the power cord when unit is in oneration

 If the unit becomes submerged in water, unplug it and contact customer service.

Do not unplug or move the unit while in operation.

Do not plug additional appliances into the same outlet or power supply

A Do not touch the plug with wet hands.

Unplug the unit when not in operation for extended periods of time.

Do not place around heating elements.

A Do not use around mist or fumes from industrial oil or around large quantities of metallic dust.

The cord can become damaged by forcefully bending, pulling, twisting, bundling, pinching or placing heavy objects on it.

Do not install in any sort of motor or transport vehicle (trucks, boats, ships, etc.).

Do not place in an area with excessive amounts of

 Do not place near any flammable materials aerosols, fuel, gases, etc.).

A Do not have the unit facing into wind or drafts.

Do not place below any electrical outlet.

Do not place in excessively humid areas where the unit may become wet.

Do not place unit closer than 12 inches from the wall during operation. It may cause condensation on the wall and the surrounding area.

SAFETY INSTRUCTIONS

Thank you for purchasing a Winix air purifier. This product is for household use only.

IMPORTANT CAUTIONS FOR USING YOUR AIR PURIFIER:

WARNING: Follow the instructions in this manual to reduce the risk of electric shock, short circuit, and/or fire.

- Do not repair or modify the unit. All repairs should be completed by a qualified technician.
- · The plug for this unit is polarized with one blade wider than the other. Do not force the plug into an electrical outlet. Do not alter the plug in any way. If the plug does not fit into the outlet, reverse the plug. If it still does not fit, contact a qualified technician to install a proper
- · Do not use if the power cord or plug is damaged or the connection to the wall outlet is loose.
- Use AC 120V only
- · Do not damage, break, forcefully bend, pull, twist, bundle, coat, pinch, or place heavy objects on the power cord.
- Periodically remove dust from the power plug. This will reduce the risk of shock due to humidity build up.
- · Remove the power plug from the outlet before cleaning the unit. When removing the power plug, grasp by holding the plug itself, never hold by the cord.

- If the power plug is damaged it must be replaced by the manufacturer or a qualified technician.
- · Remove the power plug from the outlet when not in use.
- · Do not handle the power plug with wet hands.
- Do not operate the unit when using indoor smokegenerating insecticides.
- Do not clean unit with benzene or paint thinner. Do not spray insecticides on the unit.
- · Do not use the unit where it is humid or where the unit may become wet, such as the bathroom.
- · Do not insert fingers or foreign objects into air intake or
- · Do not use the unit near flammable gases. Do not use near cigarettes, incense, or other spark-creating items.
- Unit will not remove carbon monoxide emitted from heating appliances or other sources.
- · Unplugging the product disconnects the remote functions

IMPORTANT PRECAUTIONS FOR USING YOUR AIR PURIFIER

- · Do not block the intake or outlet vents.
- · Do not use near hot objects, such as a stove.
- Do not use where the unit may come into contact with steam.
- · Do not use the unit on its side.
- · Keep away from products that generate oily residue, such as a deep fryer.
- · Do not use detergent to clean the unit.

- · Do not operate without a filter
- . Do not wash and reuse the True HEPA Filter
- Hold the handle on the back of the unit to transport.
- · Do not hold by the front panel
- . Do not stick any small objects into the air outlet vents or

FREQUENTLY ASKED QUESTIONS

The unit does not turn on at all.

- Is the plug securely attached to the outlet? - Make sure the outlet has power going to it and ensure the plug is secured.
- · Is there a power outage?
- Check to see if other lights and electrical equipment are working and try again

The unit doesn't work in Auto Mode.

- Has Auto Mode been selected?
- Press the Fan Speed button until Auto Mode is selected
- · Is the sensor blocked or clogged?
- Wipe Smart Sensor with wet cloth, then dry.

It vibrates and makes a lot of noise

- · Is it running on a slanted or uneven surface?
- Move the unit to a hard, flat, even area.

PRODUCT WARRANTY

The terms of the warranty are as follows:

- 1. This product is manufactured under stringent quality control and inspections.
- 2. The warranty will be voided if product failure is a result of negligence or misuse by the consumer.
- 3. A proof of purchase must be presented upon claiming a Product Warranty.
- 4. Store the proof of purchase in a safe place or register your product on winixamerica.com to upload your proof of purchase.
- 5. This warranty is valid only in the USA and Canada.
- * For more information visit
- https://winixamerica.com/terms-and-conditions/

The power plug and outlet feel hot.

- · Is the plug securely plugged in?
- · Make sure the plug is properly plugged into the outlet.

There is a strange smell.

7

- · Is it being used in a place with a lot of smoke, dust, or odors?
- Clean the air intakes on either side and clean the Pre-Filter.
- Replace the Carbon and the True HEPA Filter

The fan strength is weak. The unit is not purifying the air.

 Is the Check Filter Indicator light on? - Change the filters as required.

The display panel is dim.

- Is the Light Sensor blocked by debris?
- When Auto Mode is on, Sleep Mode is automatically activated when the Light Sensor detects that the room is

Product Name		Air Purifier
Model Name		C545
Purchase Date		
Warranty Period		Two (2) Years
Place of Purchase		
Place of Purchase tel.		
	Address	
Customer	Name	
	Tel.	

After purchase, be sure to complete all of the above information.

* Certified Refurbished Air Purifiers come with a 1-year warranty, All Winix Certified Refurbished Air Purifiers go through a detailed inspection and refurbishment process to ensure all quality and performance standards are met.

UNIT SPECIFICATIONS

Model Name	C545
Power Voltage	AC 120 V / 60 Hz
Power Rate	65 W
Verified Room Size	360 sq.ft.
Dimensions	13.7 in(W) × 8.4 in(D) × 20.5 in(H)
Weight	11 lbs
Replacement Filter	Filter S / SKU: 1712-0096-00

The exterior, design, and product specifications may be changed without prior notice to improve product performance.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.


"In French: Cet appareil contient des émetteurs/récepteurs exemptés de licence et conformes aux normes Innovation, Science et Economic, RSS(s) sans licence de Développement Canada. Le fonctionnement est soumis aux deux conditions

- cet appareil ne doit pas causer d'interférences nuisibles, et
- cet appareil doit accepter toute interférence recue, y compris les interférences pouvant provoquer un fonctionnement non souhaité.'

WINIX

User Manual


AIR PURIFIER



Model C545

Use & Care Guide

- The product warranty is printed on the back of this guide.
- · This product is manufactured for use only in USA / CA.
- · This product is suitable for 120 V only.









WINIX

Contact Winix for product related inquiries

contact information, and your address.

Dedicated Call Center: ☎ (877) 699-4649

· Website: www.winixamerica.com

and customer service

EPA Est. No: 99260-THA-1 2610-0256-00 Rev.07

To expedite service, please specify the model name and number, the nature of the problem, your

q

10