

LL63 SERIES INSTRUCTIONS



Transmitter

Transmitter Functions

Press once to turn on strobe.
Press again to turn on blue monitor light.
Press again to turn off.



When in blue monitor mode, blue LED will glow for approx 2 hours before automatically switching to strobe mode. You can change back to monitor mode by pressing the button.

Strobe will be at full brightness for a minimum of 8 hours even after the blue monitor mode is run for two hours.

If unit is in blue monitor mode, strobe will automatically start when device is submerged in water and continue until battery is depleted or user turns off via button push.

If unit is in off mode, strobe will automatically start when device is submerged in water and continue until battery is depleted or user turns off via button push.

Device charge time is approximately 1 hour 45 minutes to full charge from being fully depleted. Less time is needed if device has some charge left.

Any Qi certified charger (similar to cell phone chargers) can be used.

Locking Wrist Strap

After threading the nylon strap through safety device and back through the locking connector, turn locking button 90 degrees as shown using a coin or screwdriver.



Applying Graphic Label

Choose Graphic Label you would prefer.

Make sure the center and two holes where gold water sensor pins will protrude are punched out.

Remove protective backer from label. Apply label to unit making sure the gold pins push through the label completely. Use your fingernail or dull blunt object to secure around pins.

Test that sensor pins are not obstructed by wetting finger and making contact across pins.

WARNING: LABEL CAN NOT BE REMOVED ONCE PLACED. DOING SO WILL DAMAGE SEAL AND DEVICE WILL NO LONGER BE WATER PROOF.



Charging Transmitter

Place safety device on wireless charge pad so it is in the center. You will see a green light show through the graphic indicating that the unit is charging. Most wireless charge pads also have LED indicators showing when charging is taking place.



Receiver

Pairing Receiver with Transmitter

Press and hold the Check Button for 5 seconds then simply press the Manual-On button on the transmitter. You will see Pairing indicator blink multiple times showing the device has been paired. You can do this with up to 8 transmitters. To delete all pairing information, press and hold the Check Button for 10 seconds. This will erase all pairing memory. You may now pair new units to the receiver.

Each time you turn on your transmitter either in strobe or monitor you will here a confirming beep from the receiver to assure you that they are working.



Charging Receiver

Make sure the unit is fully charged by placing it standing up on a charge pad. Then wait until Charging Light stops blinking.



Turn Receiver On

Momentarily press On/Off Button to turn on. Unit initializes and then Ready indicator blinks showing unit is in normal operation.

Low Battery

When battery becomes low the Low Bat Indicator will Blink. Place unit on Charge Pad until battery is fully charged. Charging light will then go off indicating full charge.

Alarm in Progress

When Transmitter is placed in water the Strobe Light on the Transmitter activates, the Strobe Light on the Receiver activates and a Loud Alarm on the Receiver activates. To reset the Strobe on the Transmitter simply push the Manual-On Button. Transmitter will need to be dry to reset. To reset the Receiver, press the Pair/Reset Button or the On/Off Button. If On/Off Button is pressed the unit will not be in off state and will no longer monitor.

